



Technical catalogue - 2015.10

SACE Tmax XT

New low voltage moulded-case circuit-breakers up to 250 A

Power and productivity
for a better world™





Construction Characteristics	1
The SACE Tmax XT Ranges	2
Accessories	3
Characteristic Curves and Technical Information	4
Overall dimensions	5
Wiring Diagrams	6
Ordering codes	7
Glossary	8



Index

Construction characteristics	1/2
Regulations and Reference Standards.....	1/5
Identification of the SACE Tmax XT circuit-breakers	1/6
Nomenclature of the trip units and residual current protection devices	1/7

Construction characteristics

			XT1				
Size ^(G2.1)		[A]	160				
Poles		[No.]	3, 4				
Rated service voltage, U_e ^(G2.4)	(AC) 50-60Hz	[V]	690				
	(DC)	[V]	500				
Rated insulation voltage, U_i ^(G2.5)		[V]	800				
Rated impulse withstand voltage, U_{imp} ^(G2.6)		[kV]	8				
Versions			Fixed, Plug-in ⁽²⁾				
Breaking capacities according to IEC 60947-2			B	C	N	S	H
Rated ultimate short-circuit breaking capacity, I_{cu} ^(G2.7)							
Icu @ 220-230-240V 50-60Hz (AC)		[kA]	25	40	65	85	100
Icu @ 380V 50-60Hz (AC)		[kA]	18	25	36	50	70
Icu @ 415V 50-60Hz (AC)		[kA]	18	25	36	50	70
Icu @ 440V 50-60Hz (AC)		[kA]	15	25	36	50	65
Icu @ 500V 50-60Hz (AC)		[kA]	8	18	30	36	50
Icu @ 525V 50-60Hz (AC)		[kA]	6	8	22	35	35
Icu @ 690V 50-60Hz (AC)		[kA]	3	4	6	8	10
Icu @ 250V (DC) 2 poles in series		[kA]	18	25	36	50	70
Icu @ 500V (DC) 2 poles in series		[kA]	–	–	–	–	–
Icu @ 500V (DC) 3 poles in series ⁽³⁾		[kA]	18	25	36	50	70
Rated service short-circuit breaking capacity, I_{cs} ^(G2.8)							
Ics @ 220-230-240V 50-60Hz (AC)		[kA]	100%	100%	75% (50)	75%	75%
Ics @ 380V 50-60Hz (AC)		[kA]	100%	100%	100%	100%	75%
Ics @ 415V 50-60Hz (AC)		[kA]	100%	100%	100%	75%	50% (37.5)
Ics @ 440V 50-60Hz (AC)		[kA]	75%	50%	50%	50%	50%
Ics @ 500V 50-60Hz (AC)		[kA]	100%	50%	50%	50%	50%
Ics @ 525V 50-60Hz (AC)		[kA]	100%	100%	50%	50%	50%
Ics @ 690V 50-60Hz (AC)		[kA]	100%	100%	75% (5)	50% (5)	50%
Ics @ 250V (DC) 2 poles in series		[kA]	100%	100%	100%	100%	75%
Ics @ 500V (DC) 2 poles in series		[kA]	–	–	–	–	–
Ics @ 500V (DC) 3 poles in series ⁽³⁾		[kA]	100%	100%	100%	100%	75%
Rated short-circuit making capacity, I_{cm} ^(G2.10)							
Icm @ 220-230-240V 50-60Hz (AC)		[kA]	52.5	84	143	187	220
Icm @ 380V 50-60Hz (AC)		[kA]	36	52.5	75.6	105	154
Icm @ 415V 50-60Hz (AC)		[kA]	36	52.5	75.6	105	154
Icm @ 440V 50-60Hz (AC)		[kA]	30	52.5	75.6	105	143
Icm @ 500V 50-60Hz (AC)		[kA]	13.6	36	63	75.6	105
Icm @ 525V 50-60Hz (AC)		[kA]	9.18	13.6	46.2	73.5	73.5
Icm @ 690V 50-60Hz (AC)		[kA]	4.26	5.88	9.18	13.6	17
Breaking capacities according to NEMA-AB1							
@ 240V 50-60Hz (AC)		[kA]	25	40	65	85	100
@ 480V 50-60Hz (AC)		[kA]	8	18	30	36	65
Utilisation Category (IEC 60947-2)			A				
Reference Standard			IEC 60947-2				
Isolation behaviour			✓				
Mounted on DIN rail			DIN EN 50022				
Mechanical life ^(G2.14)			[No. Operations]	25000			
			[No. Hourly operations]	240			
Electrical life @ 415 V (AC) ^(G2.13)			[No. Operations]	8000			
			[No. Hourly operations]	120			
Dimensions - Fixed		3 poles	[mm]	76.2 x 70 x 130			
(Width x Depth x Height)		4 poles	[mm]	101.6 x 70 x 130			
Total opening time							
	Circuit-breaker with shunt opening release	[ms]	15				
	Circuit-breaker with undervoltage release	[ms]	15				
Trip units for power distribution							
	TMD/TMA						
	TMD/TMF				■		
	Ekip LS/I						
	Ekip I						
	Ekip LSI						
	Ekip LSIG						
	Ekip E						
Trip units for motor protection							
	MF/MA				■		
	Ekip M-I						
	Ekip M-LIU						
	Ekip M-LRIU						
Trip units for generator protection							
	TMG						
	Ekip G-LS/I						
Trip units for oversized Neutral Protection							
	Ekip N-LS/I						
Interchangeable protection trip units							
Weight	Fixed	3/4 poles	[kg]	1.1 / 1.4			
	Plug in (EF terminals)	3/4 poles	[kg]	2.21 / 2.82			
	Withdrawable (EF terminals)	3/4 poles	[kg]				

⁽¹⁾ Icu=100kA and Ics=100%Icu @690V only for XT4 160

⁽²⁾ XT1 plug-in In max=125A

⁽³⁾ XT1 500V DC 4 poles in series

⁽⁴⁾ XT4 750V DC please ask ABB SACE for availability

■ Complete circuit-breaker
▲ Loose trip unit


XT2					XT3		XT4					
160					250		160 / 250					
3, 4					3, 4		3, 4					
690					690		690					
500					500		500 ^(d)					
1000					800		1000					
8					8		8					
Fixed, Withdrawable, Plug-in					Fixed, Plug-in		Fixed, Withdrawable, Plug-in					
N	S	H	L	V	N	S	N	S	H	L	V	
65	85	100	150	200	50	85	65	85	100	150	200	
36	50	70	120	150	36	50	36	50	70	120	150	
36	50	70	120	150	36	50	36	50	70	120	150	
36	50	65	100	150	25	40	36	50	65	100	150	
30	36	50	60	70	20	30	30	36	50	60	70	
20	25	30	36	50	13	20	20	25	45	50	50	
10	12	15	18	20	5	6	10	12	15	20	25/100 ⁽¹⁾	
36	50	70	85	100	36	50	36	50	70	85	100	
–	–	–	–	–	–	–	36	50	70	85	100	
36	50	70	85	100	36	50	36	50	70	85	100	
100%	100%	100%	100%	100%	75%	50%	100%	100%	100%	100%	100%	
100%	100%	100%	100%	100%	75%	50% (27)	100%	100%	100%	100%	100%	
100%	100%	100%	100%	100%	75%	50% (27)	100%	100%	100%	100%	100%	
100%	100%	100%	100%	100%	75%	50%	100%	100%	100%	100%	100%	
100%	100%	100%	100%	100%	75%	50%	100%	100%	100%	100%	100%	
100%	100%	100%	100%	100%	75%	50%	100%	100%	100%	100%	100%	
100%	100%	100%	75% (15)	75%	75%	50%	100%	100%	100%	100%	75% (20)/100% ⁽¹⁾	
100%	100%	100%	100%	100%	100%	75%	100%	100%	100%	100%	100%	
–	–	–	–	–	–	–	100%	100%	100%	100%	100%	
100%	100%	100%	100%	100%	100%	75%	100%	100%	100%	100%	100%	
143	187	220	330	440	105	187	143	187	220	330	440	
75.6	105	154	264	330	75.6	105	75.6	105	154	264	330	
75.6	105	154	264	330	75.6	105	75.6	105	154	264	330	
75.6	105	143	220	330	52.5	84	75.6	105	143	220	330	
63	75.6	105	132	154	40	63	63	75.6	105	132	154	
40	52.5	63	75.6	105	26	40	40	52.5	94.5	105	105	
17	24	30	36	40	7.65	13.6	17	24	30	40	52.5	
65	85	100	150	200	50	85	65	85	100	150	200	
30	36	65	100	150	25	35	30	36	65	100	150	
A IEC 60947-2					A IEC 60947-2		A IEC 60947-2					
✓ DIN EN 50022					✓ DIN EN 50022		✓ DIN EN 50022					
25000					25000		25000					
240					240		240					
8000					8000		8000					
120					120		120					
90 x 82.5 x 130					105 x 70 x 150		105 x 82.5 x 160					
120 x 82.5 x 130					140 x 70 x 150		140 x 82.5 x 160					
15					15		15					
15					15		15					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■		■					
■					■							

Construction characteristics


The references in round brackets ^(Gx.x) in the technical catalogue refer to the Glossary in the final charter of the technical catalogue.



Positive operation



Installation positions



Protection degrees



Test pushbutton

All the moulded-case circuit-breakers in the SACE Tmax XT family are realized in accordance with the following construction characteristics:

- double insulation^(G1.5);
- positive operation^(G1.6);
- isolation behaviour^(G1.7);
- electromagnetic compatibility^(G1.8);
- tropicalization^(G1.9);
- impact and vibration resistance^(G1.10);
- power supply from the top towards the bottom or vice versa;
- versatility of the installation. It is possible to mount the circuit-breaker in horizontal, vertical, or lying down position without any derating of the rated characteristics;
- no nominal performance derating for use up to an altitude of 2000m. Above 2000m, the properties of the atmosphere (composition of the air, dielectric strength, cooling power and pressure) change, having an impact on the main parameters which define the circuit-breaker. The table below gives the changes to the main performance parameters;

Altitude		2000m	3000m	4000m	5000m
Rated employ voltage, U _e	[V]	690	600	540	470
Rated uninterrupted current	%	100	98	93	90

- the SACE Tmax XT circuit-breakers can be used in environments where the temperature is between -25°C and +70°C and stored in environments where the temperature is between -40°C and +70°C. To use temperatures other than 40°C, see the "Temperature Performances" paragraph of the Characteristic Curves and the technical information chapter;
- different degrees of protection IP (International Protection)^(G 1.11);

Circuit-breaker

	With front	Without front ⁽¹⁾	With Front for lever -FLD-	With rotary Handles	With transmitted rotary handle and accessory IP54	With high terminal covers HTC	With low terminal covers LTC
A	IP40	IP20	IP40	IP40	IP54	IP40	IP40
B	IP20	IP20	IP20	IP20	IP20	IP40	IP40
C	NC	NC	NC	NC	NC	IP40	IP30

⁽¹⁾ During the installation of electrical accessories
NC Not classifiable

Accessories

	Motor operator MOD, MOE or MOE-E	Residual current devices	Residual current from switchboard RCQ020	Automatic Transfer Switch ATS021 and ATS022
On Front	IP30	IP40	IP41	IP40

- all the circuit-breakers in the XT family are fitted with a test pushbutton which allows the release test to be done. This test must be carried out with the circuit-breaker closed and with no current.

Regulations and Reference Standards



Hologram

Conformity with Standards

The SACE Tmax XT circuit-breakers and their accessories are constructed in conformity with:

- Standard^(G6.1):
 - IEC 60947-2;
- Directives^(G6.2):
 - EC “Low Voltage Directive” (LVD) N° 2006/95/EC (in replacement of 73/23/EEC and subsequent amendments);
 - EC “Electromagnetic Compatibility Directive” (EMC) 2004/108/CE;
- Naval Registers^(G6.3) (ask ABB SACE for the versions available):
 - Lloyd’s Register of Shipping, Germanischer Lloyd, Bureau Veritas, Rina, Det Norske Veritas, Russian Maritime Register of Shipping, ABS.



Certification of conformity with the product Standards is carried out in the ABB SACE tests laboratory (accredited by SINAL) in respect of the EN 45011 European Standard, by the Italian certification body ACAE (Association for Certification of Electrical Apparatus), member of the European LOVAG organisation (Low Voltage Agreement Group) and by the Swedish certification body SEMKO belonging to the international IECEE organisation.

The SACE Tmax XT series has a hologram on the front, obtained using special anti-forgery techniques, a guarantee of the quality and genuineness of the circuit-breaker as an ABB SACE product.



Company Quality System

The ABB SACE Quality System conforms with the following Standards:

- ISO 9001 international Standard;
- EN ISO 9001 (equivalent) European Standards;
- UNI EN ISO 9001 (equivalent) Italian Standards;
- IRIS International Railway Industry Standard.

The ABB SACE Quality System attained its first certification with the RINA certification body in 1990.



Naval Registers

Environmental Management System, Social Responsibility and Ethics

Attention to protection of the environment is a priory commitment for ABB SACE. Confirmation of this is the realisation of an Environmental Management System certified by RINA (ABB SACE was the first industry in the electromechanical sector in Italy to obtain this recognition) in conformity with the International ISO14001 Standard. In 1999 the Environmental Management System was integrated with the Occupational Health and Safety Management System according to the OHSAS 18001 Standard and later, in 2005, with the SA 8000 (Social Accountability 8000) Standard, committing itself to respect of business ethics and working conditions.

The commitment to environmental protection becomes concrete through:


- selection of materials, processes and packaging which optimise the true environmental impact of the product;
- use of recyclable materials;
- voluntary respect of the RoHS directive^(G6.4).

ISO 14001, 18001 and SA8000 recognitions together with ISO 9001 made it possible to obtain RINA BEST FOUR CERTIFICATION.


Identification of the SACE Tmax XT circuit-breakers

The characteristics of the circuit-breaker are given on the rating nameplate on the front of the circuit-breaker, and on the side rating plate.

Front label



Side label



- 1 Name of the circuit-breaker and performance level^(*)
- 2 In: rated current of the circuit-breaker^(*)
- 3 Uimp: rated impulse withstand voltage^(*)
- 4 Ui: insulation voltage^(*)
- 5 Ics rated short-circuit duty breaking capacity^(*)
- 6 Icu: rated ultimate short-circuit breaking capacity^(*)
- 7 Ue: rated service voltage^(*)
- 8 Symbol of isolation behaviour^(*)
- 9 Reference Standard IEC 60947-2^(*)
- 10 Serial number
- 11 Anti-forgery logo
- 12 Test pushbutton
- 13 CE marking
- 14 Utilisation Category
- 15 Reference Standard NEMA-AB1

^(*) In compliance with the IEC 60947-2 Standard

Nomenclature of the trip units and residual current protection devices

The tables below give details of the logic with which each thermomagnetic trip units, electronic trip units and residual current devices has been named.

Magnetic trip units

Family Name		Protection
M: magnetic	+	F: with fixed threshold A: with adjustable threshold

Thermomagnetic trip units

Family Name		Protection
TM: thermomagnetic	+	A: with adjustable thermal and magnetic threshold D: with adjustable thermal and fixed magnetic threshold G: with adjustable thermal and fixed magnetic threshold (for generator protection)

Example:

- MA: magnetic only trip unit, with adjustable protection threshold;
- TMD: thermomagnetic trip unit, with adjustable thermal and fixed magnetic protection threshold;
- TMG: thermomagnetic trip unit, with adjustable thermal and fixed magnetic protection threshold, specifically for protection of generators.

Electronic trip units

Family Name		Application		Protection	Circuit-breaker ⁽¹⁾
Ekip	+	: Distribution M: Motor protection G: Generator protection N: Neutral E: Energy measurements	+	I LS/I LSI LSIG LIU LRIU	XT2 XT4

⁽¹⁾ Circuit-breaker has to be defined only with loose release.

Example:

- Ekip LS/I: electronic trip unit for distribution networks protection, with "L" against overload and as an alternative "S" protection function against delay short circuit or "I" protection function against instantaneous short circuit;
- Ekip M-LRIU: electronic trip unit for motors protection, with LRIU protection functions;
- Ekip N-LS/I XT2: loose electronic trip unit for the neutral protection, with "L" against overload and as an alternative "S" protection function against delay short circuit or "I" protection function against instantaneous short circuit.

Residual Current Protection Devices

Family Name		Typology
RC	+	Inst: instantaneous type "A" Sel: selective type "A" Sel 200: selective type "A" reduced to 200mm B Type: selective type "B"

Example:

- RC Inst: residual current protection device with instantaneous timing;
- RC Sel 200: residual current protection device with adjustable time trip, reduced to 200mm;
- RC B type: residual current protection device "B" type.



Index

The SACE Tmax XT family ranges	2/2
 Circuit-breakers for power distribution	
Main characteristics	2/3
Thermomagnetic trip units	2/5
Electronic trip units.....	2/7
 Circuit-breakers for motors protection	
Main characteristics	2/15
Magnetic trip units.....	2/17
Electronic trip units.....	2/18
 Circuit-breakers for generator protection	
Main characteristics	2/22
 Circuit-breakers for oversized neutral protection	
Main characteristics	2/26
 Switch-disconnectors	
Main characteristics	2/28
 Special applications	
Communication system.....	2/30

The SACE Tmax XT family ranges

The SACE Tmax XT moulded-case circuit-breaker family complies with different installation requirements. Circuit-breakers are available with trip units dedicated to different applications, such as power distribution, generator protection, motor protection and oversized neutral protection. Some of these circuit-breakers can also be used in communication systems and plants that function at 400Hz. Switch-disconnectors are also available.

In = Rated uninterrupted current ^(G2,2)	XT1 160	XT2 160	XT3 250	XT4 250
Power distribution				
Thermomagnetic trip units				
TMD/TMF	16...160		63...250	
TMD/TMA		1.6...160		16...250
Electronic trip units				
Ekip LS/I		10...160		40...250
Ekip I		10...160		40...250
Ekip LSI		10...160		40...250
Ekip LSIG		10...160		40...250
Ekip E-LSIG				40...250
Motor protection				
Magnetic trip units				
MF/MA	3.2...125	1...160 ⁽¹⁾	100...200 ⁽¹⁾	10...200 ⁽¹⁾
Electronic trip units				
Ekip M-I		20...100 ⁽¹⁾		
Ekip M-LIU		25...160 ⁽¹⁾		40...160 ⁽¹⁾
Ekip M-LRIU		25...100 ⁽¹⁾		40...200 ⁽¹⁾
Generator Protection				
Thermomagnetic trip units				
TMG		16...160	63...250	
Electronic trip units				
Ekip G-LSI		10...160		40...250
Oversized Neutral Protection 160%				
Electronic trip units				
Ekip N-LS/I		10...100 ⁽²⁾		40...160 ⁽²⁾
Switch-disconnectors	■		■	■
Special applications				
400Hz	■	■	■	■
Communication		■		■

⁽¹⁾ Only 3 poles version

⁽²⁾ Only 4 poles version

Circuit-breakers for power distribution

Main characteristics

SACE Tmax XT moulded-case circuit-breakers are the ideal solution for all distribution levels, from the main low voltage switchboard to the subswitchboards in the installation. They feature high specific let-through current peak and energy limiting characteristics that allow the circuits and equipment on the load side to be sized in an optimum way. SACE Tmax XT circuit-breakers with thermomagnetic and electronic trip units protect against overloads, short-circuits, earth faults and indirect contacts in low voltage distribution networks.

The SACE Tmax XT family of moulded-case circuit-breakers can be equipped with:

- thermomagnetic trip units^(G3.2), for direct and alternating current network protection, using the physical properties of a bimetal and an electromagnet to detect the overloads and short-circuits;
- electronic trip units^(G3.4), for alternating current network protection. Releases with microprocessor technology obtain protection functions that make the operations extremely reliable and accurate. The power required for operating them correctly is supplied straight from the current sensors of the releases. This ensures that they trip even in single-phase conditions and on a level with the minimum setting.

The electronic protection trip unit consists of:

- 3 or 4 current sensors (current transformers);
- a protection unit;
- an opening solenoid (built into the electronic trip unit).

Characteristics of Electronic trip units SACE Tmax XT

Operating temperature	-25°C...+70°C
Relative humidity	98%
Self-supplied	0.2xIn (single phase) ^{(1) (2)}
Auxiliary supply (where applicable)	24V DC ± 20%
Operating frequency	45...66Hz or 360...440Hz
Electromagnetic compatibility	IEC 60947-2 Annex F

⁽¹⁾ 0.32 x In for Ekip N-LS/I

⁽²⁾ For 10A: 0.4In

Circuit-breakers for power distribution

Main characteristics

Characteristics of circuit-breakers for power distribution

			XT1					XT2					XT3		XT4				
Size ^(G2.1)	[A]		160					160					250		160/250				
Poles	[Nr.]		3, 4					3, 4					3, 4		3, 4				
Rated service voltage, Ue ^(G2.4)	(AC) 50-60Hz	[V]	690					690					690		690				
	(DC)	[V]	500					500					500		500				
Rated insulation voltage, Ui ^(G2.5)		[V]	800					1000					800		1000				
Rated impulse withstand voltage, Uimp ^(G2.6)		[kV]	8					8					8		8				
Versions			Fixed, Plug-in					Fixed, Withdrawable, Plug-in					Fixed, Plug-in		Fixed, Withdrawable, Plug-in				
Breaking capacities			B	C	N	S	H	N	S	H	L	V	N	S	N	S	H	L	V
Trip units			Thermomagnetic					Thermomagnetic, Electronic					Thermomagnetic		Thermomagnetic, Electronic				
TMD/TMA								■							■				
TMD/TMF			■										■						
Ekip LS/I								■ In = 10A, 25A, 63A, 100A, 160A							■ In = 40A, 63A, 100A, 160A, 250A				
Ekip I								■ In = 10A, 25A, 63A, 100A, 160A							■ In = 40A, 63A, 100A, 160A, 250A				
Ekip LSI								■ In = 10A, 25A, 63A, 100A, 160A							■ In = 40A, 63A, 100A, 160A, 250A				
Ekip LSIG								■ In = 10A, 25A, 63A, 100A, 160A							■ In = 40A, 63A, 100A, 160A, 250A				
Ekip E-LSIG															■ In = 40A, 63A, 100A, 160A, 250A				
Interchangeability								■							■				

■ Complete circuit-breaker

Circuit-breakers for power distribution

Thermomagnetic trip units

TMD/TMF


Main characteristics:

- available for XT1 and XT3 in the three-pole and four-pole versions;
- protections:
 - against overload (L): adjustable protection threshold from 0.7...1xIn, with inverse long-time trip curve (TMD)*;
 - against instantaneous short-circuits (I): fixed 10xIn protection threshold, with instantaneous trip curve;
- 100% neutral protection in four-pole circuit-breakers. 50% neutral protection is only available for In≥125A;
- the thermal protection setting is made by turning the relative cursor on the front of the release.

* fixed protection at 1xIn (TMF)

Example with XT3 250A

Rotary switch for thermal protection setting



XT1

TMD/TMF

Breaking capacity		TMD/TMF		TMD	TMD	TMD	TMD	TMD	TMD	TMD	TMD	TMD
 I ₁ = 1xIn (TMF) I ₁ = 0.7...1xIn (TMD)	In [A]	16*	20*	25	32	40	50	63	80	100	125	160
	Neutral [A] - 100%	16	20	25	32	40	50	63	80	100	125	160
	Neutral [A] - 50%	–	–	–	–	–	–	–	–	–	80	100
 I ₃ = 10xIn	I ₃ [A]	450	450	450	450	450	500	630	800	1000	1250	1600
	Neutral [A] - 100%	450	450	450	450	450	500	630	800	1000	1250	1600
	Neutral [A] - 50%	–	–	–	–	–	–	–	–	–	800	1000

* 16A and 20A for N, S, H have the TMF trip unit

XT3

TMD

 I ₁ = 0.7...1xIn	In [A]	63	80	100	125	160	200	250
	Neutral [A] - 100%	63	80	100	125	160	200	250
	Neutral [A] - 50%	–	–	–	80	100	125	160
 I ₃ = 10xIn	I ₃ [A]	630	800	1000	1250	1600	2000	2500
	Neutral [A] - 100%	630	800	1000	1250	1600	2000	2500
	Neutral [A] - 50%	–	–	–	800	1000	1250	1600

Circuit-breakers for power distribution

Thermomagnetic trip units

TMD/TMA

Main characteristics:

- available for XT2 and XT4 in the three-pole and four-pole versions;
- protections:
 - against overload (L): adjustable protection threshold from 0.7...1xIn, with inverse long time trip curve;
 - against instantaneous short-circuit (I):
 - fixed protection threshold for $I_n \leq 32A$,
 - adjustable threshold between 8...10xIn for 40A,
 - adjustable threshold between 6...10xIn for 50A,
 - adjustable threshold between 5...10xIn for $I_n \geq 63A$;
- 100% neutral protection in four-pole circuit-breakers. 50% neutral protection is only available for $I_n \geq 125A$;
- the thermal and magnetic protection settings are made by turning the relative cursors on the front of the release.

Example with XT4 250A



XT2

TMD/TMA

 $I_t = 0.7...1xI_n$	In [A]	1.6 ⁽¹⁾	2 ⁽¹⁾	2.5 ⁽¹⁾	3.2 ⁽¹⁾	4 ⁽¹⁾	5 ⁽¹⁾	6.3 ⁽¹⁾	8 ⁽¹⁾	10 ⁽¹⁾	12.5 ⁽¹⁾	16	20	25	32	40	50	63	80	100	125	160
	Neutral [A] - 100%	1.6	2	2.5	3.2	4	5	6.3	8	10	12.5	16	20	25	32	40	50	63	80	100	125	160
	Neutral [A] - 50%	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	80	100
	TMD	16	20	25	32	40	50	63	80	100	125	300	300	300	320							
	TMA															300... 400	300... 500	300... 630	400... 800	500... 1000	625... 1250	800... 1600
	Neutral [A] - 100%	16	20	25	32	40	50	63	80	100	125	300	300	300	320	300... 400	300... 500	300... 630	400... 800	500... 1000	625... 1250	800... 1600
	Neutral [A] - 50%	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	400... 800	500... 1000

⁽¹⁾ Available only as complete circuit-breaker

XT4

TMD/TMA

 $I_t = 0.7...1xI_n$	In [A]	16	20	25	32	40	50	63	80	100	125	160	200	225	250
	Neutral [A] - 100%	16	20	25	32	40	50	63	80	100	125	160	200	225	250
	Neutral [A] - 50%	–	–	–	–	–	–	–	–	–	80	100	125	125	160
	TMD	300	300	300	320										
	TMA					300... 400	300... 500	315... 630	400... 800	500... 1000	625... 1250	800... 1600	1000... 2000	1125... 2250	1250... 2500
	Neutral [A] - 100%	300	300	300	320	300... 400	300... 500	315... 630	400... 800	500... 1000	625... 1250	800... 1600	1000... 2000	1125... 2250	1250... 2500
	Neutral [A] - 50%	–	–	–	–	–	–	–	–	–	315... 630	500... 1000	625... 1250	625... 1250	500... 1000


Circuit-breakers for power distribution

Electronic trip units

Ekip I

Main characteristics:

- usable with the XT2 and XT4 circuit-breaker in the three-pole and four-pole versions;
- protections:
 - against instantaneous short-circuit (I): adjustable protection threshold from 1...10xIn, with instantaneous trip curve;
 - of the neutral in four-pole circuit-breakers:
 - for In≥100A in the OFF or ON positions, 50% and 100% of the phases can be selected;
 - for In<100A, neutral protection is fixed at 100% of the phases and disabled by user;
- manual setting using the relative dip-switches, which allow the settings to be made even when the trip unit is off;
- LED:
 - LED lit with a steady green light indicating that the trip unit is supplied correctly. The LED comes on when the current exceeds 0.2xIn;
 - LED with a steady red light, indicating that protection I has tripped; red LED light on connecting Ekip TT or Ekip T&P accessories after circuit-breaker opening for “I protection” intervention;
 - Ekip I is equipped with a trip coil disconnection protection device that detects whether the opening solenoid has disconnected. Signalling is made by the red LED flashing;
- test connector on the front of the trip unit;
 - to connect the Ekip TT trip test unit, which allows trip test, LED test and signalling about latest trip happened;
 - to connect the Ekip T&P unit, which allows the measurements to be read, the trip test to be conducted and the I protection function test to be carried out;
- self-supply from a minimum current of 0.2xIn up.



Ekip I

Protection function	Trip threshold	Trip curve ⁽¹⁾	Excludability	Relation
 Against short-circuits with adjustable threshold and instantaneous trip time	Manual setting: $I_3 = 1, 1.5, 2, 2.5, 3, 3.5, 4.5, 5.5, 6.5, 7, 7.5, 8, 8.5, 9, 10 \times I_n$ Tolerance: $\pm 20\% I > 4I_n$ $\pm 10\% I \leq 4I_n$	$\leq 20\text{ms}$	Yes	$t = k$

⁽¹⁾ Tolerances in case of:
– self-powered trip unit at full power;
– 2 or 3 phase power supply.
In conditions other than those considered, the trip time is $\leq 60\text{ms}$.


Circuit-breakers for power distribution

Electronic trip units

Ekip LS/I

Main characteristics:

- available for XT2 and XT4 in the three-pole and four-pole versions;
- protections:
 - against overload (L): $0.4...1 \times I_n$ adjustable protection threshold, with adjustable time trip curve;
 - against short-circuit with delay (S): $1...10 \times I_n$ adjustable protection threshold, with adjustable time trip curve (as an alternative to I protection);
 - against instantaneous short-circuit (I): $1...10 \times I_n$ adjustable protection threshold, with instantaneous trip curve (as an alternative to S protection);
 - of the neutral in four-pole circuit-breakers:
 - for $I_n \geq 100A$ can be selected in the OFF or ON positions, 50%, 100% of the phases;
 - for $I_n < 100A$, neutral protection is fixed at 100% of the phases and disabled by user;
- manual setting using the relative dip-switches on the front of the trip unit, which allow the settings to be made even when the trip unit is off;
- LED:
 - LED with steady green light indicating that the trip unit is supplied correctly. The LED comes on when the current exceeds $0.2 \times I_n$;
 - red LED for each protection:
 - L: LED with steady red light, indicates pre-alarm for current exceeding $0.9 \times I_n$;
 - S: LED with flashing red light, indicates alarm for current exceeding set threshold;
 - LS/I: LED with steady red light, shows that the protection has tripped. After the circuit-breaker has opened, connect the Ekip TT or Ekip T&P accessory to find out which protection function tripped the trip unit;
 - Ekip LS/I is equipped with a trip coil disconnection detection device that detects whether the opening solenoid has disconnected. Signalling is made by all the red LEDs flashing simultaneously;
- test connector on the front of the release:
 - to connect the Ekip TT trip test unit, which allows trip test, LED test and signalling about latest trip happened;
 - to connect the Ekip T&P unit, which allows the measurements to be read, the trip test to be conducted and the protection functions test to be carried out;
- thermal memory which can be activated by Ekip T&P;
- self-supply from $0.2 \times I_n$ minimum current up.



Ekip LS/I

Protection function	Trip threshold	Trip curve ⁽¹⁾	Excludability	Relation	Thermal memory
 Against overloads with long inverse time delay trip according to IEC 60947-2 Standard	Manual setting: $I_1 = 0.4...1 \times I_n$ step 0.04 Tolerance: trip between $1.05...1.3 \times I_n$ (IEC 60947-2)	Manual setting: $t_1 = 12-36s$ at $I = 3 \times I_n$ Tolerance: $\pm 10\%$ up to $4 \times I_n$ $\pm 20\%$ from $4 \times I_n$	–	$t = k/I^2$	Yes
 Against short-circuits with independent time delay ($t=k$)	Manual setting: $I_2 = 1-1.5-2-2.5-3-3.5-4.5-5.5-6.5-7-7.5-8-8.5-9-10 \times I_n$ Tolerance: $\pm 10\%$	$t_2 = 0.1-0.2s$ Tolerance: $\pm 15\%$	Yes	$t = k$	–
 Against short-circuits with adjustable threshold and instantaneous trip time	Manual setting: $I_3 = 1-1.5-2-2.5-3-3.5-4.5-5.5-6.5-7-7.5-8-8.5-9-10 \times I_n$ Tolerance: $\pm 10\%$	$\leq 20ms$	Yes	$t = k$	–

⁽¹⁾ Tolerances in case of:
– self-powered trip unit at full power;
– 2 or 3 phase power supply.
In conditions other than those considered, the following tolerance hold:

Protection	Trip threshold	Trip time
L	release between 1.05 and $1.3 \times I_n$	$\pm 20\%$
S	$\pm 10\%$	$\pm 20\%$
I	$\pm 15\%$	$\leq 60ms$


Ekip LSI and Ekip LSIG

Main characteristics:

- available for XT2 and XT4 in three-pole and four-pole versions;
- protections:
 - against overloads (L): $0.4...1 \times I_n$ adjustable protection threshold, with adjustable time trip curve;
 - against short-circuits with delay (S): $1...10 \times I_n$ adjustable protection threshold, with adjustable time trip curve (short inverse time ($t=k^2$) or independent time ($t=k$));
 - against instantaneous short-circuits (I): $1...10 \times I_n$ adjustable protection threshold, with instantaneous trip curve;
 - against earth faults (G): $0.2...1 \times I_n$ adjustable protection threshold, with independent time trip curve;
 - of the neutral in four-pole circuit-breakers:
 - for $I_n \geq 100A$ can be selected in OFF or ON, 50%, 100% of phases;
 - for $I_n < 100A$ neutral protection is fixed on 100% of phases and disabled by user;
- setting:
 - manual setting using the relative dip-switches on the front of the trip unit, which allow the settings to be made even when the trip unit is off;
 - electronic setting, made both locally using the Ekip T&P or Ekip Display accessory and via remote control, by means of the Ekip Com unit;
- LED:
 - LED on with steady green light indicating that the trip unit is supplied correctly. The LED comes on when the current exceeds $0.2 \times I_n$;
 - red LED for each protection:
 - L: LED with steady red light, indicates pre-alarm for current exceeding $0.9 \times I_n$;
 - L: LED with flashing red light, indicates alarm for current exceeding setted threshold;
 - LSIG: LED with steady red light, shows that the protection has tripped. After the circuit-breaker has opened, connect the Ekip TT or Ekip T&P accessory to find out which protection function tripped the trip unit;
 - the trip unit is equipped with a device that detects the eventual opening solenoid disconnection thanks to the simultaneous blinking of all the LED;
- test connector on the front of the release:
 - to connect the Ekip TT trip test unit, which allows trip test, LED test and signalling about the latest trip happened;
 - to connect the Ekip T&P unit, which allows the measurements to be read, the trip test to be conducted, the protection functions test to be carried out, electronic setting of the protection functions of the trip unit and of the communication parameters;
- thermal memory which can be activated by Ekip T&P or Ekip Display;
- self-supply from a minimum current of $0.2 \times I_n$ up;
- the three-pole version can be accessorized with external neutral;
- with the addition of the Ekip Com in the circuit-breaker, you can:
 - acquire and transmit a wide range of information via remote control;
 - accomplish the circuit-breaker opening and closing commands by means of the motor operator in the electronic version (MOE-E);
 - know the state of the circuit-breaker (open/closed/trip) via remote control;
 - setting the configuration and programming the unit, such as the current thresholds and the protection function curves.

Circuit-breakers for power distribution

Electronic trip units



Ekip LSI – Ekip LSIG

Protection function	Trip threshold	Trip curve ⁽¹⁾	Excludability	Relation	Thermal memory
L Against overloads with long inverse time delay trip according to IEC 60947-2 Standard	Manual setting: $I_1 = 0.4 \dots 1 \times I_n$ step 0.02 Tolerance: trip between $1.05 \dots 1.3 I_1$ (IEC 60947-2)	Manual setting: $t_1 = 3-12-36-60s$ at $I = 3 \times I_1$ Tolerance: $\pm 10\%$ up to $4 \times I_n$ $\pm 20\%$ from $4 \times I_n$	–	$t = k/I^2$	Yes
	Electronic setting: $I_1 = 0.4 \dots 1 \times I_n$ step 0.01 Tolerance: trip between $1.05 \dots 1.3 I_1$ (IEC 60947-2)	Electronic setting: $t_1 = 3 \dots 60s$ at $I = 3 \times I_1$ step 0.5 Tolerance: $\pm 10\%$ up to $4 \times I_n$ $\pm 20\%$ from $4 \times I_n$	–	$t = k/I^2$	Yes
S Against short-circuits with inverse short ($t=k/I^2$) or independent ($t=k$) time delay trip	Manual setting: $I_2 = 1-1.5-2-2.5-3-3.5-4.5-5.5-6.5-7-7.5-8-8.5-9-10 \times I_n$ Tolerance: $\pm 10\%$	Manual setting: $t_2 = 0.05-0.10-0.20-0.40s$ at $10 \times I_n$ Tolerance: $\pm 10\%$ up to $4 \times I_n$ $\pm 20\%$ from $4 \times I_n$	Yes	$t = k/I^2$	–
	Electronic setting: $I_2 = 1 \dots 10 \times I_n$ step 0.1 Tolerance: $\pm 10\%$	Electronic setting: $t_2 = 0.05 \dots 0.40s$ at $10 \times I_n$ step 0.01 Tolerance: $\pm 10\%$ up to $4 \times I_n$ $\pm 20\%$ from $4 \times I_n$	Yes	$t = k/I^2$	–
	Manual setting: $I_2 = 1-1.5-2-2.5-3-3.5-4.5-5.5-6.5-7-7.5-8-8.5-9-10 \times I_n$ Tolerance: $\pm 10\%$	Manual setting: $t_2 = 0.05-0.1-0.2-0.4s$ Tolerance: $\pm 15\%$ $t_2 > 100ms$ $\pm 20\%$ $t_2 \leq 100ms$	Yes	$t = k$	–
	Electronic setting: $I_2 = 1 \dots 10 \times I_n$ step 0.1 Tolerance: $\pm 10\%$	Electronic setting: $t_2 = 0.05 \dots 0.4s$ step 0.01 Tolerance: $\pm 15\%$ $t_2 > 100ms$ $\pm 20\%$ $t_2 \leq 100ms$	Yes	$t = k$	–
I Against short-circuits with adjustable threshold and instantaneous trip time	Manual setting: $I_3 = 1-1.5-2-2.5-3-3.5-4.5-5.5-6.5-7-7.5-8-8.5-9-10 \times I_n$ Tolerance: $\pm 10\%$	$\leq 40ms$	Yes	$t = k$	–
	Electronic setting: $I_3 = 1 \dots 10 \times I_n$ step 0.1 Tolerance: $\pm 10\%$	$\leq 40ms$	Yes	$t = k$	–
G Against earth fault with independent time delay trip ⁽²⁾	Manual setting: $I_4 = 0.2-0.25-0.45-0.55-0.75-0.8-1 \times I_n$ Tolerance: $\pm 10\%$	Manual setting: $t_4 = 0.1-0.2-0.4-0.8s$ Tolerance: $\pm 15\%$	Yes	$t = k$	–
	Electronic setting: $I_4 = 0.2 \dots 1 \times I_n$ step 0.02 Tolerance: $\pm 10\%$	Electronic setting: $t_4 = 0.1 \dots 0.8s$ step 0.05 Tolerance: $\pm 15\%$	Yes	$t = k$	–

⁽¹⁾ Tolerances in case of:
– self-powered trip unit at full power;
– 2 or 3 phase power supply.
In conditions other than those considered, the following tolerance hold:

Protection	Trip threshold	Trip time
L	release between 1.05 and $1.3 \times I_1$	$\pm 20\%$
S	$\pm 10\%$	$\pm 20\%$
I	$\pm 15\%$	$\leq 60ms$
G ⁽³⁾	$I_{set} > 15A \pm 15\%$, $I_{set} \leq 15A$ up to 50%	$I_{set} > 15A \pm 20\%$, $I_{set} \leq 15A$ up to 40%

⁽²⁾ Protection G is inhibited for currents higher than 2 In.

⁽³⁾ Ask ABB for further clarifications

Ekip E-LSIG

Main characteristics:

- available for XT4 in three-pole and four-pole versions;
- protections:
 - against overloads (L): 0.4...1xIn adjustable protection threshold, with adjustable time trip curve;
 - against short-circuits with delay (S): 1...10xIn adjustable protection threshold, with adjustable time trip curve;
 - against instantaneous short-circuits (I): 1...10xIn adjustable protection threshold, with instantaneous trip curve;
 - of the neutral in four-pole circuit-breakers;
- measurements:
 - available from 0.2xIn in Vaux mode and starting from 0.5xIn in self supply mode; external current or voltage transformers are not required. See table for ranges and accuracy;
 - Currents: three phases (L_1 , L_2 , L_3), neutral (Ne) and earth fault;
 - Voltage: phase-phase, phase-neutral;
 - Power: active, reactive and apparent;
 - Power factor;
 - Frequency and peak factor;
 - Energy: active, reactive, apparent, counter;
- setting:
 - manual setting using the relative dip-switches on the front of the trip unit, which allow the settings to be made even when the trip unit is off;
 - electronic setting, made both locally using Ekip T&P or Ekip Display accessory and via remote control, by means of the dialogue unit Ekip Com. The electronic setting have a wider range and a thicker regulation step.

Use of electronic setting allows other functions to be activated:


 - function for protection against earth faults (G): 0.2...1xIn adjustable protection threshold, with a time constant trip curve;
 - over voltage protection 0.5...0.95 Un with a time constant trip curve;
 - under voltage protection 1.05...1.2 Un with a time constant trip curve;
- LED:
 - LED on with steady green light indicating that the trip unit is supplied correctly. The LED comes on when the current exceeds 0.2xIn;
 - red LED for each protection:
 - L: LED with steady red light, indicates pre-alarm for current exceeding 0.9xI_n;
 - L: LED with flashing red light, indicates alarm for current exceeding setted threshold;
 - fixed LED MAN/ELT show the kind of active parameters;
 - LSIG: LED with steady red light, shows that the protection has tripped. After the circuit-breaker has opened, connect the Ekip TT or Ekip T&P accessory to find out which protection function tripped the trip unit;
 - the trip unit is equipped with a device that detects the eventual opening solenoid disconnection thanks to the simultaneous blinking of all the LED;
- test connector on the front of the release:
 - to connect the Ekip TT trip test unit, which allows trip test, LED test and signalling about the latest trip happened;
 - to connect the Ekip T&P unit, which allows the measurements to be read, the trip test to be conducted, the protection functions test to be carried out, electronic setting of the protection functions of the trip unit and of the communication parameters;
- self-supply from a minimum current of 0.2xIn up; measurements starting from 0.5xIn;
- the three-pole version can be accessorized with external neutral current transformer and external neutral voltage connection kit;
- with the addition of the Ekip Com in the circuit-breaker, you can:
 - acquire and transmit a wide range of information via remote control;
 - accomplish the circuit-breaker opening and closing commands by means of the motor operator in the electronic version (MOE-E);
 - know the state of the circuit-breaker (open/closed/trip) via remote control;
 - setting the configuration and programming the unit, such as the current thresholds and the protection function curves.

Circuit-breakers for power distribution

Electronic trip units

L, S, I protection LED

LED for Electronic/Manual setting



Ekip E-LSIG

Protection function	Trip threshold	Trip curve ⁽¹⁾	Excludability	Relation
L Against overloads with long inverse time delay trip according to IEC 60947-2	Manual setting: $I_1 = 0.4...1 \times I_n$ step 0.04 Tolerance: trip between 1.05...1.3 I_1 (IEC 60947-2)	Manual setting: $t_1 = 12-36s$ at $I = 3 \times I_1$ Tolerance: $\pm 10\%$ up to $4 \times I_n$ $\pm 20\%$ from $4 \times I_n$	–	$t = k/I^2$
	Electronic setting: $I_1 = 0.4...1 \times I_n$ step 0.01 Tolerance: trip between 1.05...1.3 I_1 (IEC 60947-2)	Electronic setting: $t_1 = 3...60s$ at $I = 3 \times I_1$ step 0.5 Tolerance: $\pm 10\%$ up to $4 \times I_n$ $\pm 20\%$ from $4 \times I_n$	–	$t = k/I^2$
S Against short-circuits with inverse short ($t=k/I^2$) or independent ($t=k$) time delay trip	Manual setting: $I_2 = \text{OFF } 3-6-9$ Tolerance: $\pm 10\%$	Manual setting: $t_2 = 0.10-0.20s$ at $10 \times I_n$ Tolerance: $\pm 10\%$ up to $4 \times I_n$ $\pm 20\%$ from $4 \times I_n$	Yes	$t = k$
	Electronic setting: $I_2 = 1...10 \times I_n$ step 0.1 Tolerance: $\pm 10\%$	Electronic setting: $t_2 = 0.05...0.4s$ at $10 \times I_n$ step 0.01 Tolerance: $\pm 10\%$ up to $4 \times I_n$ $\pm 20\%$ from $4 \times I_n$	Yes	$t = k$
	Electronic setting: $I_2 = 1...10 \times I_n$ step 0.1 Tolerance: $\pm 10\%$	Electronic setting: $t_2 = 0.05...0.4s$ step 0.01 Tolerance: $\pm 10\%$ up to $4 \times I_n$ $\pm 20\%$ from $4 \times I_n$	Yes	$t = k/I^2$
I Against short-circuits with adjustable threshold and instantaneous trip time	Manual setting: $I_3 = \text{OFF } 1-3-4-7-9-10$ Tolerance: $\pm 10\%$	$\leq 40ms$	Yes	$t = k$
	Electronic setting: $I_3 = 1...10 \times I_n$ step 0.1 Tolerance: $\pm 10\%$	$\leq 40ms$	Yes	$t = k$
G Against earth fault with independent time delay trip ⁽²⁾	Electronic setting: $I_4 = 0.2...1 \times I_n$ step 0.02 Tolerance: $\pm 10\%$	Electronic setting: $t_4 = 0.1...0.8s$ step 0.05s Tolerance: $\pm 15\%$	Yes	$t = k$
UV Standard adjustable constant time	Electronic setting: $U_8 = 0.5...0.95 \times U_n$ step $= 0.01 \times U_n$ Tolerance: $\pm 5\%$	Electronic setting: $t_8 = 0.1...5s$ step 0.1s Tolerance: min ($\pm 20\% \pm 100ms$)	Yes	$t = k$
OV Against overvoltage with adjustable constant time	Electronic setting: $U_9 = 1.05...1.2 \times U_n$ step $= 0.01 \times U_n$ Tolerance: $\pm 5\%$	Electronic setting: $t_9 = 0.1...5s$ step 0.1s Tolerance: min ($\pm 20\% \pm 100ms$)	Yes	$t = k$

⁽¹⁾ Tolerances in case of:
– self-powered trip unit at full power;
– 2 or 3 phase power supply.
In conditions other than those considered, the following tolerance hold:

Protection	Trip threshold	Trip time
L	release between 1.05 and 1.3 x I	$\pm 20\%$
S	$\pm 10\%$	$\pm 20\%$
I	$\pm 15\%$	$\leq 60ms$
G ⁽³⁾	$I_{RMS} > 15A \pm 15\%$, $I_{RMS} \leq 15A$ up to 50%	$I_{RMS} > 15A \pm 20\%$, $I_{RMS} \leq 15A$ up to 40%

⁽²⁾ Protection G is inhibited for currents higher than 2 In.

⁽³⁾ Ask ABB for further clarifications

		Value	Range	Accuracy	Specified measuring range
Current		Phase current (I1, I2, I3, IN)	0 ... 12 In	Cl 1	0.2 ... 1.2 In
		Phase current minimum value			
		Phase current maximum value			
		Ground current (Ig)	0 ... 4 In	–	–
Voltage		Phase voltage runtime, max and min (V1N, V2N, V3N) ⁽¹⁾	5 V ... 480 V	±0.5%	30 V ... 400 V
		Line voltage runtime, max and min (U12, U23, U31)	10 V ... 828 V	±0.5%	50 V ... 690 V
Power	Active	Phase power runtime, max and min (P1, P2, P3) ⁽¹⁾	-1440 kW ... 1440 kW	Cl 2	-120 kW ... -1500 W 1500 W ... 120 kW ⁽³⁾
		Total power runtime, max and min	-4320 kW ... 4320 kW	Cl2	-360 kW ... -4500 W 4500 W ... 360 kW ⁽³⁾
	Reactive	Phase power runtime, max and min (Q1, Q2, Q3) ⁽¹⁾	-1440 kVar ... 1440 kVar	Cl 2	-120 kVar ... -1500 Var 1500 Var ... 120 kVar ⁽³⁾
		Total power runtime, max and min	-4320 kVar ... 4320 kVar	Cl 2	-360 kVar ... -4500 Var 4500 Var ... 360 kVar ⁽³⁾
	Apparent	Phase power runtime, max and min (S1, S2, S3) ⁽¹⁾	In VA ... 1440 kVA	Cl 2	1500 VA ... 120 kVA
		Total power runtime, max and min	750 VA ... 4320 kVA	Cl 2	4500 VA ... 369 kVA
Energy	Active	Total energy	1 kWh ... 214,75 GWh	Cl 2	1 kWh ... 214,75 GWh
		Incoming energy			
		Outgoing energy			
	Reactive	Total energy	1 kvarh ... 214,75 GVarh	Cl 2	1 kvarh ... 214,75 GVarh
		Incoming energy			
		Outgoing energy			
	Apparent	Total energy	1 kVAh ... 214,75 GVAh	Cl 2	1 kVAh ... 214,75 GVAh
Power quality		Harmonic analysis ⁽²⁾	11th (50 - 60Hz)	–	–
		THD of phase L1, L2, L3 ⁽²⁾	0 ... 1000%	±10%	0 ... 500%
		Frequency runtime, max, min	44 ... 440Hz	±0.5%	45 ... 66 Hz
		PF of phase L1, L2, L3 ⁽¹⁾	-1 ... 1	±2%	-1 ... -0.5 0.5 ... 1

⁽¹⁾ Not available if Neutral is not connected

⁽²⁾ Available on demand by sending a Modbus command

⁽³⁾ $0,2In < I_i < 1,2In$ and $30V < V_i < 400V$

Circuit-breakers for power distribution

Electronic trip units

Current	Ekip Display	HMI030	Modbus
Phase current (I1, I2, I3, IN)	■	■	■
Ground current (Ig)			■
Voltage			
Phase voltage (V1N, V2N, V3N)		■	■
Phase-phase Voltage (U12, U23, U31)	■	■	■
Active Power			
Phase active power (P1, P2, P3)		■	■
Total active power	■	■	■
Reactive Power			
Phase power (Q1, Q2, Q3)		■	■
Total reactive power	■	■	■
Apparent Power			
Phase power (S1, S2, S3)		■	■
Total apparent power	■	■	■
Active Energy			
Total energy	■	■	■
Incoming energy			■
Outgoing energy			■
Reactive energy			
Total energy	■	■	■
Incoming energy			■
Outgoing energy			■
Apparent Energy			
Total apparent energy	■	■	■
THD (I)			
THD della fase I1			■
THD della fase I2			■
THD della fase I3			■
THD della fase Ne			■
Harmonics			
Harmonics phase L1			■
Harmonics phase L2			■
Harmonics phase L3			■
Harmonics phase Ne			■
Frequency			
Frequency	■	■	■
Power factor			
PF phase I1			■
PF phase I2			■
PF phase I3			■
Total Power Factor	■	v	■

Circuit-breakers for motors protection

Main characteristics

The safety and reliability of the solution are important aspects that must be considered when choosing and manufacturing the system for starting^(G4.3 and G4.4) and monitoring motors.


Start-up is a particularly critical phase for the motor itself and for the installation powering it. Even rated service needs to be adequately monitored and protected so as to deal with any faults that might occur.

When it comes to direct starting, ABB SACE proposes two different solutions:


- **a conventional system** with three poles a circuit-breaker equipped with a magnetic only trip unit for protection against short-circuits, a thermal relay for protection against overloads and phase failure or imbalance, and a contactor to operate the motor;
- **an advanced protection system** which integrates all the protection and monitoring functions, and a contactor for operating the motor, in the circuit-breaker itself.

Several different factors must be considered when choosing and coordinating the protection and operating devices, e.g.:

- the electrical specifications of the motor (type, power rating, efficiency, $\cos\phi$);
- the starting type and diagram;
- the fault current and voltage in the part of the network where the motor is installed.



Conventional system



Advanced protection system

Consult the QT7 Technical Application Paper: "The asynchronous three-phase motor: general information and ABB's offer for coordinating the protections" for further details.

The motor protection and operating devices must be chosen in accordance with the coordination tables provided by ABB either through documentation "Coordination tables" or on the web site: http://www.abbcontrol.fr/coordination_tables/.

Circuit-breakers for motors protection

Main characteristics

Characteristics of circuit-breakers for protecting motors

			XT1	XT2					XT3	XT4					
Size ^(G2.1)	[A]		160	160					250	160/250					
Poles	[Nr.]		3	3					3	3					
Rated service voltage, Ue ^(G2.4)	(AC) 50-60Hz	[V]	690	690					690	690					
	(DC)	[V]	500	500					500	500					
Rated insulation voltage, Ui ^(G2.5)	[V]		1000	1000					800	1000					
Rated impulse withstand voltage, Uimp ^(G2.6)	[kV]		8	8					8	8					
Versions			Fixed, Plug in	Fixed, Withdrawable, Plug-in					Fixed, Plug-in	Fixed, Withdrawable, Plug-in					
Breaking capacities			N ⁽¹⁾	N	S	H	L	V	N	S	N	S	H	L	V
Trip Units			Magnetic	Magnetic, Electronic					Magnetic	Magnetic, Electronic					
MF/MA			■	■					■	■					
Ekip M-I				■											
				In = 20A, 32A, 52A, 100A											
Ekip M-LIU				▲						▲					
				In = 25A, 63A, 160A						In = 40A, 63A, 100A, 160A					
Ekip M-LRIU				▲						▲					
				In = 25A, 63A, 100A						In = 40A, 63A, 100A, 160A, 200A					
Interchangeability				■						■					

(1) Icu@415V = 5kA In<16A

■ Complete circuit-breaker

▲ Loose trip unit

Circuit-breakers for motors protection

Magnetic trip units

MF/MA

Main characteristics:

- available for XT1, XT2, XT3 and XT4 in the three-pole version only, these trip units are mainly used for protecting motors, in conjunction with a thermal relay and a contactor;
- protections:
 - against instantaneous short-circuit (I) for XT1: for $I_n \leq 6.3A$ the protection threshold I is adjustable from $4 \dots 11 I_n$; whereas for $I_n > 6.3A$ the protection threshold I is adjustable from $3 \dots 11 I_n$;
 - against instantaneous short-circuit (I) for XT2: for $I_n \leq 12.5A$ the protection threshold I is fixed at $14 I_n$, whereas for $I_n > 12.5A$ the protection threshold I is adjustable from $6 \dots 14 I_n$;
 - against instantaneous short-circuit (I) for XT3: the protection threshold I is adjustable from $6 \dots 12 I_n$;
 - against instantaneous short-circuit (I) for XT4: the protection threshold I is adjustable from $5 \dots 10 I_n$;
- the magnetic protection setting is made by turning the relative cursor on the front of the release.

Rotary switch for magnetic protection setting

	I3		MA
	MIN	1500A	
	MED	2250A	
	MAX	3000A	

XT1

MA

	I_n [A]	3.2	6.3	16	32	52	63	80	100	125
$I_3 = 4 \dots 11 I_n$ [A] $I_3 = 3 \dots 11 I_n$ [A]	$I_3 = MA$	13...35	25...69	48...176	96...352	189...572	189...693	240...880	300...1100	375...1375

XT2

MF/MA

	I_n [A]	1 ⁽¹⁾	2 ⁽¹⁾	4 ⁽¹⁾	8.5 ⁽¹⁾	12.5 ⁽¹⁾	20	32	52	80	100	160
$I_3 = 14 I_n$ [A] $I_3 = 6 \dots 14 I_n$ [A]	$I_3 = MF$	14	28	56	120	175						
	$I_3 = MA$						120...280	192...448	314...728	480...1120	600...1400	960...2240

⁽¹⁾ Available only as complete circuit-breaker

XT3

MA

	I_n [A]	100	125	160	200
I_3 [A]		600...1200	750...1500	960...1920	1200...2400
$I_3 = 6 \dots 12 I_n$					

XT4

MA

	I_n [A]	10 ⁽¹⁾	12.5 ⁽¹⁾	20	32	52	80	100	125	160	200
I_3 [A]		50...100	62.5...125	100...200	160...320	260...520	400...800	500...1000	625...1250	800...1600	1000...2000
$I_3 = 5 \dots 10 I_n$											

⁽¹⁾ Available only as complete circuit-breaker

Circuit-breakers for motors protection

Electronic trip units

Ekip M-I

Main characteristics:

- only available for XT2 in three-pole version. It is normally used in combination with a thermal relay and a contactor for motor protection;
- protections:
 - against instantaneous short-circuit (I): protection threshold adjustable from 6...14xI_n, with instantaneous trip curve;
- manual setting by means of the special dip-switches positioned on the front of the trip unit, which allow its adjustment even with the trip unit off;
- LED:
 - fixed green LED which indicates correct operation of the trip unit; the LED lights up for a current over 0.2xI_n;
- Test connector positioned on the front of the trip unit:
 - for connection of the Ekip TT test unit, which allows the trip test and the LED test;
 - for connection of the Ekip T&P unit, which allows the measurements to be read, to carry out the trip test and to carry out the protection function test;
 - self-supply starting from a minimum current of 0.2 x I_n.



Ekip M-I

Protection function	Trip threshold	Trip curve ⁽¹⁾	Excludability	Relation	Thermal memory
 Against short-circuits with adjustable threshold and instantaneous trip time	Manual setting: $I_3 = 6-6,5-7-7,5-8-8,5-9-9,5-10,5-11-11,5-12-12,5-13-13,5-14 \times I_n$ Tolerance: $\pm 10\%$	$\leq 15\text{ms}$	–	$t = k$	–

⁽¹⁾ Tolerances in case of:
– self-powered trip unit at full power;
– 2 or 3 phase power supply.
In conditions other than those considered, the following tolerance hold:

Protection	Trip threshold	Trip time
I	$\pm 15\%$	$\leq 60\text{ms}$

Ekip M-LIU


Main characteristics:

- available for XT2 and XT4 in the three-pole version, this device protects motors. The L protection function protects the motor against overloads, in accordance with the indications and classes defined by standard IEC 60947-4-1;
- protections:
 - against overloads (L): $0.4...1xI_n$ adjustable threshold. The operating time is established by choosing the operating class defined by Standard IEC 60947-4-1: Class 3E, 5E, 10E, 20E;
 - against short-circuits (I): $6...13xI_n$ adjustable threshold with instantaneous operating time;
 - against phase loss (U): the protection can be selected either in the ON or OFF position. With selector in ON position, circuit breaker trips if at least one current phase is lower than $0.1xI_n$ and at least a second one higher than $0.5xI_1$;
- manual setting using the relative dip-switches on the front of the release;
- LED:
 - LED on with steady green light indicating that the trip unit is supplied correctly. The LED comes on when the current exceeds $0.2xI_n$;
 - red LED for each protection:
 - L: LED with steady red light, indicates pre-alarm for current exceeding $0.9xI_n$;
 - L: LED with flashing red light, indicates alarm for current exceeding setted threshold;
 - LIU: LED with steady red light, shows that the protection has tripped. After the circuit-breaker has opened, connect the Ekip TT or Ekip T&P accessory to find out which protection function tripped the trip unit;
 - release Ekip M-LIU is equipped with a trip coil disconnection detection device that detects whether the opening solenoid has disconnected. Signalling is made by all the red LEDs flashing simultaneously;
- test connector on the front of the release:
 - to connect the Ekip TT trip test unit, which allows trip test, LED test and signalling about the latest trip happened;
 - to connect the Ekip T&P unit, which allows the measurements to be read, the trip test to be conducted and the protection function test to be carried out;
- thermal memory always active;
- self-supply starting from a minimum current of $0.2xI_n$.

L, I, U protection LED

Dip switch for L protection function setting

Dip switch for the trip classes setting according to IEC 60947-4-1



Power-on LED

Slot for lead seal

Test connector

Dip switch for I protection function setting

U protection function ON-OFF

Ekip M-LIU

Protection function	Trip threshold	Trip curve ⁽¹⁾	Excludability	Relation	Thermal memory
 Against overloads with long inverse time delay according to IEC 60947-4-1 Standard	Manual setting: $I_1 = 0.4...1xI_n$ step 0.04 Tolerance: trip between $1.05...1.2xI_1$	Manual setting: Operating class: 3E, 5E, 10E, 20E Tolerance: $\pm 10\%$ up to $4xI_n$ $\pm 20\%$ from $4xI_n$	–	$t = k/I^2$	Yes
 Against short-circuits with adjustable threshold and instantaneous trip time	Manual setting: $I_3 = 6...13xI_n$ step 1 Tolerance: $\pm 10\%$	$\leq 20ms$	–	$t = k$	–
 Against phase loss with independent time delay (IEC 60947-4-1)	Manual setting: ON / OFF	Manual setting: When ON, $t_e = 2s$ Tolerance: $\pm 10\%$	Yes	$t = k$	–

⁽¹⁾ Tolerances in case of:
– self-powered trip unit at full power;
– 2 or 3 phase power supply.
In conditions other than those considered, the following tolerance hold:

Protection	Trip threshold	Trip time
L	release between 1.05 and $1.2 \times I_1$	$\pm 20\%$
I	$\pm 15\%$	$\leq 60ms$
U	$\pm 20\%$	$\pm 20\%$

Circuit-breakers for motors protection


Electronic trip units

Ekip M-LRIU

Main characteristics:

- available for XT2 and XT4 in the three-pole version, this device is generally used for protecting integrated motors;
- protections:
 - against overloads (L): $0.4...1 \times I_n$ adjustable threshold. The operating time is established by choosing the operating class defined by standard IEC 60947-4-1;
 - rotor locking (R): with adjustable threshold in the OFF position or from $3...9 \times I_n$, with settable operating time;
 - against instantaneous short-circuits (I): with adjustable threshold from $6...13 \times I_n$ and instantaneous operating time;
 - against phase loss (U): With selector in ON position, circuit breaker trips if at least one current phase is lower than $0.1 \times I_n$ and at least a second one higher than $0.25 \times I_n$;
- setting:
 - manual setting using the relative dip-switches on the front of the trip unit, which allow the settings to be made even when the trip unit is off;
 - electronic setting, made both locally using Ekip T&P or Ekip Display accessory and via remote control, by means of the dialogue unit Ekip Com. Use of electronic setting allows other functions to be activated:
 - function for protection against earth faults (G): $0.2...1 \times I_n$ adjustable protection threshold, with a time constant trip curve;
 - duty mode setting (Normal/Heavy):
 - the Normal duty mode requires use of a circuit-breaker and a contactor. In the case of tripping, the Ekip M-LRIU release commands the opening of the contactor via PR212/CI;
 - the Heavy duty mode foresees circuit-breaker opening for all overcurrent conditions, and just the function of motor operation is entrusted to the contactor;
 - BACK UP function:
 - this protection is designed to handle the situation whereby, in the Normal duty mode, the opening command transmitted to the contactor via PR212/CI has not been implemented, i.e. the contactor has not tripped. If this happens, the Ekip M-LRIU release transmits a trip command directly to the circuit-breaker after having waited a time defined. A waiting time between the command transmitted to the contactor and the back-up command transmitted to the circuit-breaker is required so as to take the contactor opening time into account;
 - PTC protection setting:
 - PTC: this protection, monitors the temperature inside the protected motor by means of a PTC sensor. If the temperature is too high, the Ekip M-LRIU release will command contactor opening (if the mode is "Normal") or circuit-breaker opening (if the mode is "Heavy"). To realize this protection is necessary to order the connector available for PTC;
- LED:
 - LED on with steady green light indicating that the trip unit is supplied correctly. The LED comes on when the current exceeds $0.2 \times I_n$;
 - red LED for each protection:
 - L: LED with steady red light, indicates pre-alarm for current exceeding $0.9 \times I_n$;
 - L: LED with flashing red light, indicates alarm for current exceeding settled threshold;
 - fixed LED ELT show the kind of active parameters;
 - LRIU: LED with steady red light, shows that the protection has tripped. After the circuit-breaker has opened, connect the Ekip TT or Ekip T&P accessory to find out which protection function tripped the trip unit;
 - Ekip M-LRIU is equipped with a trip coil disconnection detection device that detects whether the opening solenoid has disconnected. Signalling is made by all the LEDs flashing simultaneously;
- test connector on the front of the release:
 - to connect the Ekip TT trip test unit, which allows trip test, LED test and signalling about the latest trip happened;
 - to connect the Ekip T&P unit, which allows the measurements to be read, the trip test to be conducted, the protection function test to be carried out, and electronic setting of the protection function of the release and of the communication parameters;
- thermal memory always active;
- self-supply from a minimum current of $0.2 \times I_n$ up;

- with the addition of the Ekip Com in the circuit-breaker, you can:
 - acquire and transmit a wide range of information via remote control;
 - accomplish the circuit-breaker opening and closing commands by means of the motor operator in the electronic version (MOE-E);
 - know the state of the circuit-breaker (open/closed/trip) via remote control;
 - setting the configuration and programming parameters of the unit, such as the current thresholds and the protection function curves.



Ekip M-LRIU

Protection function	Trip threshold	Trip curve ⁽¹⁾	Excludability	Relation	Thermal memory
L Against overloads with long inverse time delay trip according to IEC 60947-4-1	Manual setting: $I_1 = 0.4...1xI_n$ step 0.04 Tolerance: trip between $1.05...1.2xI_1$ Electronic setting: $I_1 = 0.4...1xI_n$ step 0.01 Tolerance: trip between $1.05...1.2xI_1$	Manual setting: Trip class: 3E, 5E, 10E, 20E Tolerance: $\pm 10\%$ up to $4xI_n$ $\pm 20\%$ from $4xI_n$ Electronic setting: Trip class: 3E, 5E, 10E, 20E Tolerance: $\pm 10\%$ up to $4xI_n$ $\pm 20\%$ from $4xI_n$	–	$t = k/I^2$	Yes
R Against rotor block with delayed trip and with an independent time delay trip (IEC 60947-4-1)	Manual setting: $I_5 = \text{OFF}, 3, 6, 9xI_1$ Tolerance: $\pm 10\%$ Electronic setting: $I_5 = \text{OFF}, 3...9xI_1$ step $0.1I_1$ Tolerance: $\pm 10\%$	Manual setting: $t_5 = 1, 4s$ Tolerance: $\pm 10\%$ up to $4xI_n$ $\pm 20\%$ from $4xI_n$ Electronic setting: $t_5 = 1...4s$ step 0.5 Tolerance: $\pm 10\%$ up to $4xI_n$ $\pm 20\%$ from $4xI_n$	Yes	$t = k$	–
I Against short-circuits threshold with adjustable threshold and instantaneous trip time	Manual setting: $I_3 = 6-8-11-13xI_n$ Tolerance: $\pm 10\%$ Electronic setting: $I_3 = 1...13xI_n$ Tolerance: $\pm 10\%$	$\leq 40ms$ $\leq 40ms$	–	$t = k$	–
U Against phase current unbalanced or loss of phase with tripping at independent time (IEC 60947-4-1)	Manual setting: On / Off Electronic setting: On / Off	Manual setting: $t_6 = 2s$ Tolerance: $\pm 20\%$ Electronic setting: $t_6 = 1...10s$ step 0.5 Tolerance: $\pm 20\%$	Yes	$t = k$	–
G Against earth fault with independent time delay trip ⁽²⁾	Electronic setting: $I_4 = 0.2...1xI_n$ step $0.1I_n$ Tolerance: $\pm 10\%$	Electronic setting: $t_4 = 0.1...0.8s$ step 0.01 Tolerance: $\pm 15\%$	Yes	$t = k$	–

⁽¹⁾ Tolerances in case of:
 – self-powered trip unit at full power;
 – 2 or 3 phase power supply.
 In conditions other than those considered, the following tolerance hold:

Protection	Trip threshold	Trip time
L	release between 1.05 and $1.3 \times I_1$	$\pm 20\%$
S	$\pm 10\%$	$\pm 20\%$
I	$\pm 15\%$	$\leq 60ms$
G*	$I_{lim} > 15A \pm 15\%$, $I_{lim} \leq 15A$ up to 50%	$I_{lim} > 15A \pm 20\%$, $I_{lim} \leq 15A$ up to 40%

* ask ABB for further clarification

⁽²⁾ Protection G is inhibited for currents higher than 2 In.


Circuit-breakers for generator protection

Main characteristics

SACE Tmax XT circuit-breakers can be equipped with thermomagnetic trip units with a low magnetic threshold.

This type of release can be designed and made so as to provide a solution for protecting small generators and distribution networks with very long cables (slight end of line fault current owing to the high cable impedance).

Generator protection requires a low magnetic threshold, typically about three times circuit-breaker's rated current, so as to "cut" the short-circuit current in the "transient" zone of the decrement curve of the generator fault current. Consult the "Electrical installation handbook" ABB SACE guide vol. 2 for further details.



Characteristics of circuit-breakers for protecting generators

		XT2		XT3		XT4	
Size ^(G2.1)	[A]	160		250		160/250	
Poles	[Nr.]	3, 4		3, 4		3, 4	
Rated service voltage, U_e ^(G2.4)	(AC) 50-60Hz	[V]		690		690	
	(DC)	[V]		500		500	
Rated insulation voltage, U_i ^(G2.5)	[V]	1000		800		1000	
Rated impulse withstand voltage, U_{imp} ^(G2.6)	[kV]	8		8		8	
Versions		Fixed, Withdrawable, Plug-in		Fixed, Plug-in		Fixed, Withdrawable, Plug-in	
Breaking capacities		N	S	N	S	N	S
Trip units		Thermomagnetic, Electronic		Thermomagnetic		Electronic	
TMG		■		■		▲	
Ekip G-LS/I		▲				▲	
		In = 10A, 25A, 63A, 100A, 160A				In = 40A, 63A, 100A, 160A, 250A	
Interchangeability		■				■	

■ Complete circuit-breaker

▲ Loose trip unit

TMG

Main characteristics:

- available for XT2 and XT3 in the three-pole and four-pole versions;
- protections:
 - against overloads (L): adjustable 0.7...1xIn protection threshold, with inverse long-time trip curve;
 - against instantaneous short-circuits (I): fixed 3xIn protection threshold, with instantaneous trip curve;
 - 100% neutral protection in four-pole circuit-breakers;
- the thermal protection setting is made by turning the relative cursor on the front of the release.

Example with XT3 250A

Rotary switch for thermal protection setting

MAX - MIN		I1 (40°C)		I3	TMG
MED		MIN	175A	750A	
		MED	212.5A		
		MAX	250A		

XT2

TMG

	In [A]	16 ⁽¹⁾	20 ⁽¹⁾	25 ⁽¹⁾	32 ⁽¹⁾	40 ⁽¹⁾	50 ⁽¹⁾	63 ⁽¹⁾	80	100	125	160
	Neutral [A] - 100%	16	20	25	32	40	50	63	80	100	125	160
I ₁ = 0.7...1xIn												
	I ₃ [A]	160	160	160	160	200	200	200	240	300	375	480
	Neutral [A] - 100%	160	160	160	160	200	200	200	240	300	375	480
I ₃ = 3xIn												

⁽¹⁾ Available only as complete circuit-breaker

XT3

TMG

	In [A]	63	80	100	125	160	200	250
	Neutral [A] - 100%	63	80	100	125	160	200	250
I ₁ = 0.7...1xIn								
	I ₃ [A]	400	400	400	400	480	600	750
	Neutral [A] - 100%	400	400	400	400	480	600	750
I ₃ = 3xIn								

Circuit-breakers for generator protection

Main characteristics


Ekip G-LS/I

Main characteristics:

- available for XT2 and XT4 in the three-pole and four-pole versions. Allows the protection against overloads to be extensively adjusted;
- protections:
 - against overloads (L): $I_t=0.4...1xI_n$ adjustable protection threshold, with inverse long-time trip curve;
 - against delayed short-circuits (S): $1...10xI_n$ adjustable protection threshold, with adjustable trip curve (as an alternative to L protection);
 - against instantaneous short-circuits (I): $1...10xI_n$ adjustable protection threshold, with instantaneous operating time (as an alternative to S protection);
 - neutral, in four-pole circuit-breakers, can be set in the OFF, ON positions at 50% or 100% of the phases;
- manual setting using the relative dip-switches on the front of the trip unit, which allow the settings to be made even when the trip unit is off;
- LED:
 - LED on with steady green light indicating that the trip unit is supplied correctly. The LED comes on when the current exceeds $0.2xI_n$;
 - red LED for each protection:
 - L: LED with steady red light, indicates pre-alarm for current exceeding settled threshold;
 - L: LED with flashing red light, indicates alarm for current exceeding settled threshold;
 - LS/I: LED with steady red light, shows that the protection has tripped. After the circuit-breaker has opened, connect the Ekip TT or Ekip T&P accessory to find out which protection function tripped the trip unit;
 - Ekip G-LS/I is equipped with a trip coil disconnection detection device that detects whether the opening solenoid has disconnected. Signalling is made by all the LEDs flashing simultaneously;
- test connector on the front of the release:
 - to connect the Ekip TT trip test unit, which allows trip test, LED test and signalling about the latest trip happened;
 - for connecting the Ekip T&P unit which allows the measurements to be read and the trip test to be carried out;
- thermal memory which can be activated by Ekip T&P;
- self-supply from $0.2xI_n$ up.

L, S, I protection LED

Dip switch for the selection between S protection function or I protection function



Dip switch for LS/I protection function setting

Dip switch for the trip curve selection

Ekip G-LS/I

Protection function	Trip threshold	Trip curve ⁽¹⁾	Excludability	Relation	Thermal memory
L Against overloads with inverse long-time delayed tripping according to IEC 60947-2 standard	Manual setting: $I_1 = 0.4 \dots 1 \times I_n$ step 0.04 Tolerance: trip between $1.05 \dots 1.3 \times I_1$ (IEC 60947-2)	Manual setting: $t_1 = 3-6s$ at $I = 3 \times I_1$ Tolerance: $\pm 10\%$ up to $4 \times I_n$ $\pm 15\%$ from $4 \times I_n$	–	$t = k/I^2$	Yes
S Against short-circuit with independent time delay trip	Manual setting: $I_2 = 1-1.5-2-2.5-3-3.5-4.5-5.5-6.5-7-7.5-8-8.5-9-10 \times I_n$ Tolerance: $\pm 10\%$ up to $2 \times I_n$ $\pm 20\%$ from $2 \times I_n$	$t_2 = 0.05-0.075-0.1-0.2s$ Tolerance: $\pm 10\%$ $t_2 > 0.075$ $\pm 20\%$ $t_2 \leq 0.075$	Yes	$t = k$	–
I Against short-circuits with adjustable threshold and instantaneous trip time	Manual setting: $I_3 = 1-1.5-2-2.5-3-3.5-4.5-5.5-6.5-7-7.5-8-8.5-9-10 \times I_n$ Tolerance: $\pm 10\%$	$\leq 20ms$	Yes	$t = k$	–

⁽¹⁾ Tolerances in case of:
– self-powered trip unit at full power;
– 2 or 3 phase power supply.
In conditions other than those considered, the following tolerance hold:

Protection	Trip threshold	Trip time
L	release between 1.05 and $1.3 \times I_1$	$\pm 20\%$
S	$\pm 10\%$	$\pm 20\%$
I	$\pm 15\%$	$\leq 60ms$

Circuit-breakers for oversized neutral protection

Main characteristics

The SACE Tmax XT range of circuit-breakers with oversized neutral is used in certain applications where harmonics or unbalance loads or single phase create an overload on the neutral conductor. Under these conditions, a current of a considerable value could travel along the neutral conductor. In particular, third-order harmonics and relative multiples add together on the neutral and give rise to a current value that could be higher than the one which travels along the phase conductors.

For this reason, circuit-breakers with oversized neutral provide adequate protection in installations where the neutral conductor is sized with a larger section than the phase conductors.

The main types of equipment that generate harmonics are given below by way of example:

- personal computers;
- fluorescent lamps;
- static converters;
- no-break power units;
- variable speed drives;
- welding machines.

By and large, the wave shape is distorted owing to the presence of semiconductor devices able to conduct for a fraction of the entire cycle, creating discontinuous trends and consequently introducing numerous harmonics.

Consult the “Electrical installation handbook” ABB SACE guide vol. 2 for further details.

Characteristics of circuit-breakers for oversized neutral protection

		XT2					XT4				
Size ^(G2.1)	[A]	160					160/250				
Uninterrupted nominal current, In	[A]	10, 63, 100					40, 63, 100, 160				
Poles	[Nr.]	4					4				
Rated service voltage, Ue ^(G2.4)	(AC) 50-60Hz [V]	690					690				
Rated insulation voltage, Ui ^(G2.5)	[V]	1000					1000				
Rated impulse withstand voltage, Uimp ^(G2.6)	[kV]	8					8				
Versions		Fixed, Withdrawable, Plug-in					Fixed, Withdrawable, Plug-in				
Breaking capacity		N	S	H	L	V	N	S	H	L	V
Trip units		Electronic					Electronic				
Ekip N-LS/I		▲					▲				
Interchangeability		■					■				

■ Complete circuit-breaker

▲ Loose trip unit

Ekip N-LS/I

Main characteristics:

- available for XT2 and XT4 in the four-pole version;
- protections:
 - against overload (L): $I_1=0.4...1xI_n$ adjustable protection threshold, with inverse long-time trip curve;
 - against delayed short-circuits (S): $1...10xI_n$ adjustable protection threshold, with adjustable trip curve (as an alternative to I protection);
 - against instantaneous short-circuit (I): $1...10xI_n$ adjustable protection threshold, with instantaneous operating time (as an alternative to S protection);
 - neutral can be set in the OFF or ON positions, at 100% or at 160% of the phases;
- manual setting using the relative dip-switches on the front of the trip unit, which allow the settings to be made even when the trip unit is off;
- LED:
 - LED on with steady green light indicating that the trip unit is supplied correctly. The LED comes on when the current exceeds $0.32xI_n$;
 - red LED for each protection:
 - L: LED with steady red light, indicates pre-alarm for current exceeding $0.9xI_1$;
 - L: LED with flashing red light, indicates alarm for current exceeding setted threshold;
 - LS/I: LED with steady red light, shows that the protection has tripped. After the circuit-breaker has opened, connect the Ekip TT or Ekip T&P accessory to find out which protection function tripped the trip unit;
 - Ekip N-LS/I is equipped with a device that detects whether the opening solenoid has disconnected. Signalling is made by all the LEDs flashing simultaneously;
- test connector on the front of the release:
 - to connect the Ekip TT trip test unit which allows trip test, LED test and signalling about the latest trip happened;
 - for connecting the Ekip T&P unit, which allows the measurements to be read and the trip test to be carried out;
- thermal memory which can be activated by Ekip T&P;
- self-supply from $0.32xI_n$.

L, S, I protection LED

Dip switch for neutral selection

Dip switch for LS/I protection function setting

The diagram shows the front panel of the Ekip N-LS/I trip unit. It includes a neutral selection dip switch (OFF/ON), a series of trip threshold and time-current curve dip switches (L, S, I), a test connector, and a slot for a lead seal. Labels indicate the settings for I_1 , I_2 , I_3 , t_1 , t_2 , and t_3 .

Dip switch for the selection between S protection function or I protection function

Power-on LED

Test connector

Slot for lead seal

Dip switch for the trip curve selection

Ekip N-LS/I

Protection function	Trip threshold	Time-current curve ⁽¹⁾	Excludability	Relation	Thermal memory
L Against overloads with inverse long-time delayed tripping. According to IEC 60947-2 Standard	Manual setting: $I_1 = 0.4...1xI_n$ step 0.04 Tolerance: trip between $1.05...1.3xI_1$ (IEC 60947-2)	Manual setting: $t_1 = 12-36s$ at $I = 3xI_1$ Tolerance: $\pm 10\%$ up to $4xI_n$ $\pm 15\%$ from $4xI_n$	–	$t = k/I^2$	Yes
S Against short-circuits with time delay trip ($t=k$)	Manual setting: $I_2 = 1-1.5-2-2.5-3-3.5-4.5-5.5-6.5-7-7.5-8-8.5-9-10xI_n$ Tolerance: $\pm 10\%$	$t_2 = 0.1-0.2s$ Tolerance: $\pm 15\%$	Yes	$t = k$	–
I Against short-circuits with instantaneous trip time	Manual setting: $I_3 = 1-1.5-2-2.5-3-3.5-4.5-5.5-6.5-7-7.5-8-8.5-9-10xI_n$ Tolerance: $\pm 10\%$	$\leq 20ms$	Yes	$t = k$	–

⁽¹⁾ Tolerances in case of:
 – self-powered trip unit at full power;
 – 2 or 3 phase power supply.
 In conditions other than those considered, the following tolerance hold:

Protection	Trip threshold	Trip time
L	release between 1.05 and $1.3 \times I_1$	$\pm 20\%$
S	$\pm 10\%$	$\pm 20\%$
I	$\pm 15\%$	$\leq 60ms$

Switch-disconnectors

Main characteristics



XT1D



XT3D



XT4D

The switch-disconnector (or, in short, disconnector) is a device created from the corresponding circuit-breakers (of which it features the same overall dimensions, versions, fastening mechanisms and ability to be fitted with accessories).

The main function of these devices is to disconnect the circuit they are installed in. In the open position, the disconnector disconnects and guarantees a sufficient insulation distance (between the contacts) to assure safety and to prevent an electrical arc from striking.

Applications

Switch-disconnectors are generally used as:

- general disconnectors of subswitchboards;
- operating and disconnecting devices for lines, pan-assemblies or groups of equipment;
- bus-ties;
- general disconnecting devices for groups of machines;
- general group disconnecting devices for motor operation and protection;
- insulation of small tertiary distribution units.

Protection

A disconnector is unable to automatically break the short-circuit or overload current. For this reason, each switch-disconnector must be protected on the supply side by a coordinated device that safeguards it against short-circuits. The circuit-breaker able to act as a protection for each switch-disconnector is indicated in the table below.

Category of use ^(G2.11)

The CEI EN 60947-3 Standard defines the utilisation categories for disconnectors in accordance with the table below. Tmax XT disconnectors comply with the AC21A, AC22A and AC23A utilisation categories.

Class of use

Infrequent operation	Frequent operation	Typical applications
AC-21A	AC-21B	Control of resistive loads with overloads of modest entity
AC-22A	AC-22B	Control of mixed resistive and inductive loads with overloads of modest entity
AC-23A	AC-23B	Control of motors or other highly inductive loads

Characteristics of switch-disconnectors

		XT1D	XT3D	XT4D
Size ^(G2.1)	[A]	160	250	250
Rated operating current in class AC21, I_e ^(G2.12)	[A]	160	250	250
Rated operating current in class AC22, I_e ^(G2.12)	[A]	160	250	250
Rated operating current in class AC23, I_e ^(G2.12)	[A]	125	200	200
Poles	[Nr.]	3, 4	3, 4	3, 4
Rated service voltage, U_e ^(G2.4)	(AC) 50-60Hz	[V]	690	690
	(DC)	[V]	500	500
Rated insulation voltage, U_i ^(G2.5)	[V]	800	800	800
Rated impulse withstand voltage, U_{imp} ^(G2.6)	[kV]	8	8	8
Test voltage at industrial frequency for 1 min	[V]	3000	3000	3000
Rated making capacity in short-circuit, I_{cm} ^(G2.10)	(Min) Disconnector only	[kA]	2.8	5.3
	(Max) With automatic circuit-breaker on supply side	[kA]	154	105
Rated short-time withstand current for 1s, I_{cw} ^(G2.9)	[kA]	2	3	3.6
Versions		Fixed, Plug-in	Fixed, Plug-in	Fixed, Withdrawable, Plug-in

Switch-disconnectors coordination

			Load S.	XT1D	XT3D	XT4D
			I _{cw} [kA]	2	3,6	3,6
Supply S.	Version	I _{cu}	I _u I _{th}	160	250	250
XT1	B	18	160	18	18	18
	C	25		25	25	25
	N	36		36	36	36
	S	50		50	50	50
	H	70		70	50	70
XT2	N	36	160	36	36	36
	S	50		50	50	50
	H	70		70	50	70
	L	120		70	50	120
	V	150		70	50	150
XT3	N	36	250		36	36
	S	50			50	50
XT4	N	36	160 250		36	36
	S	50			50	50
	H	70			50	70
	L	120			50	120
	V	150			50	150

Special applications

Communication system

XT2 and XT4 moulded-case circuit-breakers, equipped with Ekip LSI, Ekip LSIG or Ekip M-LRIU trip unit and Ekip Com dialogue module, can be integrated in supervision systems for control and management of electrical and technological plants.


XT2 and XT4 equipped with thermomagnetic trip units or in switch-disconnector version are able to communicate CB status and to be operated remotely, when Ekip Com and MOE-E motor operators are installed.

The communication protocol available is Modbus RTU.

Necessaries accessories for communications are:

- Ekip Com communication module and electronic auxiliary contacts (1Q + 1SY) included in the Ekip Com module. For further details about the Ekip Com communication module, see the paragraph dedicated to this in the Accessories chapter;
- Electronic motor operator MOE-E only if operation from remote is required;

Configuration 1: Supervision (Electronic trip unit and Ekip Com)




Positioned in the right-hand slot of the circuit-breaker, the Ekip Com accessory connects to the Ekip LSI, Ekip LSIG, Ekip E-LSIG or Ekip M-LRIU trip unit via connector supplied. Six cables come out of Ekip Com, of which two are required for auxiliary supply, two for connection to the Modbus and two for connection to Internal Bus.

This configuration allows you to:

- read the measurements and settings from the electronic trip unit in remote mode;
- program the electronic trip unit in remote mode;
- know the state of the circuit-breaker (Open/Closed/Tripped) in remote mode;
- visualize locally Ekip Multimeter or on HMI 030 all the relevant information of the CB.

Consult the Electric Diagrams chapter for further details about wiring.

Configuration 2: Supervision and Remote control (Thermomagnetic trip unit or switch-disconnector, Ekip Com and MOE-E)




The Ekip Com accessory, positioned in the right-hand slot of the circuit-breaker, is connected with the MOE-E by means of the connector on the rear of the MOE-E. Six cables come out of the Ekip Com, of which two are needed for the auxiliary power supply and two for connection to the Modbus.

With this configuration it is possible to:

- read the Open/Closed/Tripped state of the circuit-breaker remotely;
- open/close the circuit-breaker or of the switch-disconnector remotely.

For further details regarding cabling of the various devices, please refer to the chapter on Electric Diagrams.

Configuration 3: Supervision and Remote Control (Electronic trip unit, Ekip Com and MOE-E)



Ekip Com accessory, positioned in the right-hand slot of the circuit-breaker, is connected to MOE-E and to Ekip LSI, Ekip LSIg, Ekip E-LSIG or Ekip M-LRIU trip unit by means of two connectors. Six cables come out of Ekip Com of which two are required for auxiliary supply, two for connection to the Modbus and two for connection to Internal Bus.

This configuration allows you to:


- read the measurements and settings from the solid-state release in remote mode;
- program the electronic trip unit in remote mode;
- read the state of the circuit-breaker (Open/Closed/Tripped) in remote mode;
- open/close the circuit-breaker in remote mode;
- visualize locally Ekip Multimeter or on HMI 030 all the relevant information of the CB.

Consult the Electric Diagrams chapter for further details about wiring.

Special applications

Communication system

Configuration 4: Interface from front panel (Electronic trip unit and Ekip Multimeter or HMI030 Unit)



With XT2 and XT4 circuit-breakers, equipped with electronic trip unit Ekip LSI, Ekip LSI_G, Ekip E-LSIG or Ekip M-LRIU, in addition to Ekip Multimeter or HMI030, it's possible to visualize directly on the panel door the main electrical parameters and the last trip information.

The necessary accessories, useful to permit the lecture directly from the front of the switchboard are:

- interface device Ekip Multimeter or HMI030;
- kit of 24V DC auxiliary voltage for electronic trip unit.

Four cables come out of kit of 24V DC auxiliary voltage, two of which are needed for the auxiliary power supply and two for connection to Ekip Multimeter or to HMI030 on Internal Bus.

This configuration makes it possible to read the measurements and alarms from the electronic trip unit by means of the HMI030 accessory positioned on the front of the panel.

For further details on cabling the various different devices, refer to the Electric Diagram Chapter.

Measurement, signalling and available data functions

	Ekip LSI	Ekip M-LRIU	Ekip E-LSIG	Ekip LS/I
	Ekip LSIG			TM
				Switch-disconnector
Electrical quantities				
Phase current (I_{L1}, I_{L2}, I_{L3})	■	■	■	
Neutral current (I_N) ⁽¹⁾	■		■	
Ground current (I_g)	■ ⁽¹⁾	■	■	
Phase to phase voltage ($V_{12}-V_{23}-V_{31}$)			■	
Phase-Neutral Voltage ($V_{1N}-V_{2N}-V_{3N}$) ⁽²⁾			■	
Frequency			■	
Power (active P, reactive Q, apparent S) total power and phase power ⁽²⁾			■	
Power factor (total and phase) ⁽²⁾			■	
Energy (active, reactive, apparent) total			■	
Harmonic calculation (THDi, spectre)			■	
Status information				
CB status (open, closed, tripped)	■	■	■	■
Modality (local, remote)	■		■	
Protection parameters	■	■	■	
Thermal memory	■	■	■	
Maintenance data				
Total number of operation	■	■	■	
Total number of protection trips	■	■	■	
Total number of trip test	■	■	■	
Total number of manual operations	■	■	■	
Total number of failed trip	■	■	■	
Last trip data recording	20	20	20	
Protection alarm				
I Protection (trip)	■	■	■	
S Protection (timing and trip)	■		■	
L Protection (timing and trip)	■	■	■	
G Protection (timing and trip)	■ ⁽¹⁾	■	■	
R Protection		■		
U Protection (timing and trip)				
L protection Prealarm ⁽³⁾	■	■	■	
Diagnostic Alarm				
Trip command failed	■	■	■	
Trip coil disconnected	■	■	■	
Commands				
CB Open/CB Close (with MOE-E motor operator)	■	■	■	■
CB Reset (with MOE-E motor operator)	■	■	■	■
Alarm Reset	■	■	■	
Trip test	■	■	■	
Protection parameter setting	■	■	■	
Run Time Events				
CB status changes, protection status change and alarms status change	■	■	■	

⁽¹⁾ Only with Ekip LSIG trip unit

⁽²⁾ Measurements available only with Neutral connected

⁽³⁾ $90\%I_n < I < 105\%I_n$



Index

Versions and types

Fixed part of plug-in and withdrawable versions	3/2
Conversion kits	3/3

Mechanical Accessories

Connection terminals	3/5
Terminal covers, phase separators and sealable screws for terminal covers	3/12
Rotary handle operating mechanism	3/12
IP54 Protection	3/13
Front for operating lever mechanism	3/13
Locks	3/14
Rear mechanical interlock	3/16
Bracket for fixing on DIN rail	3/16
Flanges	3/16

Electrical Accessories

Service releases	3/17
Auxiliary contacts	3/19
Motor operators	3/23
Connectors for electrical accessories	3/27
Residual current releases	3/28

Accessories for electronic trip units

Ekip Display	3/34
Ekip LED Meter	3/35
SACE PR212/CI contactor operator	3/35
Current sensor for external neutral	3/36
Connection accessories	3/36

Communication devices and systems

Ekip Multimeter	3/37
Ekip Com	3/39
Ekip Connect	3/40

Test and configuration accessories

Ekip T&P	3/41
Ekip TT	3/42

Automatic network-generator transfer unit ATS021-ATS022	3/43
---	------

Compatibility of accessories	3/45
------------------------------------	------

Accessories

Versions and types



Fixed circuit-breaker

Tmax XT automatic circuit-breakers are available in the following versions:

- **FIXED.** Fixed circuit-breakers consist of a current-interrupting part connected to the trip unit, to be installed on the back plate of the cubicle or on a DIN rail;
- **PLUG-IN.** Plug-in circuit-breakers consist of a fixed part that must be installed on the back plate of the cubicle, and of a moving part, obtained from the fixed circuit-breaker plus the relative kit that converts it from the fixed version into the moving part of the plug-in version;
- **WITHDRAWABLE.** Withdrawable circuit-breakers consist of a fixed part that must be installed on the back plate of the cubicle equipped with side runners to allow the moving part to be easily racked out and in, which is obtained from the fixed circuit-breaker plus the relative kit that converts it from the fixed version into the withdrawable moving part. To obtain the withdrawable version, a front accessory to be applied onto the front of the circuit-breaker must be ordered so as to maintain the IP40 degree of protection over the entire isolation run of the circuit-breaker.

If the plug-in circuit-breaker is fitted with electrical accessories, the appropriate connectors for isolation of the relative auxiliary circuits must also be ordered on the other hand, for the withdrawable version there are dedicated accessories, fitted with connectors which allow automatic disconnection in the case of racking-out (consult the “connection of electrical accessories” section in the Accessories chapter).



Plug-in circuit-breaker

Starting from the fixed version, SACE Tmax XT circuit-breakers can easily be converted into the plug-in and withdrawable versions using the relative conversion kits.

The moving part can always be obtained in the required version, fully pre-engineered in the factory, by ordering the fixed circuit-breaker and the conversion kit at the same time.

	Version		
	Fixed	Plug-in	Withdrawable
XT1	■	■	
XT2	■	■	■
XT3	■	■	
XT4	■	■	■




Withdrawable circuit-breaker

Fixed part of plug-in and withdrawable versions

The fixed parts of the plug-in/withdrawable versions are available with front terminals (F) or with horizontal or vertical rear terminals (HR/VR). The terminals are factory-mounted in the horizontal position. In case of need, the Customer can easily rotate the terminals into the vertical position. These fixed parts can be equipped with the same terminal, terminal-cover and phase separator kits used for the fixed circuit-breakers, using the proper adapter.

The fixed parts of a plug-in/withdrawable circuit-breaker can be installed at a distance of 50mm from the back of the panel or at 70mm as shown in the picture. Installation at 50mm is only compulsory in the case where rear vertical or horizontal terminals (HR/VR) are used.





Conversion kit for turning a fixed circuit-breaker into the moving part of a plug-in circuit-breaker



Conversion kit for turning a fixed circuit-breaker into the moving part of a withdrawable circuit-breaker



Conversion kit for turning a fixed part of plug-in version into the fixed part of a withdrawable version

Conversion kits

The following conversion kits can be obtained in order to create the different versions:

- **Kit for converting the fixed circuit-breaker into the moving part of plug-in/withdrawable versions.** The conversion kit converts the fixed circuit-breaker into the moving part of plug-in/withdrawable versions. Only when withdrawable versions are made is it essential to order an accessory to apply to the front of the circuit-breaker so as to maintain the IP40 degree of protection over the entire isolation run. This accessory can be chosen from:
 - front for lever operating mechanism (FLD);
 - motor operator (MOE);
 - direct or transmitted rotary handle operating mechanisms (RHD or RHE).

In the case where no accessory to be applied onto the front is indicated, the front for lever operating mechanism (FLD) is automatically included in the order.

- **Kit for converting the fixed part of plug-in versions into the fixed part of withdrawable versions.** The kit comprises:
 - a guide for turning the fixed part of the plug-in circuit-breaker into the fixed part of the withdrawable circuit-breaker;
 - a racking-out rotary handle that allows the moving part to be inserted and withdrawn. The mechanism allows the circuit-breaker to be set to the isolated position (with the power and auxiliary circuits disconnected) with the compartment door closed, all to the advantage of operator safety. The rotary handle can only be inserted when the circuit-breaker is open. Once it has been removed or withdrawn, the circuit-breaker can be set to the open/closed position;
 - a flange for the compartment door, which replaces the one supplied with the fixed version of the circuit-breaker.

- **Kit for converting fixed type into the plug-in version for RC Sel residual current devices for XT2-XT4.** RC Sel four-pole residual current devices for XT2 e XT4 can be converted from the fixed version into the plug-in version using the special kit.

- **Kit for converting plug-in types into the withdrawable version for RC Sel residual current devices for XT2-XT4.** RC Sel four-pole residual current devices for XT2 and XT4 can be converted from the plug-in version to the withdrawable version using the special kit, which comprises a bellows to apply to the front of the residual current device so as to allow it and the residual current part to be withdrawn when the panel door is closed. This kit can also be assembled on fixed circuit-breakers fitted with the front part for locks or the direct rotary handle, thus adding to the range of uses for residual current devices.


In the plug-in to withdrawable conversion kit, there is also a 6 pin connector to be applied onto the right side of the circuit-breaker to facilitate disconnection of the auxiliary circuits connected to the residual current device.

This kit contains also the shunt opening release of the residual current device dedicated to the withdrawable version, which is fitted with a connector for the fixed part and the moving part.

Accessories


Versions and types

Plug-in version




Withdrawable version

1st solution



2nd solution



⁽¹⁾ Frontal accessory mandatory. If not specified in the order, the FLD is supplied automatically

Accessories

Mechanical Accessories

Mechanical Accessories		XT1	XT2	XT3	XT4
Terminals	F - Front	■	■	■	■
	EF - Front extended	■	■	■	■
	ES - Front extended spread	■	■	■	■
	FCCu - Front for copper cables	■	■	■	■
	FCuAl - Front for copper/aluminium cables	■	■	■	■
	FB - For flexible busbars	■	■	■	■
	MC - Multi-cable	■	■	■	■
	R - Rear orientated	■	■	■	■
	EF - Extended front for the fixed part	■	■	■	■
	HR/VR - Horizontal rear / Vertical rear for fixed part	■	■	■	■
	HR for RC - for residual current release	■	—	■	—
Rotary handle operating mechanism	RHD - Direct rotary handle	■	■	■	■
	RHE - Transmitted rotary handle	■	■	■	■
	RHE-LH - Wide transmitted rotary handle	■	■	■	■
	RHS - Side rotary handle	■	■	■	■
Front for lever operating mechanism	FLD - Front for locks	—	■	—	■
Locks on CB	Padlock device	■	■	■	■
	Key lock	■	■	■	■
Locks on handle	Key lock	■	■	■	■
Locks on FLD	Key lock	—	■	—	■
Locks on Motor Operator	Key lock	■	■	■	■
	Key lock against manual operation	—	■	—	■
Lock for fixed part	Key lock	—	■	—	■
Rear interlock	Interlock	■	■	■	■
Bracket for DIN rail	Bracket	■	■	■	■

Consult the relative section for more details.

Connection terminals

Connection terminals allow the circuit-breaker to be connected to the system in the way most suited to the installation requirements. By and large they consist of:

- front terminals: for connecting cables or busbars directly from the front of the circuit-breaker;
- rear terminals: for installing circuit-breakers in segregated panels with rear access.

Where possible, the terminals have laser marking on the surface indicating the tightening torques for the correct isolation of cables and bars.

Fixed version

The part of the standard equipment, fixed version SACE Tmax XT circuit-breakers are supplied with front terminals (F). However, they can be fitted with the following types of terminals as accessories thanks to the special kits:

- extended front (EF);
- extended spread front (ES);
- front for copper/aluminium cables (FCCuAl). A pitch adapter must be applied to the terminal zone of the circuit-breaker to ensure that copper and aluminium cables with sections of up to 240mm² can be connected to all the circuit-breakers. The pitch adapter is automatically supplied when it is necessary (see table page 3/9);
- front for copper cables (FCCu);
- for flexible busbars (FB);
- multicable (MC);
- rear oriented (R).

For XT 1 and XT3 sizes, the use of not insulated busbar with $U_e \leq 480V$ involves the mandatory assembly of terminal covers HTC.

Accessories

Mechanical Accessories

Plug-in and withdrawable versions


Fixed part of plug-in and withdrawable version circuit-breakers are normally supplied with extended front terminals (EF) or horizontal/vertical rear terminals (HR/VR).

The terminals are factory-mounted in the horizontal position. In case of need, the Customer can easily rotate the terminals into the vertical position.

A fixed part with front terminals (EF) can be converted into a fixed part with rear terminals (HR/VR) by ordering the appropriate terminal kit. The fixed parts can also be fitted with the same types of terminals available on the fixed circuit-breaker after an adapter has been installed on the terminal zone of the fixed part itself. Consequently, the following types of connection terminals are also available for the fixed part:

- extended spread front (ES);
- for copper-aluminium cables (FCCuAl);
- for copper cables (FCCu);
- for flexible busbars (FB);
- multi-cable (MC).

The adapter reproduces the terminal zone of the fixed circuit-breaker. This means that fixed parts can also be equipped with the same terminal covers and phase separators as those used for fixed circuit-breakers.



Fixed part adapter

Fixed part adapter

Circuit- breakers	H ₁ fixed part [mm]	H ₂ circuit-breaker [mm]	H ₃ fixed part with two adapters [mm]
XT1	146	134	181
XT2	153	134	188
XT3	166	154	225
XT4	182	164	228

Front terminals - F

CB.	Vers.	Busbar dimensions [mm]						Cable terminals [mm]		Tightening		H Terminal covers [mm]			H Separators [mm]		
		W min	W max	H	Ø	D min	D max	W	Ø	Cable or busbar /Terminal		2	50	60	25	100	200
XT1	F	13	16	7.5	6.5	3.5	5	16	6.5	M6	6Nm	–	R	–	S	R	R
XT2	F	13	20	7.5	6.5	2.5	5	20	6.5	M6	6Nm	–	R	–	S	R	R
XT3	F	17	25	9.5	8.5	5	8	24	8.5	M8	8Nm	–	–	R	S	R	R
XT4	F	17	25	10	8.5	5	8	25	8.5	M8	8Nm	–	–	R	S	R	R



Front terminal - F



F terminal with cable lug



F terminal with busbar

Front extended terminals - EF

CB	Vers.	Busbar dimensions MAX [mm]			Cable terminals [mm]		Tightening				H Terminal covers [mm]			H Separators [mm]		
		W	D	Ø	W	Ø	Terminal /CB		Cable or busbar /Terminal		2	50	60	25	100	200
XT1	F	20	4	8.5	20	8.5	M6	6Nm	M8	9Nm	–	R	–	–	S	R
XT2	F	20	4	8.5	20	8.5	M6	6Nm	M8	9Nm	–	S	–	–	S	R
XT3	F	20	6	10	20	10	M8	8Nm	M10	18Nm	–	–	R	–	S	R
XT4	F	20	10	10	20	10	M8	8Nm	M10	18Nm	–	–	S	–	S	R




Front extended terminal - EF



EF terminal with cable lug



EF terminal with busbar



W Width
H Hole Height
D Depth

F Fixed
P Plug-in
W Withdrawable
Ø Diameter
S Standard
R On Request

Accessories

Mechanical Accessories

Front extended spread terminals - ES

CB	Vers.	Busbar dimensions MAX [mm]			Cable terminals [mm]		Tightening				H Terminal covers [mm]			H Separators [mm]		
		W	D	Ø	W	Ø	Terminal /CB		Cable or busbar /Terminal		2	50	60	25	100	200
XT1	F-P	25	4	8.5	25	8.5	M6	6Nm	M8	9Nm	–	–	–	–	–	S
XT2	F-P-W	30	4	10.5	30	10.5	M6	6Nm	M10	18Nm	–	–	–	–	–	S
XT3	F-P	30	4	10.5	30	10.5	M8	8Nm	M10	18Nm	–	–	–	–	–	S
XT4	F-P-W	30	6	10.5	30	10.5	M8	8Nm	M10	18Nm	–	–	–	–	–	S



Front extended spread terminal - ES



ES terminal with cable lug



ES terminal with busbar

Terminals for copper cables - FCCu

CB	Type of terminal	Vers.	Cable [mm²]		Tightening		L cable stripping [mm]	H Terminal covers [mm]			H Separators [mm]		
			Rigid	Flexible	Cable or busbar /Terminal			2	50	60	25	100	200
XT1	internal	F-P	1x2.5...70	1x2.5...50	12x12mm	7Nm	12	–	R	–	S ⁽¹⁾	R	R
	internal	F-P	–	2x2.5...35				–	R	–	S ⁽¹⁾	R	R
XT2	internal	F-P-W	1x2.5...95	1x2.5...70	14x14mm	7Nm	14	–	R	–	S ⁽¹⁾	R	R
	internal	F-P-W	–	2x2.5...50				–	R	–	S ⁽¹⁾	R	R
XT3	internal	F-P	1x6...185	1x6...150	18x18mm	14Nm	12	–	–	R	S ⁽¹⁾	R	R
	internal	F-P	–	2x6...70				–	–	R	S ⁽¹⁾	R	R
XT4	internal	F-P-W	1x6...185	1x6...150	18x18 mm	14Nm	12	–	–	R	S ⁽¹⁾	R	R
	internal	F-P-W	–	2x6...70				–	–	R	S ⁽¹⁾	R	R

⁽¹⁾ Phase separators supplied as standard with basic version circuit-breaker




FCCu terminal



FCCu terminal with cable



FCCu terminal with busbar



W Width
H Hole Height
D Depth

F Fixed
P Plug-in
W Withdrawable
Ø Diameter
S Standard
R On Request

Terminals for copper/aluminium cables - FC CuAl

CB	Type of terminal	Vers.	Cable [mm ²]		Tightening				L cable stripping [mm]	H Terminal covers [mm]			H Separators [mm]		
			Rigid	Flexible	Terminal /CB		Cable or busbar /Terminal			2	50	60	25	100	200
XT1	internal	F-P	1x1.5...50	1x 1.5...50	M5	5Nm	Ø 9.5mm	7Nm	16	–	R	–	S	R	R
	external	F-P	1x35...95	NO	M6	6Nm	Ø 14mm	13.5Nm	16	–	S	–	–	–	–
	external ⁽¹⁾	F-P	1x120...240	NO	M6	6Nm	Ø 24mm	31Nm	24	ADAPTER					
XT2	internal	F-P-W	1x2.5...95	1x2.5...70	–	–	Ø 14mm	7Nm	14	–	R	–	S	R	R
	external ⁽¹⁾	F-P-W	1x120...240	NO	M6	6Nm	Ø 24mm	31Nm	24	ADAPTER					
	external ⁽¹⁾	F-P-W	1x70...185	NO	M6	6Nm	Ø 18mm	25Nm	20	–	S	–	–	–	–
	external ⁽¹⁾	F-P-W	2x35...95	NO	M6	6Nm	Ø 16mm	12Nm	18/33	–	–	S	–	–	–
XT3	internal ⁽¹⁾	F-P-W	1x35...150	NO	M9	9Nm	Ø 17mm	31Nm	20	–	–	R	S	R	R
	internal	F-P	1x95...185	NO	–	–	Ø 18mm	16Nm	20	–	–	R	S	R	R
	external ⁽¹⁾	F-P	1x120...240	NO	M8	8Nm	Ø 24mm	31Nm	24	ADAPTER					
	external ⁽¹⁾	F-P	2x35...150	NO	M8	8Nm	Ø 18mm	16Nm	22/42	–	–	S	–	–	–
XT4	internal	F-P-W	1x2.5...185	1x2.5...150	–	–	Ø 17mm	10Nm	21	–	–	R	S	R	R
	external ⁽¹⁾	F-P-W	1x120...240	NO	M8	8Nm	Ø 24mm	31Nm	24	ADAPTER					
	external ⁽¹⁾	F-P-W	2x35...150	NO	M8	8Nm	Ø 18mm	16Nm	22/42	–	–	S	–	–	–

⁽¹⁾ Take-up auxiliary voltage device included



Internal FCCuAl terminal for copper/aluminium cables



Internal FCCuAl terminal for copper and aluminium cable with take-up of auxiliary voltage



External FCCuAl terminal for copper/aluminium cables



FCCuAl internal terminal with cable



FCCuAl external terminal with cables




Pitch adapter

Adaptor for FCCuAl terminals up to 240mm²

Circuit-breaker	Poles	Dimensions [mm] [WxHxD]
XT1	3	105x50x68
	4	140x50x68
XT2	3	105x50x68
	4	140x50x68
XT3	3	105x50x68
	4	140x50x68
XT4	3	105x50x68
	4	140x50x68

Note: With XT1 and XT2 the adaptor increases the width of the circuit-breaker



W Width
H Hole Height
D Depth

F Fixed
P Plug-in
W Withdrawable
Ø Diameter
S Standard
R On Request

Accessories

Mechanical Accessories

Terminals for flexible busbars - FB

CB	Type of terminal	Vers.	Busbar dimensions MIN [mm]			Busbar dimensions MAX [mm]			Tightening [Nm]	H Terminal covers [mm]			H Separators [mm]		
			W	D	Nr	W	D	Nr		2	50	60	25	100	200
XT1	internal	F-P	10	0.8	2	10	0.8	9	7Nm	–	R	–	S ⁽¹⁾	R	R
XT2	internal	F-P-W	10	0.8	2	10	0.8	9	7Nm	–	R	–	S ⁽¹⁾	R	R
XT3	internal	F-P	16	0.8	2	16	0.8	10	14Nm	–	–	R	S ⁽¹⁾	R	R
XT4	internal	F-P-W	16	0.8	2	16	0.8	10	14Nm	–	–	R	S ⁽¹⁾	R	R

⁽¹⁾ Phase separators supplied as standard with basic version circuit-breaker



Terminal for flexible busbars (FB)



FB terminal with flexible busbars

Multi-cable terminals - MC

CB	Vers.	Cable [mm²]		Tightening				L cable stripping [mm]	H Terminal covers [mm]			H Separators [mm]		
		Rigid	Flexible	Terminal /CB		Cable or busbar /terminal			2	50	60	25	100	200
XT1	F-P	6x2.5...35	6x2.5...25	M6	6Nm	Ø 8	7Nm	10, 20, 30	–	S	–	–	–	–
XT2	F-P-W	6x2.5...35	6x2.5...25	M6	6Nm	Ø 8	7Nm	10, 20, 30	–	S	–	–	–	–
XT3 ⁽¹⁾	F-P	6x2.5...35	6x2.5...25	M8	8Nm	Ø 8	7Nm	15, 30	–	–	S	–	–	–
XT4 ⁽¹⁾	F-P-W	6x2.5...35	6x2.5...25	M8	8Nm	Ø 8	7Nm	15, 30	–	–	S	–	–	–

⁽¹⁾ Take up auxiliary voltage device included



Multi-cable terminals (MC)



Multi-cable terminals with cables

Rear horizontal terminals - R

CB	Vers.	Busbar dimensions MAX [mm]				Tightening				H Terminal covers [mm]			H Separators [mm]		
		W	H	D	Ø	Terminal /CB		Cable or busbar /terminal		2	50	60	25	100	200
XT1	F	15	7.5	5	6.5	M5	5Nm	M6	6Nm	S	–	–	–	–	–
XT2	F	20	9	4	8.5	M6	6Nm	M8	9Nm	S	–	–	–	–	–
XT3	F	20	9	6	8.5	M8	8Nm	M8	9Nm	S	–	–	–	–	–
XT4	F	20	9	6	8.5	M8	8Nm	M8	9Nm	S	–	–	–	–	–



Rear horizontal terminals (R)



R terminal with horizontal busbar



R terminal with vertical busbar

Extended front terminals for fixed part - EF

CB	Vers.	Busbar dimensions MAX [mm]			Cable terminals [mm]		Tightening				Rear Separators [mm]	
		W	D	Ø	W	Ø	Terminal / CB		Cable or busbar / Terminal		100	200
XT1	P	20	5	6.5	21	6.5	M6	6Nm	M6	9Nm	S	R
XT2	P-W	20	5	6.5	21	6.5	M6	6Nm	M6	9Nm	S	R
XT3	P	25	8	8.5	30	8.5	M6	8Nm	M8	18Nm	S	R
XT4	P-W	25	8	8.5	30	8.5	M6	8Nm	M8	18Nm	S	R



EF terminals for fixed part

Rear flat horizontal terminals for fixed part - HR

CB	Vers.	Busbar dimensions MAX [mm]			Cable terminals [mm]		Tightening		Rear Separators [mm]	
		W	D	Ø	W	Ø	Terminal / CB	Cable or busbar / Terminal	90	
XT1	P	20	4	8.5	20	8.5	6Nm	9Nm	R	
XT2	P-W	20	4	8.5	20	8.5	6Nm	9Nm	R	
XT3	P	20	6	8.5	20	8.5	6Nm	9Nm	R	
XT4	P-W	20	10	8.5	20	8.5	6Nm	9Nm	R	




HR terminals for fixed part

Rear flat vertical terminals for fixed part - VR

CB	Vers.	Busbar dimensions MAX [mm]			Cable terminals [mm]		Tightening		Rear Separators [mm]	
		W	D	Ø	W	Ø	Terminal / CB	Cable or busbar / Terminal	90	
XT1	P	20	4	8.5	20	8.5	6Nm	9Nm	R	
XT2	P-W	20	4	8.5	20	8.5	6Nm	9Nm	R	
XT3	P	20	6	8.5	20	8.5	6Nm	9Nm	R	
XT4	P-W	20	10	8.5	20	8.5	6Nm	9Nm	R	



VR terminals for fixed part



W Width
H Hole Height
D Depth

F Fixed
P Plug-in
W Withdrawable
Ø Diameter
S Standard
R On Request

Accessories

Mechanical Accessories



Terminal covers



Phase separators



Sealable screws

Terminal covers, phase separators and sealable screws for terminal covers

Terminal covers are applied to the circuit-breaker to prevent accidental contact with live parts, thus providing protection against direct contacts. The terminal covers are pre-punched for know-out on the front to facilitate installation of busbars and/or cables, guaranteeing correct insulation.

The phase separator partitions increase the insulation characteristics between the phases on a level with the connections. They are mounted from the front, even when the circuit-breaker has already been installed, by inserting them into the corresponding slots.

The table lists the various different terminal covers and phase separators available for each SACE Tmax XT circuit-breaker. The terminal covers/phase separators able to guarantee adequate circuit-breaker installation and correct insulation are listed in the "Connection Terminals" section of the Accessories Chapter alongside each terminal.

The lead sealing kit consists of screws which, when applied to the terminal covers, prevent their removal, providing protection against direct contacts and tampering. The screws can be locked with wire and lead seals.

Each sealing kit consists of two screws. The maximum number of sealable screws that can be used for each circuit-breaker is given in the table below.

		XT1		XT2		XT3		XT4	
		3p	4p	3p	4p	3p	4p	3p	4p
HTC - High terminal covers	[mm]	50	50	50	50	60	60	60	60
LTC - Low terminal covers	[mm]	2	2	2	2	2	2	2	2
Max number sealable screws for each terminal cover	[No.]	1	1	1	1	1	2	1	1
Phase separator - low	[mm]	25	25	25	25	25	25	25	25
Phase separator - medium	[mm]	100	100	100	100	100	100	100	100
Phase separator - high	[mm]	200	200	200	200	200	200	200	200
Rear phase separator for FP	[mm]	90		90		90		90	

Rotary handle operating mechanism

Operating device that allows the circuit-breaker to be operated by means of a rotary handle, which makes the circuit-breaker easier to open and close thanks to its ergonomic handgrip.

Different types of handles are available:

- direct (RHD): installed directly on the front of the circuit-breaker. Allows it to be operated frontally;
- transmitted (RHE): installed on the panel door. Allows the circuit-breaker to be operated by means of a rod which acts on a base installed on the front of the circuit-breaker;
- lateral left (RHS-L) and lateral right (RHS-R): installed directly on the front of the circuit-breaker. Allows it to be operated from the side.

The wide handle grip (LH) only is also available, which can be combined with the transmitted handle (RHE) and with the lateral handle (RHS).



Direct rotary handle (RHD)



Transmitted rotary handle (RHE)



(LH) Handle grip



(RHS) Lateral handle

All rotary handles are available in two versions:

- standard: grey colour;
- emergency: red on a yellow background. Suitable for operating machine tools.

Rotary handles can be ordered:

- by specifying one single sales code (for RHD, RHE, RHS L/R);
- by indicating the following three devices (only for RHE):
 - rotary handle on compartment door with normal standard handgrip (RHE_H, RHE_H LH) or emergency handgrip (RHE_H_EM, RHE_H_EM LH);
 - 500mm transmission rod (RHE_S). The minimum and maximum distances between the fixing plate and the door are 60.5mm and 470.5mm;
 - base on the circuit-breaker to fix to the circuit-breaker (RHE_B).

Use of the rotary handle is an alternative to the motor operator and to all accessories of the front type.

The rotary handles can be locked by means of a vast range of key locks and padlocks (consult the “locks” section of the Accessories chapter).

The direct and transmitted rotary operating mechanisms allow early contacts to be used on closing so as to supply the undervoltage release in advance of circuit-breaker closing (consult the “early auxiliary contacts” section of the Accessories chapter).



IP54 protection

IP54 Protection

Device which can be applied onto the transmitted rotary and lateral handle allowing IP54 degree of protection^(G.1.11) to be achieved.



Front for locks

Front for operating lever mechanism

This device can be installed on the front of the circuit-breaker and allows it to be locked with key locks and padlocks.

The front for lever operating mechanism can only be installed on XT2 and XT4 three-pole and four-pole circuit-breakers. The front for lever operating mechanism can be fitted with a vast range of key locks and padlocks (see the “locks” section of the Accessories chapter).

Accessories

Mechanical Accessories



Key lock



Fixed padlock in open position



Fixed padlock in open/closed position



Removable padlock in open position



Key lock/padlock for withdrawable fixed part

Locks

Padlocks or key locks that prevent the circuit-breaker from being closed and/or opened. They can be fitted:

- directly on the front of the circuit-breaker;
- on the rotary handle operating mechanism;
- on the front for lever operating mechanism;
- on the motor;
- to the fixed and withdrawable part, to prevent the moving part from being inserted;
- on the front of the thermomagnetic trip unit, to prevent the adjuster of the thermal part from being tampered with.

All locks that hold the circuit-breaker in the open position ensure circuit isolation in accordance with the IEC 60947-2 Standard. In the closed position, the locks do not prevent the mechanism from releasing after a fault or remote control.



Circuit-breaker with removable padlock in open position



Circuit-breaker with fixed padlock in open position



Circuit-breaker with fixed padlock in open/close position



RHD with key lock



RHE with key lock



FLD with key lock



MOD with key lock



MOE with key lock



Withdrawable fixed part with key lock/padlock

Type of lock		Circuit-breaker	Optional/ Standard supply	Position of circuit-breaker lock	Type of lock	Removability of key
Circuit-breaker	PLL Fixed padlock device	XT1...XT4	Optional	OPEN / CLOSED	padlocks max 3 padlocks Ø 7mm stem (not supplied)	—
		XT1...XT4	Optional	OPEN	padlocks max 3 padlocks Ø 7mm stem (not supplied)	—
	PLL Removable padlock device	XT1, XT3	Optional	OPEN	padlocks max 3 padlocks Ø 7mm stem (not supplied)	—
	KLC Key lock ⁽⁵⁾	XT1...XT4	Optional	OPEN	Ronis Same key (A, B, C, D type)	OPEN
		XT1...XT4	Optional	OPEN	Ronis Different key	OPEN
		XT1...XT4	Optional	OPEN	Ronis Same key	OPEN / CLOSED
Rotary handle (RHD/RHE/ RHE-LH/ RHS)	RHL Key lock ⁽¹⁾	XT1...XT4	Optional	OPEN	Ronis Same key	OPEN
		XT1...XT4	Optional	OPEN	Ronis Different key	OPEN
		XT1...XT4	Optional	OPEN / CLOSED	Ronis Different key	OPEN / CLOSED
	Padlock device	XT1...XT4	Standard	OPEN	padlocks max 3 padlocks Ø 6mm stem (not supplied)	—
	Door lock ⁽⁴⁾	XT1...XT4	Standard	DOOR LOCKED WHEN CIRCUIT-BREAKER CLOSED	—	—
Frontal for operating lever (FLD)	Padlock device	XT2, XT4	Standard	OPEN	padlocks max 3 padlocks Ø 6mm stem (not supplied)	—
	Door lock	XT2, XT4	Standard	DOOR LOCKED WHEN CIRCUIT-BREAKER CLOSED	—	—
	RHL Key lock ⁽¹⁾	XT2, XT4	Optional	OPEN	Ronis Same key	OPEN
		XT2, XT4	Optional	OPEN	Ronis Different key	OPEN
		XT2, XT4	Optional	OPEN / CLOSED	Ronis Different key	OPEN / CLOSED
Motor (MOD, MOE, MOE-E)	Padlock device	XT1...XT4	Standard	OPEN	padlocks max 3 padlocks Ø 8mm stem (not supplied)	—
	Key lock on motor MOL-D MOL-S	XT1...XT4	Optional	OPEN	Ronis Different keys	OPEN
		XT1...XT4	Optional	OPEN	Ronis Same keys	OPEN
	Key lock against manual operation MOL-M ⁽²⁾	XT1...XT4	Optional	MANUAL	Ronis key	WITH LOCK INSERTED
Fixed part of withdrawable	KLF-FP Key lock / padlock for fixed part of withdrawable device	XT2, XT4	Optional	Key WITHDRAWN / INSERTED Padlock WITHDRAWN	Ronis key Different + padlocks max 3 padlocks Ø 6mm stem (not supplied)	—
		XT2, XT4	Optional	Key WITHDRAWN / INSERTED Padlock WITHDRAWN	Ronis key Same + padlocks max 3 padlocks Ø 6mm stem (not supplied)	—
		XT2, XT4	Optional	Key WITHDRAWN / INSERTED Padlock WITHDRAWN	Giussani key Different + padlocks max 3 padlocks Ø 6mm stem (not supplied)	—
		XT2, XT4	Optional	Key WITHDRAWN / INSERTED Padlock WITHDRAWN	Giussani key Same + padlocks max 3 padlocks Ø 6mm stem (not supplied)	—
Trip unit	Lock of thermal regulation ⁽³⁾	XT1, XT3	Optional	—	—	—
		XT2, XT4	Standard	—	—	—

⁽¹⁾ On the transmitted rotary handle (RHE), the lock is mounted on the base. The key lock is not available on the lateral handle (RHS).

⁽²⁾ Only for MOE and MOE-E.

⁽³⁾ Applied to the cover of the circuit-breakers on a level with the regulator of the thermal element of thermomagnetic release TMD and prevents it from being tampered with.

⁽⁴⁾ This function can be totally inhibited by the customer when the handle is assembled by means of a simple operation that can be reversed if needed.

Moreover, if the door lock function is not disabled by the customer during the assembly phase, the door lock can be temporarily deactivated with a tool in exceptional cases, so that the door can be opened without opening the circuit-breaker.

⁽⁵⁾ Incompatible with electrical accessories mounted in the third pole.

Accessories

Mechanical Accessories



Interlock

Rear mechanical interlock

Support, designed for installation on the rear of two circuit-breakers to be interlocked, and which, by means of linkages, prevents the two circuit-breakers it is installed on from closing simultaneously. The circuit-breakers in the Tmax XT family are interlocked two-by-two (IO-OI-OO) by means of a chassis and special plates. Interlocked circuit-breakers can be in fixed, plug-in or withdrawable version. Both circuit-breakers and switch-disconnectors in the three-pole and four-pole versions can be interlocked.


The acceptable combinations are:

- | | |
|-----------|------------|
| ■ XT1-XT1 | ■ XT2-XT4 |
| ■ XT1-XT2 | ■ XT2-XT2 |
| ■ XT1-XT3 | ■ XT3-XT3 |
| ■ XT1-XT4 | ■ XT4-XT4. |

The following equipment must be ordered to make the rear interlock:

- a vertical or horizontal chassis;
- a plate for each circuit-breaker to be interlocked.

Please advise that remote closing commands sent to interlocked CB in open position must be prevented in order to ensure correct functioning of mechanical interlock. If it is not possible to prevent them, key lock in open position for MOE is necessary.



Bracket for fixing on DIN rail

Bracket for fixing on DIN rail

Support designed for installation on the back of the circuit-breakers to simplify assembly on standardized DIN EN 50022 rail.

The following can be installed on DIN EN 50022 rail:

- all Tmax XT circuit-breakers in the fixed three-pole or four-pole versions;
- XT1, XT3 circuit-breakers equipped with RC Sel 200; RC Inst, RC Sel for XT1 and XT3 residual current releases.

Flanges

Plastic plate that acts as an interface between the circuit-breaker and the hole in the panel door. All the Tmax XT series flanges are newly designed and do not require screws for installation. Flanges are applied:

- around the front part of the fixed/plug-in circuit-breaker;
- around the operating lever for all fixed/plug-in/withdrawable version circuit-breakers;
- around the MOD or MOE motor operator;
- around the front for FLD locks;
- around the direct rotary handle operating mechanism;
- around the transmitted rotary handle operating mechanism;
- around the RC Inst, RC Sel for XT1 and XT3, RC Sel for XT2 and XT4 residual current release



XT1-XT3 circuit-breaker with standard flange



XT2-XT4 circuit-breaker with standard flange



Circuit-breaker with optional flange



Rotary handle with flange



MOE with flange



MOD with flange

Accessories

Electrical Accessories

Electrical Accessories		XT1	XT2	XT3	XT4
Shunt opening release	SOR	■	■	■	■
Permanent shunt opening release	PS-SOR	■	■	■	■
Undervoltage release	UVR	■	■	■	■
Time-delay device for undervoltage release	UVD	■	■	■	■
Auxiliary contacts	1Q 1SY 24V DC	■	■	■	■
	3Q 1SY 24V DC	—	■	■	■
	1S51 24V DC	—	■	—	■
	1Q 1SY 250V AC/DC	■	■	■	■
	2Q 2SY 1S51 250V AC/DC	—	■	—	■
Q: open/close signalling contact	3Q 2SY 250V AC/DC	—	■	—	■
SY: trip signalling contact	3Q 1SY 250V AC/DC	—	■	■	■
S51: electronic trip signalling contact	1S51 250V AC/DC	—	■	—	■
	2Q 1SY 250V AC/DC	■	■	■	■
	3Q on left 250V AC/DC	■	■	■	■
	400V 1Q 1SY 400V AC	—	■	—	■
	400V 2Q 400V AC	—	■	—	■
Position contacts	AUP-Racked-in	■	■	■	■
	AUP-Racked-out	—	■	—	■
Early auxiliary contacts	AUE-In handle	■	■	■	■
Motor operator	MOD	■	—	■	—
	MOE	—	■	—	■
	MOE-E	—	■	—	■
Residual current devices	RC Inst	■	—	■	—
	RC Sel 200	■	—	—	—
	RC Sel for XT1 XT3	■	—	■	—
	RC Sel for XT2 XT4	—	■	—	■
	RC Sel B Type	—	—	■	—



Cabled SOR - PS SOR - UVR



Cabled SOR - PS SOR - UVR for withdrawable circuit-breaker



Uncabled SOR - PS SOR - UVR

Service releases

Shunt opening release (SOR). Allows the circuit-breaker to be opened by means of a non-permanent electrical control. Release operation is guaranteed for voltage between 70% and 110% of the rated power supply voltage U_n , in both alternating and direct current. SOR is equipped with a built-in limit contact to shut-off the power supply in the open position with the relay tripped. A remote controlled emergency opening command can be created by connecting an opening button to the SOR.

Shunt opening release with permanent service (PS-SOR), unlike SOR, this version can be continuously powered. The power input of PS SOR is much lower than the power input of SOR.

Undervoltage release (UVR). Allows the circuit-breaker to open when the release is subjected to either a power failure or voltage drop. Opening, as prescribed in the Standard, is guaranteed when the voltage is between 70% to 35% of U_n . After tripping, the circuit-breaker can be closed again if the voltage exceeds the 85% of U_n . When the undervoltage release is not energized, neither the circuit-breaker nor the main contacts can be closed. A remote controlled emergency opening command can be created by connecting an opening button to the UVR.

None of the service releases in the Tmax XT series require screws for installation. They are extremely easy to fit. Just use slight pressure in the appropriate place. All service releases are available in two versions:

- cabled (AWG20 cable section - 0.5mm² up to 300V, AWG17 - 1mm² up to 525V):
 - for fixed/plug-in circuit-breakers with 1m long cables;
 - for withdrawable circuit-breakers with fixed part and moving part connector;
- not cabled:
 - for fixed/plug-in circuit-breakers with cables from 1.5 mm² in section.

Accessories

Electrical Accessories

In circuit-breakers:

- three-pole: as an alternative, SOR, PS-SOR or UVR can be installed in the slot on the left of the operating lever;
- four-pole: SOR, PS-SOR or UVR can be housed at the same time in the slot of the third and fourth pole. If the circuit-breaker is the withdrawable type, the connector for the fourth pole must be ordered to be able to install SOR, PS SOR and UVR in the fourth pole. If there is a residual current release, the opening solenoid (SA) of the residual current device must be installed in the slot of the third pole on the left of the operating lever.



SOR Electrical specifications

Version	Max power absorbed on inrush		Resistance	
	AC [VA]	DC [W]	Internal [ohm]	External [ohm]
12V DC		50	2,67	0
24-30V AC/DC	50	50	11	0
48-60V AC/DC	60	60	62	0
110...127V AC-110...125V DC	50	50	248	0
220...240V AC-220...250V DC	50	50	930	0
380-440V AC	55		2300	0
480-525V AC	55		5830	0

PS SOR Electrical specification

Version	Power absorbed during normal operation		Resistance	
	AC [VA]	DC [W]	Internal [ohm]	External [ohm]
24-30V AC/DC	6	6	162	0
48-60V AC/DC	4.5	4.5	586-930 ⁽¹⁾	0
110...127V AC-110...125V DC	5	5	3720	0
220...240V AC-220...250V DC	5	5	13550	0
380-440V AC	7		20502	10000
480-525V AC	8.5		20502	15000

⁽¹⁾ The two different values refer to the minimum-maximum value of the voltage used

UVR Electrical specification

Version	Power absorbed during normal operation		Resistance	
	AC [VA]	DC [W]	Internal [ohm]	External [ohm]
24-30V AC/DC	1.5	1.5	399	0
48V AC/DC	1	1	1447	100
60V AC/DC	1	1	2405	100
110...127V AC-110...125V DC	2	2	8351	390
220...240V AC-220...250V DC	2.5	2.5	20502	9000
380-440V AC	3		20502	39000
480-525V AC	4		20502	59000



Time delay device for undervoltage release

Opening and closing release test unit - YO/YC Test Unit

On Tmax XT the opening and closing releases test unit helps ensure that the various version of releases are running smoothly, to guarantee a high level of reliability in controlling circuit-breaker opening. The test unit ensures the continuity of the opening releases with a rated operating voltage between 24V and 250V (AC and DC). Continuity is checked cyclically with an interval of 20s between tests. The unit has optic signals via LEDs on the front, which provide the following information:

POWER ON: power supply present

TESTING: testing in progress

TEST FAILED: signal following a failed test or lack of auxiliary power supply

ALARM: signal given following three failed tests.

Two relays with one change-over area also available on board the unit, to allow remote signalling of the following events:

Failure of a test - resetting takes place automatically when the alarm stops

Failure of three tests - resetting occurs only by pressing the manual RESET on the unit.


Characteristics of devices

Auxiliary power supply	24...250V AC/DC
Specifications of the signalling relays	
Maximum interrupted current	6A
Maximum interrupted voltage	250V AC

Auxiliary contacts

Contacts which allow information about the operating state of the circuit-breaker to be routed outside the circuit-breaker. The following information is available:

- open/closed: indication of the position of the circuit-breaker power contacts (Q);
- trip: signalling circuit-breaker opening due to the current release tripping (owing to overload or short-circuit), the residual current device, the opening or undervoltage releases, the emergency opening pushbutton of the motor operator, or owing to use of the test button (SY);
- trip unit tripping: indicates that one of the protection functions of the electronic or thermomagnetic trip unit has tripped (S51).



Changeover of auxiliary contacts Q (open/closed), SY (Relay tripped) and S51 (trip unit tripping)

Normal sequence	CB Open	Q=12	SY=96	S51=06
	CB Closed	Q=14	SY=96	S51=06
Trip Sequence (trip caused by: - SOR, - UVR, - Trip Test)	CB Open	Q=12	SY=96	S51=06
	CB Closed	Q=14	SY=96	S51=06
	CB Trips	Q=12	SY=98	S51=06
	CB Resets	Q=12	SY=96	S51=06
Trip Sequence (trip caused by trip unit)	CB Open	Q=12	SY=96	S51=06
	CB Closed	Q=14	SY=96	S51=06
	CB Trips	Q=12	SY=98	S51=08
	CB Resets	Q=12	SY=96	S51=06



24V DC and 250V AC/DC auxiliary contacts

250V AC/DC and 24VAC/ DC auxiliary contacts are installed without the need for any screws. They are extremely easy to fit. Simply use slight pressure in the appropriate place. The following versions of auxiliary contacts are available:

Accessories

Electrical Accessories

- cabled (AWG20 cable section -0.5mm²):
 - for fixed/plug-in circuit-breakers with 1m long cables;
 - for withdrawable circuit-breakers with fixed part and moving part connector;
- not cabled:
 - for fixed/plug-in circuit-breakers with cables from 0.5 up to 1.5 mm² in section.





Auxiliary contacts are supplied for each circuit-breaker in the SACE XT family in various different combinations, as shown in the table. The following items can be ordered to make installation even more flexible:

- a non-cabled auxiliary contact can create different signals (Q or SY) as the position of the circuit-breaker it is installed in varies;
- a non-cabled S51 auxiliary contact, which can be used for XT2 and XT4 circuit-breakers;
- a cabled auxiliary contact, with non numerates cables. Changing the placement in circuit-breaker, it's possible to obtain different signals (Q or SY).

Combinations of cabled auxiliary contacts with cables numbered	XT1 3/4p	XT2 3/4p	XT3 3/4p	XT4 3/4p
1Q 1SY 24V DC	F-P	F-P-W	F-P	F-P-W
3Q 1SY 24V DC	–	F-P-W	F-P	F-P-W
1S51 24V DC	–	F-P-W	–	F-P-W
1Q 1SY 250V AC/DC	F-P	F-P-W	F-P	F-P-W
2Q 2SY 1S51 250V AC/DC	–	F-P-W	–	F-P-W
3Q 2SY 250V AC/DC	–	F-P-W	–	F-P-W
3Q 1SY 250V AC/DC	–	F-P-W	F-P	F-P-W
1S51 250V AC/DC	–	F-P-W	–	F-P-W
2Q 1SY 250V AC/DC	F-P	F-P	F-P	F-P
3Q on the left 250V AC/DC	F-P	F-P	F-P	F-P

F = Fixed, P = Plug-in, W = Withdrawable

Auxiliary contacts 24V DC - 250V AC/DC

	Circuit-breaker 3p	Circuit-breaker 4p
XT1		
XT3		
XT2 XT4		

AUX 250V AC/DC - Electrical specifications

Power supply voltage	Operating current according to class of use(G2.16)					
	AC-15	AC-14	AC-13	DC-14	DC-13	DC-12
250 V AC	4 A	5 A	6 A	-	-	-
125 V AC	5 A	6 A	6 A	-	-	-
250 V DC	-	-	-	0.03 A	0.03 A	0.03 A
110 V DC	-	-	-	0.05 A	0.05 A	0.05 A

AUX 24V DC - Electrical specifications

Power supply Voltage	Operating current
5 V DC	0.001 A
30 V DC	0.1 A



Cabled auxiliary contact



Cabled auxiliary contact for withdrawable circuit-breaker

400V AC auxiliary contacts

400V AC auxiliary contacts are only available for XT2 and XT4 circuit-breakers in the following versions:

- cabled (AWG17 cable section -1mm²):
 - for fixed/plug-in circuit-breakers with 1m long cables;
 - for withdrawable circuit-breakers with fixed part and moving part connector.

The 400V auxiliary contacts take up the whole right-hand slot of the circuit-breaker.

Combinations	XT1	XT2	XT3	XT4
	3/4p	3/4p	3/4p	3/4p
1Q 1SY 400V	–	F-P-W	–	F-P-W
2Q 400V	–	F-P-W	–	F-P-W

F = Fixed, P = Plug-in, W = Withdrawable

Auxiliary contacts 400V AC

	Circuit-breaker 3p	Circuit-breaker 4p
XT2 XT4	AUX 400V	AUX 400V

AUX 400V AC - Electrical specifications

Power supply Voltage [V]	Operating current [A]	
	AC	DC
125 AC/DC	–	0.5
250 AC/DC	12	0.3
400 AC/DC	3	–

Accessories

Electrical Accessories



Auxiliary position contact

Auxiliary position contacts - AUP


These allow information about the position of the circuit-breaker in relation to the fixed part of plug-in or withdrawable versions to be routed outside the circuit-breaker itself.

Two types of position contact (AUP) are available, at 250V AC/DC and 24V AC/DC:

- racked-in contact for all plug-in and withdrawable SACE Tmax XT circuit-breakers, to be positioned in the fixed part;
- racked-out contact for all withdrawable SACE Tmax XT2 and XT4 circuit-breakers, to be installed in the side part of the withdrawable version.

For further details about the electrical specifications of the contacts, consult the “24V DC and 250V AC contacts” section of the Accessories chapter.


Circuit-breaker		N° racked-in contact	N° racked-out contact
XT1	3/4 poles	4	–
	3 poles	2	2
XT2	3 poles	4	–
	4 poles	4	2
XT3	3/4 poles	4	–
XT4	3/4 poles	4	2




Plug-in circuit-breaker with racked in contact



S57I=104



S75I=102



Withdrawable circuit-breaker with racked in - racked out contacts



S75I=102
S75E=144



S75I=102
S75E=142



S75I=104
S75E=142



Early auxiliary contacts
in the handle

Early auxiliary contacts - AUE

Early contacts in relation to **closing**: allow the undervoltage release to be supplied before the main contacts close, in accordance with the IEC 60204-1, VDE 0113 Standards.

Early contacts in relation to **opening**: allow any electronic devices connected to the system that could be damaged owing to overvoltages generated by the circuit-breaker opening operation to be disconnected in advance.

The early opening/closing auxiliary contacts can be installed inside the direct and transmitted rotary handle operating mechanisms for all the SACE Tmax XT family circuit-breakers (max two contacts @ 400V):

- in the cabled version with 1m long cables (AWG20 cable sections);
- a dedicated code is available in the withdrawable version which includes the connector for the moving part and fixed part;

For further details about the electrical specifications of the contacts, consult the “400V DC and 250V AC contacts” section of the Accessories chapter.

Motor operators


Devices that allow circuit-breaker opening and closing to be controlled:

- in the remote mode, by means of electric controls;
- locally directly from the front, by means of a special mechanisms.



Direct action motor
operator (MOD)

MOD direct action motor operator



The direct action motor control available for XT1 and XT3, is supplied:


- complete with 1m long cables;
- with flange, to replace the standard one supplied with the circuit-breaker;
- with padlock device, only removable when the motor is in the open position. The padlock device accepts up to three 8 mm padlocks;
- auxiliary contacts (AU-MO) which allow the motor control mode (manual or auto) signal to be routed outside;
- (on request) the motor operator can be fitted with a key lock (consult the “locks” section in the Accessories chapter).

Accessories

Electrical Accessories

Operating principles:

- a selector on the front of the MOD, is used for selecting the operating mode:
 - AUTO: when the selector is in this position, circuit-breaker closing can only take place remotely by means of an electric impulse, whereas opening is allowed both remotely and from the front of the motor;
 - MANUAL: when the selector is in this position, the circuit-breaker can only be opened/closed from the front of the motor by means of the relative lever housed in a slot made in the motor itself;
- operation of the motor operator via remote control is also guaranteed by permanent electrical opening/closing impulses;
- the resetting modes shown in the diagrams below depend on the reset wiring diagram chosen by the customer (consult the reset wiring diagrams in the “Electric Diagrams”) chapter.



Stored energy motor operators (MOE)

Stored energy motor operators - MOE and MOE-E



The MOE or MOE-E stored energy motor operator available for XT2 and XT4 is supplied:


- complete with 1m long cables;
- complete with connector for the fixed part and moving part of withdrawable devices. If the motor operator is used with fixed or plug-in circuit-breakers, the connector can be easily removed;
- with flange, to use instead of the standard one supplied with the circuit-breaker;
- with padlock device, only removable when the motor is in the open position. The padlock device accepts up to three 8mm padlocks;
- with lock of the AUTO-MANUAL selector;
- with auxiliary contacts (AUX-MO) that allow the motor's control mode (manual or remote) signal

- to be routed outside;
- (on request) the motor operator can be equipped with key lock (consult the “locks” section in the Accessories chapter);
- (on request) the motor operator can be equipped with lock to safeguard against manual operation MOL-M (consult the “locks” section in the Accessories chapter).

Operating principles:


- a selector on the front of the MOE, is used for selecting the operating mode:
 - AUTO: when the selector is in this position, the pushbuttons on the front of the motor are locked. Circuit-breaker closing can only take place remotely by means of an electric impulse, whereas opening is allowed both remotely and from the front of the motor;
 - MANUAL: the circuit-breaker can only be opened/closed from the front of the motor using the relative pushbuttons;
 - LOCKED: when the selector is in this position, the circuit-breaker is in the open position. The padlock device can be withdrawn and the motor locked in the open position;
- operation of the motor operator via remote control is also guaranteed by permanent electrical opening/closing impulses. Once an opening command has been given, the next closing command (permanent) is taken over by the motor operator once opening has been completed. In the same way, an opening command is taken over once the previous closing operation has been completed;
- the resetting modes shown in the diagrams below depend on the reset wiring diagram chosen by the customer (consult the reset wiring diagrams in the “Electric Diagrams”) chapter.

When Ekip Com module is used, motor operator MOE-E can be used instead of motor operator MOE. MOE-E allows the digital signals from the supervision and monitoring system to be used by means of the release and Ekip Com contacts and to be converted into power signals for operating the motor operator. All the features described above for the MOE motor operator are also valid for the MOE-E version.



Accessories

Electrical Accessories



Changeover of auxiliary contacts Q (open/closed), SY (Relay tripped) and S51 (trip unit tripping)

Circuit-breaker with MOE (MANUAL Mode)

Normal sequence	CB Closed	Q=14	SY=96	S51=06
	By pressing the Red pushbutton, the CB trips	Q=12	SY=98	S51=06
	Charging the springs, CB opens	Q=12	SY=96	S51=06
	By pressing the Green pushbutton, the CB Closes	Q=14	SY=96	S51=06
Trip Sequence (trip caused by: - SOR, - UVR, - Trip Test)	CB Closed	Q=14	SY=96	S51=06
	CB trips	Q=12	SY=98	S51=06
	Charging the springs, CB opens	Q=12	SY=96	S51=06
	By pressing the Green pushbutton, the CB Closes	Q=14	SY=96	S51=06
Trip Sequence (trip caused by trip unit)	CB Closed	Q=14	SY=96	S51=06
	CB trips	Q=12	SY=98	S51=08
	Charging the springs, CB opens	Q=12	SY=96	S51=06
	By pressing the Green pushbutton, the CB Closes	Q=14	SY=96	S51=06

Circuit-breaker with MOE (AUTO Mode)

Normal sequence	CB Closed	Q=14	SY=96	S51=06
	By pressing the Opening pushbutton remotely, the CB opens	Q=12	SY=98	S51=06
	By pressing the Closing pushbutton remotely, the CB Closes	Q=14	SY=96	S51=06
Trip Sequence (trip caused by: - SOR, - UVR, - Trip Test)	CB Closed	Q=14	SY=96	S51=06
	CB trips	Q=12	SY=98	S51=06
	By pressing the Opening pushbutton remotely, the CB opens	Q=12	SY=96	S51=06
	By pressing the Closing pushbutton remotely, the CB Closes	Q=14	SY=96	S51=06
Trip Sequence (trip caused by trip unit)	CB Closed	Q=14	SY=96	S51=06
	CB trips	Q=12	SY=98	S51=08
	By pressing the Opening pushbutton remotely, the CB opens	Q=12	SY=96	S51=06
	By pressing the Closing pushbutton remotely, the CB Closes	Q=14	SY=96	S51=06

Electrical specifications		MOD		MOE and MOE-E	
Rated voltage, Un	[V]	–	24 DC	–	24 DC
	[V]	–	48...60 DC	–	48...60 DC
	[V]	110...125 AC	110...125 DC	110...125 AC	110...125 DC
	[V]	220...250 AC	220...250 DC	220...250 AC	220...250 DC
	[V]	380...440 AC	–	380...440 AC	–
	[V]	480...525 AC	–	480...525 AC	–
Operating Voltage	[% Un]	MIN=85% Un; MAX=110% Un			
Power absorbed on inrush Ps	[VA - W]	≤ 500	≤ 500	≤ 300	≤ 300
Power absorbed in Pc service	[VA - W]	≤ 300	≤ 300	≤ 150	≤ 150
Operating frequency	[Hz]	50..60		50..60	
Duration ⁽¹⁾	CL → OP [s]	< 0.1		< 1.5	
	OP → CL [s]	< 0.1		< 0.1	
	TR → OP [s]	< 0.1		< 3	
Mechanical life	[N° operations]	25000		25000	
Minimum duration of electrical opening and closing command	[ms]	≥ 150		≥ 150	

⁽¹⁾ Total time, from transmission of impulse to opening/closing of circuit-breaker

Connectors for electrical accessories

Plug-in circuit-breaker

In the plug-in version of SACE Tmax XT circuit-breakers, the auxiliary circuits can be disconnected by means of two different types of adapter:

- plug and socket adapter to be fixed on the bottom of the panel: for XT1, XT2, XT3, XT4;
- plug and socket adapter installed on the rear of the circuit-breaker and in the fixed part of plug-in devices: for XT2, XT4.



Plug and socket adapters on the back of the panel

Plug and socket adapters on the back of the panel

To make it easier to connect/disconnect auxiliary circuits, wired electrical accessories can be connected to one or more plug and socket connectors to be installed on the back of the panel.

3, 6, 9 and 15 PIN connectors are available. The cables connect/disconnect to and from the connector in a fast and simple way without the aid of any dedicated tools.

Consider the number of cables of each electrical accessory when calculating the number of connectors required.

Accessory	Number of cables
SOR, PS-SOR, UVR, External Neutral, PTC	2
SA, 1 AUX	3
Auxiliary power supply 24V DC, AUE, PR212CI	4
MOE-E	5
Ekip Com, Residual current	6
MOE (with AUX-MO), MOD (with AUX-MO)	7

Plug and socket adapters installed on the rear of the circuit-breaker and in the fixed part

Only for the plug-in versions of Tmax XT2 and XT4 circuit-breakers, the auxiliary circuits can be automatically disconnected by means of an adapter installed on the rear of the circuit-breaker and in the fixed part of plug-in versions.

The 12 PIN connector can only be used with accessories that function at a voltage of not more than 250V AC/DC. The cables are connected to /disconnected from the connector in a fast and simple way without the aid of any dedicated tools. Wiring is to be carried out by the Customer.



Plugged and socket adaptor placed on the back moving part



Plug and socket adaptor in the fixed part



Cabling of withdrawable version

Withdrawable circuit-breaker

When withdrawable circuit-breakers are used, the codes of the electrical accessories specifically designed for this version must be ordered. These dedicated codes contain the wired electrical accessory with connector for the moving part and for the fixed part to be inserted in the side of the fixed part. If the MOE motor operator is ordered, connectors for the fixed part and moving part are always supplied since there is no dedicated code for the withdrawable version.

The connectors of electrical accessories for withdrawable circuit-breakers must all be installed on the right side of the circuit-breaker in housings made in the side of the fixed part.

This type of connection allows the auxiliary circuits to be disconnected automatically when the circuit-breaker is withdrawn from the fixed part.

If the Customer wants to wire the fixed part in advance of the moving part, the fixed part mounting connectors can be ordered as spare parts.

Accessories

Electrical Accessories

Residual current releases

Both circuit-breakers and switch-disconnectors are pre-engineered for assembly combined with residual current releases.

Residual current circuit-breakers derived from the circuit-breaker are known as “mixed”, meaning that, besides protection against the typical overloads and short-circuits of circuit-breakers, they also provide protection for people and against earth fault currents, thus protecting against direct, indirect contacts and the risk of fires.

Residual current circuit-breakers derived from the switch-disconnector are “pure” residual current circuit-breakers, i.e. they only provide residual current protection and not the protections typical of circuit-breakers. “Pures” residual current circuit-breakers are only sensitive to earth fault current and are generally used as main switches in small panels for distribution to end users.

Use of “pure” and “mixed” residual current circuit-breakers allows the insulation state of the installation to be continuously monitored. It ensures efficient protection against the risks of fires and explosions and, in the case that detect fault at $I_{\Delta n} < 30\text{mA}$ devices, also protects people against indirect and direct contacts, thereby integrating the compulsory measures established by the accident prevention standards and regulations.

The residual current releases comply with the following Standards:

- IEC 60947-2 annex B;
- IEC 61000: for protection against unwarranted tripping.

The table gives all the residual current devices which can be used with the Tmax XT family of circuit-breakers:

	XT1		XT2		XT3		XT4	
	3p	4p	3p	4p	3p	4p	3p	4p
RC Inst	F	F			F	F		
RC Sel XT1-XT3	F	F			F	F		
RC Sel 200		F						
Rc Sel XT2-XT4				F-P-W				F-P-W
RC B type						F		


F = Fixed, P = Plug-in, W = Withdrawable

All Tmax XT residual current devices:


- feature microprocessor technology and act directly on the circuit-breaker by means of a dedicated opening solenoid (supplied with the residual current release and also available as a spare part) which must be housed in the relative slot formed in the third pole are to the left of the operating lever;
- do not need an auxiliary supply as they are powered directly from the mains;
- can be supplied either from above or below;
- functionality is guaranteed even with a single phase plus neutral or just two live phases and in the presence of pulsating unidirectional currents with direct components (minimum auxiliary voltage PHASE-NEUTRAL 85 Vrms);
- all possible connection combinations are permitted, as long as the neutral connection to the first pole on the left in the four-pole version is guaranteed.

RC Sel 200 residual current releases (type A) XT1

Thanks to its low height, the RC Sel 200 residual current release can be installed in 200mm modules. Moreover, its special shape reduces the overall size of the installation if two or more units are to be installed side by side.




RC Inst residual current releases for XT1 and XT3



Accessories


Electrical Accessories

RC Sel residual current releases (type A) for XT1 and XT3



With RC Inst and RC Sel residual current release for XT1 - XT3, available only in Fixed version, it is possible to have rear terminal connection, ordering RC Rear terminals 4p kits.

RC Sel residual current releases (type A) for XT2 and XT4




The fixed version of the RC Sel residual current release can easily be converted:

- into the plug-in type:
 - by ordering the kit for converting the residual current release from the fixed to the plug-in version.
- into the withdrawable type:
 - by ordering the kit for converting the residual current release from the plug-in to the withdrawable version. This kit contains the shunt opening release of the withdrawable residual current device to replace the shunt opening release supplied with the fixed version. The shunt opening release of the withdrawable residual current device contains both the connector for the moving part and the connector for the fixed part.

With the RC Sel residual current release for XT2-XT4, it is possible to use the same terminals usable for the fixed circuit-breaker and for the fixed parts of plug-in and withdrawable circuit-breakers.

Whitdrawable and plug-in versions frame 160A with RC can be used up to a maximum current of 135A, whereas frame 250A can be used up to 210A.

RC B Type residual current release (type B) for XT3



The RC B Type residual current release, to be used in conjunction with the XT3 circuit-breaker, has the following features:

- it complies with type B operation, which guarantees sensitivity to residual fault currents with alternating, pulsating alternating and direct current components (IEC 60947-1, IEC 60947-2 Annex B, IEC 60755);
- the maximum frequency band of the residual fault current can be selected (3 steps: 400 - 700 - 1000Hz). The residual current device can therefore be adapted to suit various industrial installation requirements according to the prospective fault frequencies generated on the load side of the release. Typical installations that may require different frequency thresholds from the standard ones (50 - 60Hz) are welding systems for the automobile industry (1000Hz), the textile industry (700Hz), airports and three-phase drives (400Hz).

Accessories

Electrical Accessories

Electrical characteristic	Residual current devices				
	RC Sel 200mm XT1	RC Inst XT1-XT3	RC Sel XT1-XT3	RC Sel XT2-XT4	RC B Type XT3
Primary power supply Voltage [V]	85...690	85...690	85...690	85...690	110...500
Operating frequency [Hz]	45...66	45...66	45...66	45...66	45...66
Fault frequency [Hz]	50-60	50-60	50-60	50-60	400-700-1000
Test operating range [V]	85...690	85...690	85...690	85...690	110...500
Rated operating current [A]	up to 160	XT1 up to 160 XT3 up to 250	up to 160 XT1 up to 250 XT3	up to 160 XT2 ⁽²⁾ up to 250 XT4 ⁽²⁾	up to 225
Adjustable trip thresholds [A]	0.03-0.05-0.1-0.3 0.5-1-3-5-10	0.03-0.1-0.3 0.5-1-3	0.03-0.05-0.1-0.3 0.5-1-3-5-10	0.03-0.05-0.1-0.3 0.5-1-3-5-10	0.03-0.05-0.1 0.3-0.5-1
Selective type S	■	—	■	■	■
Adjustable NON-trip time settings [s] at 2xI _{Δn}	instantaneous 0.1-0.2-0.3- 0.5-1-2-3	instantaneous	instantaneous 0.1-0.2-0.3- 0.5-1-2-3	instantaneous 0.1-0.2-0.3- 0.5-1-2-3	instantaneous 0-0.1-0.2-0.3- 0.5-1-2-3
Power input	<5 W at 690V AC	<5 W at 690V AC	<5 W at 690V AC	<5 W at 690V AC	<10 W at 500V AC
Trip Coil with switch contact for trip signal	■	■	■	■	■
Input for remote controlled opening command	■	—	■	■	■
NO contact for pre-alarm signal	■	—	■	■	■
NO contact for alarm signal	■	—	■	■	■
Prealarm indication from 25% I _{Δn} . Steady yellow Led light	■	—	■	■	■
Alarm timing indication at 75% I _{Δn} . Flashing yellow Led light ⁽¹⁾	■	—	■	■	■
Type A for pulsating alternating current, Type AC for alternating current	■	■	■	■	■
Type B for pulsating current and direct current	—	—	—	—	■

⁽¹⁾ indication of alarm timing at 90% I_{Δn} for 30mA

⁽²⁾ plug in and withdrawable version: the 160 frame can be used with a max I_n = 135A
the 250 frame can be used with a max I_n = 210A



Toroid

SACE RCQ020/A panel type residual current release (type A)

Tmax circuit-breakers can also be used in conjunction with RCQ020 panel type residual current relays with separate toroid to be installed on the line conductors ("A" letter show the necessity to have on auxiliary power supply).

Thanks to its wide range of settings, the panel relay is suitable for:

- applications where the installation conditions are particularly restrictive, such as circuit-breakers already installed or limited space in the circuit-breaker compartment;
- creating a residual current protection system coordinated at various distribution levels, from the main switchboard to the end user;
- where residual current protection with low sensitivity is required, e.g. in partial (current) or total (time) selective chains;
- highly sensitive applications (physiological sensitivity) for protecting people against direct contacts.

Thanks to the 115-230...415V external auxiliary power supply, the RCQ020 panel-type residual current device is able to detect current leakage from 30mA to 30A and to act with a trip time that can be adjusted from instantaneous to delayed by 5s. The opening mechanism is the indirect action type and acts on the circuit-breaker release mechanism by means of the shunt opening or undervoltage release of the circuit-breaker itself.

The opening command to the circuit-breaker (Trip delay) can be temporarily inhibited, and the circuit-breaker can be opened by remote control by means of the RCQ020 device.

The following equipment must be requested when ordering:

- the RCQ020 device;
- an opening coil (SOR) or an undervoltage release (UVR) of the circuit-breaker to be housed in the relative slot made in the left pole of the circuit-breaker itself;
- a closed toroid, that can be used for cables and busbars, chosen from amongst those available, with a diameter from 60mm to 185mm.

Signals available:

- LED to indicate the status of the residual current device (supplied or not supplied). RCQ020 is equipped with the positive safety function thanks to which the RCQ020 commands automatic circuit-breaker opening in the absence of auxiliary voltage;
- LED for signalling faults;
- LED for signalling tripping of the residual current device;
- pre-alarm/alarm/trip electrical signals.



RCQ020/A residual current release

Power supply Voltage	AC [V]	115-230...415
Operating frequency	[Hz]	45÷66Hz
Inrush current	@115V AC	500mA for 50ms
	@230V AC	150mA for 50ms
	@415V AC	100mA for 50ms
Power input at full rate		2 [VA] / 2 [W]
Trip threshold adjustment $I_{\Delta n}$	[A]	0.03-0.05-0.1-0.3-0.5-1-3-5-10-30
No trip time adjustment	[s]	instantaneous 0.1-0.2-0.3-0.5-0.7-1-2-3-5
Pre-alarm threshold	x $I_{\Delta n}$	25%
A type for pulsing alternate current		■

Signals

Device powered visual signalling		■
Visual signalling of device not functioning/ not configured		■
Visual signalling of residual current protection		■
Electrical alarm/pre-alarm signal		■
Electric trip signal		■

Controls

Remotely controlled opening command		■
Remotely controlled reset command		■

Operating range of closed transformers

Ø 60 [mm] toroidal transformer	[A]	In max = 250A Use 0.03..30A
Ø 110 [mm] toroidal transformer	[A]	In max = 400A Use 0.03..30A
Ø 185 [mm] toroidal transformer	[A]	In max = 800A Use 0.1..30A
Connection to toroidal transformer		By means of 4 shielded or twisted conductors. Maximum tolerated length: 15m
Dimensions W x H x D	[mm]	96 x 96 x 77
Drilling for assembly on door	[mm]	92 x 92
Standard		IEC 60947-2 annex M


Accessories

Accessories for electronic trip units

	Accessories for electronic trip units			
	Ekip Display	Ekip LED Meter	SACE PR212/CI	External neutral
Distribution protection				
Ekip LS/I	–	–	–	–
Ekip I	–	–	–	–
Ekip LSI	■	■	–	■
Ekip LSIG	■	■	–	■
Motor protection				
Ekip M-I	–	–	–	–
Ekip M-LIU	–	–	–	–
Ekip M-LRIU	■	■	■	–
Generator Protection				
Ekip G-LS/I	–	–	–	–
Oversized Neutral Protection				
Ekip N-LS/I	–	–	–	–
Energy measurement				
Ekip E-LSIG	■	■	–	■

Ekip Display

The Ekip Display is a unit which can be applied on the front of the solid-state trip unit and shows the current values, alarms and protection and communication parameter programming.




Main features:

- **installation:** Ekip Display can easily be installed on the front of the Ekip LSI, Ekip LSIG, Ekip M-LRIU and Ekip E-LSIG electronic trip units. It is connected by means of the test connector on the front of the trip unit, and fixing is simple and reliable thanks to a specially designed mechanism. This mechanism also provides a practical way of fastening the accessories to the circuit-breaker in order to prevent undesired access to the dip-switches. Installation can be carried out under any conditions, even with the door closed and the electronic trip unit already on and functioning;
- **functions:** Ekip Display has four buttons for browsing through the menus. It functions in the self-supply mode starting from a current of $I > 0.2 \times I_n$ circulating through at least one phase. Backlighting is activated in the presence of higher loads, thereby allowing a better legibility of visualized informations. The rear lighting comes on in self-supply for a current $I > 0.4 \times I_n$ and is always on when there is electronic trip unit auxiliary power supply.
Ekip Display:
 - shows the current, voltage, power and energy values;
 - shows the settings of the protection functions in Amperes or in I_n ;
 - shows the protection that caused the release to trip and the fault current (only when there is 24V external voltage or the Ekip TT unit);
 - allows the trip thresholds of the trip unit to be programmed and the communication parameters to be set on bus system;
- **compatibility:** Ekip Display can be fitted even when front accessories, such as the motor, direct and transmitted rotary handles etc. are already installed. It's possible to use Ekip TT or Ekip T&P without removing Ekip Display. It's not possible to use Ekip Display when the breaker is in the withdrawable version.

Ekip LED Meter

The Ekip LED Meter can be applied to the front of the electronic trip unit and displays the current values and alarms.



Main features:

- **installation:** Ekip LED Meter can be easily installed on the front of Ekip LSI, Ekip LSIG, Ekip M-LRIU and Ekip E-LSIG electronic trip units. It is connected by means of the test connector on the front of the release and fixing is simple and reliable thanks to a specially designed mechanism. This mechanism also provides a practical way of fastening the accessories to the circuit-breaker in order to prevent undesired access to the dip-switches. Installation can be carried out under any conditions, even with the door closed and the electronic trip unit already on and functioning;
- **functions:** Ekip LED Meter provides an accurate indication about the value of the current circulating in the trip unit. It does this by means of a scale of LED. Their different colours allow the normal operation, prealarm and alarm states of the circuit-breaker to be recognized at a glance. It functions in self-supply mode from a current of $I > 0.2 \times I_n$ circulating through at least one phase or when electronic trip unit's auxiliary power is available;
- **compatibility:** the Ekip LED Meter can also be fitted when front accessories, such as the motor, direct and transmitted rotary handles. It's possible to use Ekip TT or Ekip T&P without removing Ekip LED Meter. It's not possible to use Ekip LED Meter when the breaker is in the withdrawable version.

SACE PR212/CI contactor operator



PR212/CI is an interface device that allow Ekip M-LRIU to comand the contactor. The stand-by position normally corresponds to the opening position of the main contacts. PR212/CI can be used in conjunction with XT2-XT4 circuit-breakers equipped with the electronic trip unit for Ekip M-LRIU motor protection.

Main features:

- **installation:** PR212/CI can be installed both on a DIN rail and on the back of the door. It is connected to the electronic trip unit with a dedicated connector, which has to be ordered in relation to the circuit-breaker version;
- **functions:** when the release is set to "Normal Mode" the contactor can be opened if a fault occurs due to overload L, locked rotor R or phase failure/unbalance U.

Accessories

Accessories for electronic trip units

Current sensor for external neutral

The current sensor for external neutral is applied to the uninterrupted neutral conductor. It allows the reading of the neutral current for all the protection functions.

Main features:

- **installation:** the external neutral current sensor is available for XT2 and XT4 three-pole circuit-breakers in the fixed/plug-in and withdrawable version equipped with Ekip LSI, Ekip LSIg electronic trip unit. The sensor must be connected to the release with the specific connector, which must be ordered separately.

Connection accessories

Devices which allow the electronic trip unit to be connected to external plant units or components. The connectors are available for the circuit-breakers in fixed, plug-in and withdrawable version.

Name of connector	Trip Units
External neutral connector	Ekip LSI – Ekip LSIg – Ekip E-LSIg
Connector for PR212/CI	Ekip M-LRIU
Connector for 24V DC auxiliary power supply	Ekip LSI – Ekip LSIg – Ekip M-LRIU – Ekip E-LSIg
Connector for PTC	Ekip M-LRIU
Connector for external neutral voltage	Ekip E-LSIg

The connector for the auxiliary power supply is inserted inside the right-hand slot of the circuit-breaker, and occupies the space of two due auxiliary contacts. To check compatibility with the auxiliary contacts, consult the compatibility tables in the Accessories chapter.



Accessories

Communication devices and systems

Ekip Multimeter Display on front of switchboard

Ekip Multimeter is a display unit on the front of the switchboard, which is only usable with protection trip units fitted with one of the following accessories:

- Ekip Com
- Kit of 24V DC auxiliary voltage for electronic trip unit



Main features:

- **installation:** Ekip Multimeter can be easily fitted on the switchboard door. In situations where mechanical stress is particularly intense, it can also be installed by using the special clips supplied. The dimensions of the device are 96mmx96mm. It must be connected directly to the Ekip LSI, Ekip LSIg, Ekip M-LRIU or Ekip E-LSIG protection trip unit with “Ekip Com” or “kit of 24V DC auxiliary voltage for electronic trip unit” via the serial communication line. Ekip Multimeter can be powered either in direct current (24-48V DC or 110-240V DC) or in alternating current (110-240V AC). It is equipped with a 24V DC output that can supply the connected trip unit.

Power supply	24-48V DC, 110-240V AC/DC
Tolerance	21.5-53V DC, 105-265V AC/DC
Rated Power	8W


- **functions:** Ekip Multimeter is equipped with a large touch screen display and enables measurements to be displayed. This accessory allows you to view the following:
 - measurements of the connected trip unit
 - alarms/events of the trip unit
 - modify the protection threshold directly from the display.
- **communication:** Ekip Multimeter is provided with a Local Bus communication line. One device can be connected to each trip unit. Connecting Ekip LSI, Ekip LSIg, Ekip M-LRIU or Ekip E-LSIG to the local bus gives the possibility to connect the Modbus line of the Ekip Com module to a different communication network. Consult the “Electrical Diagrams” chapter for further details about wiring.

Accessories

Communication devices and systems

HMI030 interface on the front of the switchboard

HMI030 is an interface on the front of the switchboard only usable with protection trip units fitted with Ekip Com.



Main features:

- **installation:** HMI030 can be fitted into the hole in the door using the automatic click-in method. In situations where mechanical stress is particularly intense, it can also be installed by using the special clips supplied. It must be connected directly to the Ekip LSI, Ekip LSIg, Ekip M-LRIU or Ekip E-LSIG protection trip unit with Ekip Com via the serial communication line. HMI030 requires a 24V DC power supply;
- **functions:** HMI030 consists of a graphic display and 4 buttons for browsing through the menus. This accessory allows you to view:
 - the measurements taken by the release to which it is connected;
 - the alarms/events of the release.Thanks to its high level of accuracy, the same as that of the trip unit protection, the device is a valid substitute for conventional instruments without any additional current transformers.
- **communication:** HMI030 is provided with two communication lines, to be used in alternative:
 - Modbus
 - Local Bus.Connecting Ekip LSI, Ekip LSIg, Ekip M-LRIU or Ekip E-LSIG to the Local Bus gives the possibility to connect the Modbus line of the Ekip Com module to a different communication network. Consult the Electrical Diagrams Chapter for further details about wiring.

Ekip Com

Ekip Com allows the MOE-E motor operator to be controlled, to determine the ON/OFF/TRIP state of the circuit-breaker and to connect the electronic trip unit to a Modbus communication line.

Ekip Com is available in two versions: one version for the circuit-breakers in the fixed/plug-in version and a version complete with connector for the fixed part and the moving part for circuit-breakers in the withdrawable version.

Main characteristics:

- **installation:** the Ekip Com module is inserted in the right-hand slot of the circuit-breaker and fixing is carried out without any need for screws or tools.
Connection to the trip unit is made using the special small cable which, for greater practicality and safety, is fitted with a cable guide. The connection towards the Modbus line is made by means of the terminal box to which a 24V DC auxiliary power supply must also be connected, which activates both the module and the protection trip unit;
- **functions:** the Ekip Com module offers the possibility of acquiring the state of the circuit-breaker remotely and, in combination with the MOE-E motor operator, allows it to be opened and closed. If combined with a trip unit fitted with communication (Ekip LSI, Ekip E, Ekip LSIg or Ekip M-LRIU), the Ekip Com module allows the trip unit to be connected to a Modbus network, offering the possibility of programming the protections and acquiring the measurements and alarms when it is connected to a control and/or supervision system. When it is connected to the HMI030 unit, it is possible to have these data locally on the front of the switchboard.

For further details on the communication systems which can be made by means of the Ekip Com module, refer to the “Communication Systems” paragraph in the “Ranges” chapter.




Ekip Com

Communication devices and systems

Ekip Connect

Installation and diagnosis software for ABB SACE products with Modbus RTU communication. The software can be used during the commissioning stage, or for troubleshooting in an up and running communication network.



Ekip Connect automatically scans the RS-485 bus, detects all the devices connected and checks their configuration, checking all the possible address, parity and baud rate combinations. A simple click over SCAN will highlight:

- devices that fail to respond;
- configuration errors;
- incorrect addresses and parity;
- any wiring errors (with the SACE electronic trip unit);

thus achieving a complete diagnosis of the communication network.

Thanks to this friendly program, the Modbus communication network installation is very easy. Ekip Connect is distributed free of charge and can be downloaded from the BOL web site (<http://bol.it.abb.com>).

Accessories

Test and configuration accessories



Ekip T&P

Ekip T&P

Ekip T&P is a kit purpose studied to supervise, configure and testing electronic protection trip units.

The kit is composed by:

- Ekip T&P unit;
- Ekip TT unit;
- Adaptors for Emax and Tmax trip units;
- USB cable for connecting the Ekip T&P unit to the electronic trip unit;
- CD for installing Ekip Connect and the Ekip T&P driver.


The Ekip T&P unit is connected on one side to the USB port of its own PC and on the other, by means of a cable provided, to the protection trip unit of the SACE Tmax XT series.

The Ekip T&P unit allows automatic, manual test and the trip test of the device it is connected to. These functions are managed by means of the Ekip T&P Interface which can only be activated directly by the Ekip Connect when the Ekip T&P is present and connected to the PC.

Accessories

Test and configuration accessories

Ekip TT



The Ekip TT accessory is supplied with a special connector which makes connection between the electronic trip unit and the Ekip TT unit easier. The kit also include san adaptor which allows use of the Ekip TT unit with the current Tmax breakers.

Ekip TT is a device which allows:

- verify the correct functioning of the electronic trip unit's opening solenoid and the trip mechanism of circuit-breaker (trip test);
- testing of the LEDs on the electronic trip unit it is connected to;
- (in case of intervention by electronic trip unit) to supply the trip unit powered by auxiliary power to show the latest intervened protection. Simply linking Ekip TT to the electronic trip unit (or to the Ekip display or to the Ekip LED Meter), the LED light on the latest protection intervened.

Its reduced dimension make it pocket size.

	Ekip T&P functions						Ekip TT functions		
	Trip Test	Protection function test	Parameter reading	Protection parameter programming	Communication parameter programming	Thermal memory enabling/disabling	Trip test	LED test	Latest trip detection
Distribution protection									
Ekip LS/I	■	■	■	–	–	■	■	■	■
Ekip I	■	■	■	–	–	–	■	■	■
Ekip LSI	■	■	■	■	■	■	■	■	■
Ekip LSIG	■	■	■	■	■	■	■	■	■
Ekip E-LSIG	■	■	■	■	■	–	■	■	■
Motor Protection									
Ekip M-I	–	–	–	–	–	–	■	■	■
Ekip M-LIU	■	■	■	–	–	–	■	■	■
Ekip M-LRIU	■	■	■	■	■	–	■	■	■
Generator Protection									
Ekip G-LS/I	■	■	■	–	–	■	■	■	■
Oversized Neutral Protection									
Ekip N-LS/I	■	■	■	–	–	■	■	■	■

Accessories

Automatic network-generator transfer unit ATS021-ATS022



ATS021



ATS022

The ATS (Automatic Transfer Switch) is the network-generator transfer unit used in installations where switching the main power line to an emergency one is required, to ensure power supply to the loads in the case of anomalies in the main line.

The unit is able to manage the entire transfer procedure automatically, and prepares the commands for carrying out the procedure manually as well.

In the case of an anomaly in the main line voltage, in accordance with the parameters set by the user, the opening of the circuit-breaker of the main line, the starting of the generator set (when provided) and the closing of the emergency line are performed. In the same way, in the case of the main line returning, the procedure of reverse transfer is controlled automatically.

The new generation of ATS (ATS021 and ATS022) offers the most advanced and complete solutions to guarantee service continuity. The ATS021 and ATS022 can be used both with all the circuit-breakers in the SACE Tmax XT family and with the switch-disconnectors.

The ATS021 and ATS022 devices have been designed to operate with self-supply. The ATS022 unit also prepares the connection for auxiliary power supply, which allows additional functions to be used.

The ATS021 and ATS022 devices carry out control of both the power supply lines and analyse:

- phase unbalance;
- frequency unbalance;
- phase loss.

Apart from the standard control functions, with the ATS022 unit, the following is possible:

- selecting the priority line;
- controlling a third circuit-breaker;
- incorporating the device in a supervision system with Modbus communication (auxiliary power supply is needed);
- reading and setting the parameters, and displaying the measurements and alarms, by means of a graphic display.

Typical applications for use are: power supply to UPS (Uninterrupted Power Supply) units, operating rooms and primary hospital services, emergency power supply for civil buildings, airports, hotels, data banks and telecommunication systems, power supply of industrial lines for continuous processes.

For correct configuration, each circuit-breaker connected to the ATS021 or ATS022 must be fitted with the following accessories:

- mechanical interlock;
- motorised control of opening and closing;
- key lock against just manual operation for the motor operator;
- contact for signalling the state (open/closed) and contact for tripped;
- contact for racked-in (in the case of a withdrawable version circuit-breaker).

Accessories

Automatic network-generator transfer unit ATS021-ATS022

	ATS021	ATS022
General		
Auxiliary Power Supply	Not Required	Not Required (24-110 Vdc is required only for Modbus dialogue and 16 2/3 Hz system)
Rated Voltage, Un [VAC]	Max 480	Max 480
Frequency [Hz]	50, 60	16 2/3, 50, 60, 400
Dimensions (HxLxD) [mm]	96x144x170	96x144x170
Type of installation	Door mounting	Door mounting
	DIN-rail mounting	DIN-rail mounting
Operating Mode	Auto/Manual	Auto/Manual
Features		
Monitoring of the Normal and Emergency lines	■	■
Controlling CBs of the Normal and Emergency lines	■	■
Generator set startup	■	■
Generator set shutdown with adjustable delay	■	■
Bus-tie	-	■
No-priority Line	-	■
Modbus RS485	-	■
Display	-	■
Ambient conditions		
Operating temperature	-20...+60 °C	-20...+60 °C
Humidity	5% - 90% without condensation	5% - 90% without condensation
Operating thresholds		
Minimum voltage	-30%...-5%Un	-30%...-5%Un
Maximum voltage	+5%...+30%Un	+5%...+30%Un
Fixed frequency thresholds	-10%...+10%fn	-10%...+10%fn
Test		
Test Mode	■	■
Compliance with standards		
Electronic equipment for use in power installations	EN-IEC 50178	EN-IEC 50178
Electromagnetic compatibility	EN 50081-2	EN 50081-2
	EN 50082-2	EN 50082-2
Environmental conditions	IEC 68-2-1	IEC 68-2-1
	IEC 68-2-2	IEC 68-2-2
	IEC 68-2-3	IEC 68-2-3

Accessories

Compatibility of accessories


Check whether the different devices are compatible/incompatible with each other when ordering accessories. The following table allow provides a simple check of the compatibility between:

- mechanical accessories, accessories for electronic trip units, motors and residual current devices;
- internal electrical accessories.

To understand the abbreviations used to identify the accessories more easily, refer to the “Symbols” paragraph in chapter 8, “Glossary”.



Three-pole circuit-breaker



Four-pole circuit-breaker

Example of reading the compatibility tables

Fixed/plug-in circuit-breaker compatibility XT1-XT3

	SOR 3p	UVR 3p	PS-SOR 3p	3Q 3p	SA 3p	SOR 4p	UVR 4p	
SOR 3p							✓	
UVR 3p ¹	→ 2	→ 3	→ 4	→ 5	→ 6	→ 7	→ 8	
PS-SOR 3p						✓	✓	
3Q sx 3p						✓	✓	
SA 3p						✓	✓	
SOR 4p	✓	✓	✓	✓	✓		✓	
UVR 4p	✓	✓	✓	✓	✓	✓		
.....								

The **UVR** positioned in the slot of the **3rd pole⁽¹⁾** is:

- incompatible with the SOR positioned in the 3rd pole⁽²⁾;
- incompatible with the UVR positioned in the 3rd pole⁽³⁾;
- incompatible with the PS-SOR positioned in the 3rd pole⁽⁴⁾;
- incompatible with the 3Q contacts on the left in the 3rd pole⁽⁵⁾;
- incompatible with the SA of the residual current device⁽⁶⁾;
- compatible with the SOR positioned in the slot of the 4th pole⁽⁷⁾;
- compatible with the UVR positioned in the slot of the 4th pole⁽⁸⁾;
-

Compatibility of mechanical accessories

	RHD	RHE	RHS	FLD	PLL on CB	KLC on CB	KLC on RHX	KLC on FLD	KLC on motor	MOD/ MOE/ MOE-E	Ekip Display	Ekip LED Meter	SOR/ PS-SOR/ UVR/SA/ 3Q sx 3p	1Q + 1SY	2Q + 1SY	3Q + 1SY
RHD						✓					✓	✓	✓	✓	✓	✓
RHE						✓					✓	✓	✓	✓	✓	✓
RHS											✓	✓	✓	✓	✓	✓
FLD								✓			✓	✓	✓	✓	✓	✓
PLL on CB											✓	✓	✓	✓	✓	✓
KLC on CB											✓	✓	✓	✓	✓	✓
KLC on RHX	✓	✓									✓	✓	✓	✓	✓	✓
KLC on FLD				✓							✓	✓	✓	✓	✓	✓
KLC on motor									✓		✓	✓	✓	✓	✓	✓
MOD/MOE/MOE-E									✓		✓	✓	✓	✓	✓ ⁽¹⁾	✓ ⁽²⁾
Ekip Display	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓			✓	✓	✓	✓
Ekip LED Meter	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓			✓	✓	✓	✓
SOR/PS-SOR/UVR/SA/3Q sx 3p	✓	✓	✓	✓	✓				✓	✓	✓	✓		✓	✓	✓
1Q + 1SY	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		✓	✓	✓
2Q + 1SY	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓ ⁽¹⁾	✓	✓				
3Q + 1SY	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓ ⁽²⁾	✓	✓	✓			

✓ Compatibility

⁽¹⁾ Not valid for XT1

⁽²⁾ Not valid for XT3

Accessories

Compatibility of accessories

Compatibility of electrical accessories

Fixed/plug-in circuit-breaker compatibility XT1-XT3

	SOR 3p	UVR 3p	PS-SOR 3p	3Q sx 3p	SA 3p	SOR 4p	UVR 4p	PS-SOR 4p	3Q sx 4p	1Q 1SY	2Q 1SY	3Q 1SY	KLC on CB	MOD
SOR 3p						✓	✓	✓	✓	✓	✓	✓		✓
UVR 3p						✓	✓	✓	✓	✓	✓	✓		✓
PS-SOR 3p						✓	✓	✓	✓	✓	✓	✓		✓
3Q sx 3p						✓	✓	✓	✓	✓	✓	✓		✓
SA 3p						✓	✓	✓	✓	✓	✓	✓		✓
SOR 4p	✓	✓	✓	✓	✓					✓	✓	✓	✓	✓
UVR 4p	✓	✓	✓	✓	✓					✓	✓	✓	✓	✓
PS-SOR 4p	✓	✓	✓	✓	✓					✓	✓	✓	✓	✓
3Q sx 4p	✓	✓	✓	✓	✓					✓	✓	✓	✓	✓
1Q 1SY	✓	✓	✓	✓	✓	✓	✓	✓	✓				✓	✓
2Q 1SY	✓	✓	✓	✓	✓	✓	✓	✓	✓				✓	✓ ⁽¹⁾
3Q 1SY	✓	✓	✓	✓	✓	✓	✓	✓	✓				✓	
KLC on CB						✓	✓	✓	✓	✓	✓	✓		
MOD	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓ ⁽¹⁾			

✓ Compatibility

⁽¹⁾ Not valid for XT1

Compatibility of electrical accessories

Fixed/plug-in circuit-breaker compatibility XT2-XT4

	SOR 3p	UVR 3p	PS- SOR 3p	3Q sx 3p	SA	SOR 4p	UVR 4p	PS- SOR 4p	3Q sx 4p	S51	1Q 1SY	2Q 1SY	3Q SY	3Q 2SY	2Q 2SY 1S51	400V 2Q	400V 1Q 1SY	24V	Ekip Com	KLC on CB	MOE/ MOE-E
SOR 3p						✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		✓
UVR 3p						✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		✓
PS-SOR 3p						✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		✓
3Q sx 3p						✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		✓
SA						✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		✓
SOR 4p	✓	✓	✓	✓	✓					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
UVR 4p	✓	✓	✓	✓	✓					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
PS-SOR 4p	✓	✓	✓	✓	✓					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
3Q sx 4p	✓	✓	✓	✓	✓					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
S51	✓	✓	✓	✓	✓	✓	✓	✓	✓		✓	✓						✓	✓	✓	✓
1Q 1SY	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓								✓		✓	✓
2Q 1SY	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓										✓	✓
3Q 1SY	✓	✓	✓	✓	✓	✓	✓	✓	✓											✓	✓
3Q 2SY	✓	✓	✓	✓	✓	✓	✓	✓	✓											✓	✓
2Q 2SY 1S51	✓	✓	✓	✓	✓	✓	✓	✓	✓											✓	✓
400V 2Q	✓	✓	✓	✓	✓	✓	✓	✓	✓											✓	✓
400V 1Q 1SY	✓	✓	✓	✓	✓	✓	✓	✓	✓											✓	✓
24V	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓									✓	✓
Ekip Com	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓										✓	✓
KLC on CB						✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
MOE/MOE-E	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	

✓ Compatibility

Withdrawable circuit-breaker compatibility XT2-XT4

	S51	1Q 1SY	3Q 1SY	3Q 2SY	2Q 2SY S51	400V 2Q	400V 1Q 1SY	Ekip Com	24V	PR 212CI	NE	PTC	MOE	MOE -E	AUX- MOE	AUE	SOR 3p	UVR 3p	PS- SOR 3p	SA	SOR 4p	UVR 4p	PS- SOR 4p
S51		✓						✓	✓	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
1Q 1SY	✓								✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
3Q 1SY											✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
3Q 2SY													✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
2Q 2SY S51													✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
400V 2Q											✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
400V 1Q 1SY											✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Ekip Com	✓									✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
24V	✓	✓										✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
PR212CI	✓							✓			✓	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓
NE	✓	✓	✓			✓	✓	✓		✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
PTC		✓				✓	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
MOE	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓				✓ ⁽¹⁾	✓	✓	✓	✓	✓	✓	✓
MOE-E	✓	✓	✓	✓	✓	✓	✓	✓	✓		✓	✓				✓ ⁽¹⁾	✓	✓	✓	✓	✓	✓	✓
AUX-MOE	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓ ⁽¹⁾	✓ ⁽¹⁾			✓	✓	✓	✓			
AUE	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓					✓	✓	✓	✓	✓	✓	✓
SOR 3p	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓					✓	✓	✓
UVR 3p	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓					✓		✓
PS-SOR 3p	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓					✓	✓	✓
SA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓					✓	✓	✓
SOR 4p	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓			
UVR 4p	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓			
PS-SOR 4p	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓			

✓ Compatibility

⁽¹⁾ AUX-MOE always supplied with MOE and MOE-E



Characteristic Curves and Technical Information

Index

Characteristic Curves

Examples of Curve reading	4/2
---------------------------------	-----

Trip curves with thermomagnetic trip unit

Trip curves for distribution.....	4/4
Trip curves for motor protection.....	4/5
Trip curves for generator protection	4/8

Trip curves with electronic trip unit

Trip curves for distribution.....	4/9
Trip curves for motor protection.....	4/13
Trip curves for generator protection	4/16
Trip curves for oversized neutral protection	4/17

Specific let-through energy curves

240V	4/18
415V	4/19
440V	4/20
500V	4/21
690V	4/22

Limiting curves

240V	4/23
415V	4/24
440V	4/25
500V	4/26
690V	4/27


Technical Information

Temperature performances	4/28
Power losses	4/34
Magnetic trip values	4/35
Applications at 440 Hz	4/36

Examples of Curve reading


Example 1 – XT3N 250 Trip curves for distribution (thermomagnetic trip unit)

Let us consider an XT3N 250 TMD $I_n=250$ A circuit-breaker. According to the conditions the overload is found in, i.e. with the circuit-breaker at thermal regime or not, tripping of the thermal protection varies considerably. For example, for an overload current $3 \times I_n$, the trip time is between 107.9 s and 31.5 s for cold tripping and between 31.5 s and 7.0 s for hot tripping. For fault current values higher than 2500 A the circuit-breakers trips with the instantaneous magnetic protection I_3 .




Example 2 – XT2N 160 Specific let-through energy curves

The following figure shows an example of the graph of the specific let-through energy of the XT2N 160 $I_n=160$ A circuit-breaker at a voltage of 220/230 V. The prospective symmetrical short-circuit current is indicated on the abscissas, whereas the values of the specific let-through energy expressed in A^2s are shown on the ordinates. The circuit-breaker lets through a value of I^2t equal to $0.76 \cdot 10^6 \cdot A^2s$ in correspondence with a short-circuit current of 20 kA.



Example 3 – XT2N 160 Limitation curves

The figure below gives the trend of the Limitation curves of the XT2N 160 $I_n=160$ A circuit-breaker. The effective value of the prospective symmetrical short-circuit current is given on the abscissas of the diagram, whereas the peak value of the short-circuit current is indicated on the ordinates. The limiting effect can be evaluated by comparing the peak value corresponding to the prospective short-circuit current (curve A) with the peak limited value (curve B), at the same value of symmetrical short-circuit current. For a fault current of 20 kA, the XT2N 160 circuit-breaker with a thermomagnetic trip unit $I_n = 160$ A limits the peak prospective short-circuit current to 13.5 kA at a voltage of 500 V, with a reduction in relation to the peak value of the prospective short-circuit current of 36.5 kA.





Example 4 - XT4N 250 Ekip M-LIU

Cold trip / hot trip curves

The first curve gives indication of time of intervention of trip unit in case of fault in cold condition. Each curve is related to a single operating class defined by Standard IEC 60947-4-1 (3E, 5E, 10E or 10E). The second curve, hot trip, must be read in conjunction with the previous one. Given the time CB has been kept open after the first trip, t_{off} on the abscissas, t_{hot}/t_{cold} ratio can be identified on the ordinates. So, once cold trip time has been identified on the first chart in relation to a fault current, hot trip time can be calculated on the second chart, based on t_{off} and class of intervention.


For a XT4N 250 $I_n=200A$ under operating class 10E, given a fault current of $0.8kA$ ($4 \times I_n$), cold trip time for intervention is $7s$. If we consider a $t_{off} = 90s$, $t_{hot}/t_{cold} = 0.4$, so hot trip time for intervention is going to be $2.8s$.




Trip curves with thermomagnetic trip unit

Trip curves for distribution


XT1 160 TMD $I_n=16\ldots63\text{A}$




XT1 160 TMD $I_n=80\ldots160\text{A}$




XT2 160 TMA $I_n=1.6\ldots160\text{A}$



XT3 250 TMD $I_n=63\ldots250\text{A}$




XT4 250 TMA In=16...250A




Trip curves with thermomagnetic trip unit

Trip curves for motor protection


XT1 125 MA $I_n=3.2...6.3A$




XT1 125 MA $I_n=16...125A$




XT2 160 MF/MA $I_n=1...160A$



XT3 250 MA $I_n=100...250A$




XT4 200 MA $I_n=10\ldots 200\text{A}$




Trip curves with thermomagnetic trip unit

Trip curves for generator protection

XT2 160 TMG $I_n=16\ldots160A$




XT3 250 TMG $I_n=63\ldots250A$




Trip curves with electronic trip unit

Trip curves for distribution


XT2 Ekip LS/I L-I functions




XT2 Ekip LS/I L-S functions



XT2 Ekip I I function




XT2 Ekip LSI L-S-I functions




Trip curves with electronic trip unit

Trip curves for distribution


XT2 Ekip LSIG L-S-I functions




XT2 Ekip LSIG G function




XT4 Ekip LS/I L-I functions




XT4 Ekip LS/I L-S functions




XT4 Ekip I I function




XT4 Ekip LSI L-S-I functions



XT4 Ekip LSIG, Ekip E-LSIG L-S-I functions




XT4 Ekip LSIG, Ekip E-LSIG G function




Trip curves with electronic trip unit

Trip curves for distribution

XT4 Ekip E-LSIG OV protection




XT4 Ekip E-LSIG UV protection




Trip curves with electronic trip unit

Trip curves for motor protection


XT2 Ekip M-I I function




XT2-XT4 Ekip M-LIU L function (cold trip)



XT2-XT4 Ekip M-LIU (hot trip)




XT2-XT4 Ekip M-LIU I function



Trip curves with electronic trip unit

Trip curves for motor protection


XT2-XT4 Ekip M-LIU U function




XT2-XT4 Ekip M-LRIU L function (cold trip)

Hot trip*	3E	5E	10E	20E
Thermal memory reset time	200s	320s	600s	1200s


*ask ABB for additional details




XT2-XT4 Ekip M-LRIU I function



XT2-XT4 Ekip M-LRIU U function




XT2-XT4 Ekip M-LRIU R function




Trip curves with electronic trip unit

Trip curves for generator protection


XT2 Ekip G-LS/I L-I functions




XT2 Ekip G-LS/I L-S functions




XT4 Ekip G-LS/I L-I functions




XT4 Ekip G-LS/I L-S functions




XT2 Ekip N-LS/I L-I functions




XT2 Ekip N-LS/I L-S functions



XT4 Ekip N-LS/I L-I functions



XT4 Ekip N-LS/I L-S functions




Specific let-through energy curves

240V


XT1

240V




XT2

240V




XT3

240V



XT4


240V




Specific let-through energy curves

415V


XT1
415V




XT2
415V



XT3
415V



XT4
415V




Specific let-through energy curves

440V


XT1

440V




XT2

440V




XT3

440V



XT4

440V




Specific let-through energy curves

500V


XT1

500V




XT2

500V




XT3

500V



XT4

500V




Specific let-through energy curves

690V


XT1

690V




XT2

690V




XT3

690V



XT4


690V




Limiting curves

240V


XT1
240V




XT2
240V



XT3
240V



XT4
240V




Limiting curves

415V


XT1

415V




XT2

415V




XT3

415V



XT4


415V




Limiting curves

440V


XT1
440V




XT2
440V



XT3
440V



XT4
440V




Limiting curves

500V


XT1

500V




XT2

500V




XT3

500V



XT4


500V




Limiting curves

690V


XT1
690V




XT2
690V



XT3
690V



XT4
690V



Temperature performances

All the Tmax XT circuit-breakers can be used under the following environmental conditions:

- -25°C +70°C: range of atmospheric temperature where the circuit-breaker is installed;
- -40°C +70°C: range of atmospheric temperature where the circuit-breaker is stored.

The circuit-breakers fitted with thermomagnetic trip unit have the thermal element set for a reference temperature of +40°C. With the same setting, for temperatures other than +40°C there is a variation in the thermal trip threshold as indicated in the tables below.

XT1

T amb (°C)	10		20		30		40		45		50		60		70	
In [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]
16	13	18	12	18	11.9	17	11.2	16	10.8	15.5	11	15	10	14	9	13
20	16	23	15	22	14.7	21	14	20	13.6	19.4	13	19	12	18	11	16
25	20	29	19	28	18.2	26	17.5	25	16.9	24.2	16	23	15	22	14	20
32	26	37	25	35	23.8	34	22.4	32	21.7	31.0	21	30	20	28	18	26
40	32	46	31	44	29.4	42	28	40	27.1	38.7	27	38	25	35	23	33
50	40	58	39	55	37.1	53	35	50	33.9	48.4	33	47	31	44	28	41
63	51	72	49	69	46.2	66	44.1	63	42.7	61	41	59	39	55	36	51
80	64	92	62	88	58.8	84	56	80	54.2	77	53	75	49	70	46	65
100	81	115	77	110	73.5	105	70	100	67.8	97	66	94	61	88	57	81
125	101	144	96	125	91.7	131	87.5	125	84.7	121	82	117	77	109	71	102
160	129	184	123	176	117.6	168	112	160	108.4	155	105	150	98	140	91	130

XT2 with thermomagnetic trip units

T amb (°C)	10		20		30		40		45		50		60		70	
In [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]
1.6	1.3	1.8	1.2	1.8	1.2	1.7	1.1	1.6	1.1	1.5	1.1	1.5	1.0	1.4	0.9	1.3
2	1.6	2.3	1.5	2.2	1.5	2.2	1.4	2.0	1.3	1.9	1.3	1.9	1.2	1.7	1.1	1.6
2.5	2.0	2.9	1.9	2.8	1.8	2.6	1.8	2.5	1.7	2.4	1.6	2.3	1.5	2.2	1.4	2.0
3	2.5	3.6	2.5	3.5	2.5	3.5	2.1	3.0	2.0	2.9	2.0	2.8	1.8	2.6	1.6	2.3
4	3.2	4.6	3.1	4.4	2.9	4.2	2.8	4.0	2.7	3.9	2.6	3.7	2.5	3.5	2.2	3.2
5	4	5.7	3.9	5.5	3.7	5.3	3.5	5	3.4	4.8	3.3	4.7	3	4.3	2.8	4
6.3	5.0	7.2	4.9	6.9	4.6	6.6	4.4	6.3	4.2	6.1	4.1	5.9	3.9	5.5	3.6	5.1
8	6.4	9.2	6.2	8.8	5.9	8.4	5.6	8.0	5.4	7.7	5.3	7.5	4.9	7.0	4.6	6.5
10	8.1	11.5	7.7	11.0	7.4	10.5	7.0	10.0	6.7	9.6	6.5	9.3	6.1	8.7	5.7	8.1
12.5	10.1	14.4	9.7	13.8	9.2	13.2	8.8	12.5	8.4	12.0	8.2	11.7	7.6	10.9	7.1	10.1
16	13	18.0	12.0	18.0	11.9	17.0	11.2	16.0	10.8	15.4	10.5	15.0	9.8	14.0	9.1	13.0
20	16	23.0	15.4	22.0	14.7	21.0	14.0	20.0	13.5	19.3	13.3	19.0	11.9	17.0	11.2	16.0
25	20	29.0	19.6	28.0	18.2	26.0	17.5	25.0	16.8	24.0	16.1	23.0	15.4	22.0	14.0	20.0
32	26	37.0	24.5	35.0	23.8	34.0	22.4	32.0	21.6	30.8	21.0	30.0	19.6	28.0	18.2	26.0
40	32	46.0	30.8	44.0	29.4	42.0	28.0	40.0	27.0	38.5	25.9	37.0	24.5	35.0	22.4	32.0
50	40	57.0	38.5	55.0	37.1	53.0	35.0	50.0	33.7	48.2	32.9	47.0	30.1	43.0	28.0	40.0
63	50	72.0	48.3	69.0	46.2	66.0	44.1	63.0	42.5	60.7	41.3	59.0	38.5	55.0	35.7	51.0
80	64	92.0	61.6	88.0	58.8	84.0	56.0	80.0	54.0	77.1	52.5	75.0	49.0	70.0	45.5	65.0
100	81	115.0	77.0	110.0	73.5	105.0	70.0	100.0	67.5	96.4	65.1	93.0	60.9	87.0	56.7	81.0
125	101	144.0	96.6	138.0	92.4	132.0	87.5	125.0	84.3	120.5	81.9	117.0	76.3	109.0	70.7	101.0
160	129	184.0	123.0	178.0	117.6	168.0	112.0	160.0	107.9	154.2	105.0	150.0	97.3	139.0	90.3	129.0

XT3

T amb (°C)	10		20		30		40		45		50		60		70	
In [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]	MIN [A]	MAX [A]
63	51	72	49	69	46	66	44	63	43	61	41	59	39	55	36	51
80	64	92	62	88	59	84	56	80	54	77	53	75	48	69	45	64
100	80	115	77	110	74	105	70	100	68	97	65	93	61	87	56	80
125	101	144	96	138	92	132	88	125	85	121	81	116	76	108	70	100
160	129	184	123	176	118	168	112	160	108	155	104	149	97	139	90	129
200	161	230	154	220	148	211	140	200	136	194	130	186	121	173	113	161
250	201	287	193	278	184	263	175	250	169	242	163	233	151	216	141	201

XT4 with thermomagnetic trip units

T amb (°C)	10		20		30		40		45		50		60		70	
In [A]	MIN[A]	MAX [A]	MIN[A]	MAX [A]	MIN[A]	MAX [A]	MIN[A]	MAX [A]	MIN[A]	MAX [A]	MIN[A]	MAX [A]	MIN[A]	MAX [A]	MIN[A]	MAX [A]
16	13	19	13	18	12	17	11	16	11	15	10	14	9	13	8	12
20	19	27	17	24	16	23	14	20	14	19	12	17	11	15	9	13
25	21	30	20	28	19	27	18	25	17	24	16	23	15	21	13	19
32	26	43	24	39	25	36	22	32	22	31	19	27	17	24	15	21
40	33	48	32	45	30	43	28	40	27	39	26	37	24	34	21	30
50	37	62	35	58	38	54	35	50	34	48	32	46	29	42	27	39
63	53	75	50	71	47	67	44	63	43	61	41	58	37	53	33	48
80	59	98	55	92	60	86	56	80	54	77	52	74	46	66	41	58
100	83	118	79	113	74	106	70	100	68	97	67	95	60	85	53	75
125	102	145	100	140	94	134	88	125	85	121	81	115	74	105	67	95
160	130	185	123	176	118	168	112	160	108	155	105	150	96	137	91	130
200	161	230	154	220	147	210	140	200	136	194	133	190	123	175	112	160
225	188	269	179	255	168	241	158	225	152	218	146	208	133	190	119	170
250	200	285	193	275	183	262	175	250	169	242	168	240	161	230	154	220

The electronic overcurrent trip units do not undergo any variations in performance as the temperature varies.

However, even if heating does not affect the trip thresholds of the electronic trip units, in the case of temperatures exceeding +40°C it is advisable to reduce the maximum setting for protection against overloads (L) to preserve the copper parts of the circuit-breaker against high temperatures.

The same considerations can be done about the switch-disconnectors and magnetic only circuit-breakers.

The table and graph below show the maximum adjustment at which the threshold I_n of the overcurrent protection (L) must be set according to the ambient temperature and to the type of terminals used.

XT1 - Fixed circuit-breakers with only magnetic trip unit or switch-disconnectors

	40°C	50°C	60°C	70°C
	I _{max} [A]	I _{max} [A]	I _{max} [A]	I _{max} [A]
F-EF-ES-FCCu-R	160	160	153	140


F = Front flat terminals

EF = Extended front

ES = Extended spreaded

FCCu = Front for copper cables

R = Rear




Temperature performances

XT1 - Plug-in circuit-breakers with magnetic only trip unit or switch-disconnectors

	40°C	50°C	60°C	70°C
	I _{max} [A]	I _{max} [A]	I _{max} [A]	I _{max} [A]
EF-HR/VR	125	117	108	100

EF = Extended front

HR/VR = Rear horizontal/vertical




XT2 - Fixed circuit-breakers with only magnetic and electronic trip unit

	40°C	50°C	60°C	70°C
	I _{max} [A]	I _{max} [A]	I _{max} [A]	I _{max} [A]
F-FCCu	160	160	160	145

F = Front flat terminals


FCCu = Front for copper cables



XT2 - Plug-in/withdrawable circuit-breakers with electronic trip unit, magnetic only trip unit or switch-disconnectors

	40°C	50°C	60°C	70°C
	I _{max} [A]	I _{max} [A]	I _{max} [A]	I _{max} [A]
EF-HR/VR	160	160	160	146


EF = Extended front HR/VR = Rear horizontal/vertical



XT3 - Fixed circuit-breakers with only magnetic trip unit or switch-disconnectors

	40°C	50°C	60°C	70°C
	I _{max} [A]	I _{max} [A]	I _{max} [A]	I _{max} [A]
F-FCCu	250	250	228	204

F = Front flat terminals FCCu = Front for copper cables




Temperature performances

XT3 - Plug-in circuit-breakers with magnetic only trip unit or switch-disconnectors

	40°C	50°C	60°C	70°C
	I _{max} [A]	I _{max} [A]	I _{max} [A]	I _{max} [A]
EF-HR/VR	250	222	196	170

EF = Extended front terminals

HR/VR = Rear horizontal/vertical terminals




XT4 - Fixed circuit-breakers with only magnetic, electronic trip unit and switch-disconnector

	40°C	50°C	60°C	70°C
	I _{max} [A]	I _{max} [A]	I _{max} [A]	I _{max} [A]
F-FCCu	250	250	238	213

F = Front flat terminals


FCCu = Front for copper cables



XT4 - Plug-in/withdrawable circuit-breakers with electronic trip unit, magnetic only trip unit or switch-disconnectors

	40°C	50°C	60°C	70°C
	I _{max} [A]	I _{max} [A]	I _{max} [A]	I _{max} [A]
EF-HR/VR	250	231	211	190

EF = Extended front HR/VR = Rear horizontal/vertical



1SDC21068MF0001

Power losses

To ensure service continuity of the plants, how to keep the temperature within acceptable levels for operation of the various devices and not only for the circuit-breakers must be carefully assessed, for example with recourse to forced ventilation in the switchboards and in the rooms where they are installed.

The table gives the dissipated power values per single pole at the rated current I_n for each circuit-breaker used. The total maximum dissipated power for a circuit-breaker used at 50/60Hz is equal to the power per single pole multiplied by the number of poles.

Power [W/pole]	I_n [A]	XT1		XT2		XT3		XT4	
		F	P	F	P/W	F	P	F	P/W
TMD TMA TMG MF MA	1.6			2.00	2.40				
	2			2.40	2.80				
	2.5			2.50	2.80				
	3			2.80	3.20				
	4			2.50	2.80				
	6.3			3.30	3.90				
	8			2.60	3.00				
	10			2.90	3.40				
	12.5			1.00	1.20				
	16	1.50	1.60	1.30	1.50				
	20	1.80	2.00	1.60	1.90				
	25	2.00	2.80	2.00	2.5				
	32	2.10	3.20	2.60	3.00			2.50	2.60
	40	2.60	4.60	3.70	4.40			2.60	2.70
	50	3.70	5.00	4.10	4.00			2.70	2.80
	63	4.30	6.00	4.80	5.70	4.30	5.10	5.30	5.70
	80	4.80	7.20	5.80	6.80	4.80	5.80	5.50	2.40
	100	7.00	10.00	8.10	9.50	5.60	6.80	6.20	7.20
	125	10.70	14.70	11.40	14.00	6.60	7.90	7.40	9.00
	160	15.00		16.10	19.00	7.90	9.50	8.90	10.80
Ekip LS/I Ekip I Ekip LSI Ekip LSIG Ekip E-LSIG Ekip M-LRIU Ekip M-LIU Ekip N-LS/I Ekip G-LS/I	200					13.20	15.80	11.90	14.90
	250					17.80	21.40	16.40	21.10
	10			0.10	0.10				
	25			0.80	0.90				
	40							0.60	0.70
	63			1.70	2.10			1.40	1.80
	100			4.20	5.20			3.50	4.50
	160			10.80	13.40			8.90	11.50
	250							16.40	22.70

Magnetic Trip Values

Breaker	Trip Unit	I_n [A]	I_3 [A]	Single-phase trip current (% I_3) ⁽¹⁾
XT1	TMD	16..160	450..1600	150%
	MF/MA	1..160	14..2240	150%
	TMD/TMA	1.6..160	16..1600	150%
	TMG	16..160	160..480	150%
	Ekip I	10..160	1..10xI _n	100%
XT2	Ekip LS/I	10..160	1..10xI _n	100%
	Ekip LSI	10..160	1..10xI _n	100%
	Ekip LSIG	10..160	1..10xI _n	100%
	Ekip M-I	20..100	6..14xI _n	100%
	Ekip M-LIU	25..160	6..13xI _n	100%
	Ekip M-LRIU	25..100	6..13xI _n	100%
	Ekip G-LS/I	10..160	1..10xI _n	100%
	Ekip N-LS/I	10..100	1..10xI _n	100%
XT3	MA	100..200	600..2400	150%
	TMD	63..250	630..2500	150%
	TMG	63..250	400..750	150%
	MA	10..200	50..2000	150%
XT4	TMD/TMA	16..250	300..2500	150%
	Ekip I	40..250	1..10xI _n	100%
	Ekip LS/I	40..250	1..10xI _n	100%
	Ekip LSI	40..250	1..10xI _n	100%
	Ekip LSIG	40..250	1..10xI _n	100%
	Ekip M-LIU	40..160	6..13xI _n	100%
	Ekip M-LRIU	40..200	6..13xI _n	100%
	Ekip G-LS/I	40..250	1..10xI _n	100%
	Ekip N-LS/I	40..160	1..10xI _n	100%
	Ekip E-LSIG	40..250	1..10xI _n	100%

⁽¹⁾ Satisfies the requirements of the IEC 60947-2 Standard, section 8.3.3.1.2

Applications at 400Hz

The circuit-breakers used for power distribution can operate in alternating current at different frequencies from 50/60Hz (frequencies which the rated performance of the apparatus refers to) so long as the appropriate derating coefficients are applied.

At 400Hz, the performance of the circuit-breakers is reclassified so as to take the following phenomena into account:

- an increase in the skin effect and increased inductive reactance in a way that is directly proportional to the frequency, overheat the conductors or the copper components that normally carry the current in the circuit-breaker;
- lengthening of the hysteresis loop and reduction of the magnetic saturation value, which consequently varies the forces associated with the magnetic field to a given current value.

By and large, these phenomena influence the behaviour of both thermomagnetic trip units' thresholds and circuit breakers' current carrying capacity.

All the circuit-breakers in the SACE Tmax XT family equipped with thermomagnetic or electronic trip units (except for the Ekip M-I, Ekip M-LIU and Ekip M-LRIU trip units) can be used in 400Hz installations with deviation described below.

Trip thresholds of thermal components decrease as the frequency increases, due to reduced conductivity of the materials and to the increase of associated thermal phenomena.

Viceversa magnetic thresholds, I₃, increase in accordance to Km multiplication factor, due to induced magnetic fields. Circuit breakers with electronic trip units do not undergo any modification of trip thresholds, but maximum current carrying capacity of circuit breakers may be reduced.

Following tables refer to circuit breakers with a breaking capacity up to 36kA, 400 Hz plants are usually characterized by fairly low short-circuit currents.

XT1 160 - TMF/TMD 16÷100 A

XT1B 160 XT1C 160 XT1N 160	I1 (400Hz)				I3		
	In	MIN	MED	MAX	I3 (50Hz)	km	I3 (400Hz)
	16	10	12	14	450	2	900
	20	13	15	18	450	2	900
	25	16	20	23	450	2	900
	32	20	25	29	450	2	900
	40	25	31	36	450	2	900
	50	32	38	45	500	2	1000
	63	40	48	57	630	2	1260
	80	50	61	72	800	2	1600
	100	63	77	90	1000	2	2000

XT2 160 - TMD/TMA 1.6÷100 A

XT2N 160	I1 (400Hz)				I3		
	In	MIN	MED	MAX	I3 (50Hz)	km	I3 (400Hz)
	1,6	1	1,2	1,4	16	1,2	19,2
	2	1,3	1,5	1,8	20	1,2	24
	2,5	1,6	2	2,3	25	1,2	30
	3,2	2	2,5	2,9	32	1,2	38,4
	4	2,5	3,1	3,6	40	1,2	48
	5	3,2	3,8	4,5	50	1,2	60
	6,3	4	4,8	5,7	63	1,2	75,6
	8	5	6,1	7,2	80	1,2	96
	10	6,3	7,7	9	100	1,2	120
	12,5	7,9	9,6	11,3	125	1,2	150
	16	10	12	14	300	1,2	360
	20	13	15	18	300	1,2	360
	25	16	20	23	300	1,2	360
	32	20	25	29	320	1,2	384
	40	25	31	36	300...400	1,2	360...480
	50	32	38	45	300...500	1,2	360...600
	63	40	48	57	300...630	1,2	360...756
	80	50	61	72	400...800	1,2	480...960
	100	63	77	90	500...1000	1,2	600...1200

XT3 250 - TMD/TMA 63÷160 A

XT3N 250	I1 (400Hz)				I3		
	In	MIN	MED	MAX	I3 (50Hz)	km	I3 (400Hz)
	63	40	48	57	630	2	1260
	80	50	61	72	800	2	1600
	100	63	77	90	1000	2	2000
	125	79	96	113	1250	2	2500
	160	101	122	144	1600	2	3200

XT4 160 - TMD/TMA 16÷160 A

XT4N 160	I1 (400Hz)				I3		
	In	MIN	MED	MAX	I3 (50Hz)	km	I3 (400Hz)
	16	10	12	14	300	1,2	360
	20	13	15	18	300	1,2	360
	25	16	20	23	300	1,2	360
	32	20	25	29	320	1,2	384
	40	25	31	36	300...400	1,2	360...480
	50	32	38	45	300...500	1,2	360...600
	63	40	48	57	315...630	1,2	378...756
	80	50	61	72	400...800	1,2	480...960
	100	63	77	90	500...1000	1,2	600...1200
	125	79	96	113	625...1250	1,2	750...2400
	160	101	122	144	800...1600	1,2	960...1920

XT2 160 - Ekip trip units 10÷100 A*

XT2N 160	I1 (400Hz)	
	In	MAX
	10	10
	25	25
	63	63
	100	100
	160	125

XT4 160 - Ekip trip units 40÷160 A*

XT4N 160	I1 (400Hz)	
	In	MAX
	40	40
	63	63
	100	100
	160	160

XT4 250 - Ekip trip units 160÷200 A*

XT4N 250	I1 (400Hz)	
	In	MAX
	250	200


* not valid for Ekip M-I, Ekip M-LIU and Ekip M-LRIU trip units



Index

Tmax XT1 - Installation for fixed circuit-breaker	5/2
Tmax XT1 - Terminals for fixed circuit-breaker	5/5
Tmax XT1 - Accessories for fixed circuit-breaker	5/8
Tmax XT1 - Installation for plug-in circuit-breaker	5/16
Tmax XT1 - Terminals for plug-in circuit-breaker	5/19
Tmax XT1 - Accessories for plug-in circuit-breaker	5/22
Tmax XT2 - Installation for fixed circuit-breaker	5/23
Tmax XT2 - Terminals for fixed circuit-breaker	5/26
Tmax XT2 - Accessories for fixed circuit-breaker	5/30
Tmax XT2 - Installation for plug-in circuit-breaker	5/36
Tmax XT2 - Terminals for plug-in circuit-breaker	5/38
Tmax XT2 - Accessories for plug-in circuit-breaker	5/43
Tmax XT2 - Installation for withdrawable circuit-breaker	5/47
Tmax XT2 - Terminals for withdrawable circuit-breaker	5/50
Tmax XT2 - Accessories for withdrawable circuit-breaker	5/55
Tmax XT3 - Installation for fixed circuit-breaker	5/60
Tmax XT3 - Terminals for fixed circuit-breaker	5/63
Tmax XT3 - Accessories for fixed circuit-breaker	5/67
Tmax XT3 - Installation for plug-in circuit-breaker	5/73
Tmax XT3 - Terminals for plug-in circuit-breaker	5/76
Tmax XT3 - Accessories for plug-in circuit-breaker	5/80
Tmax XT4 - Installation for fixed circuit-breaker	5/81
Tmax XT4 - Terminals for fixed circuit-breaker	5/84
Tmax XT4 - Accessories for fixed circuit-breaker	5/89
Tmax XT4 - Installation for plug-in circuit-breaker	5/95
Tmax XT4 - Terminals for plug-in circuit-breaker	5/99
Tmax XT4 - Accessories for plug-in circuit-breaker	5/103
Tmax XT4 - Installation for withdrawable circuit-breaker	5/107
Tmax XT4 - Terminals for withdrawable circuit-breaker	5/110
Tmax XT4 - Accessories for withdrawable circuit-breaker	5/115
Tmax XT - Common accessories	5/119
Distances to be respected	5/120


Drilling template for circuit-breaker fixing



Flanges

Caption

- ① Flange for circuit-breaker III
- ② Flange for circuit-breaker IV
- ③ Flange for circuit-breaker III with RC Sel - RC Inst residual current release
- ④ Flange for circuit-breaker IV with RC Sel - RC Inst residual current release
- ⑤ Flange for fixed circuit-breaker III-IV with direct motor operator (MOD)
- ⑥ Flange for circuit-breaker III-IV with direct rotary handle (RHD)
- ⑦ Optional flange




Overall dimensions


Tmax XT1 - Installation for fixed circuit-breaker

Drilling templates compartment door


With standard flange



Without flange



With optional flange




Overall dimensions

Tmax XT1 - Terminals for fixed circuit-breaker

Terminals F

Caption


- ① Front terminals for busbars connection
- ⑦ 25mm insulating barriers between phases (compulsory) provided



Terminals EF

Caption


- ② Front extended terminals
- ③ High terminal covers with degree of protection IP40 (optional) not provided
- ⑤ 100mm insulating barriers between phases (compulsory) provided
- ⑨ Internal insulating plate compulsory with phase barriers (customer attention)



Terminals ES

Caption

- ④ Front extended spread terminals for busbar connection
- ⑥ 200mm insulating barriers between phases (compulsory) provided





Overall dimensions

Tmax XT1 - Terminals for fixed circuit-breaker

1x1.5...50mm² terminals FCCuAl

Caption

- ① 1x1.5...50mm² front terminal FCCuAl
- ③ 25mm insulating barriers between phases (compulsory) provided





1SDC21082CF0001

1x35...95mm² terminals FCCuAl

Caption

- ① External terminal FCCuAl
- ② High terminal covers with degree of protection IP40 (optional) provided





1SDC21077FF0001

Terminals FCCu

Caption

- ② Front terminal FCCu





1SDC21071GF0001

Terminals MC

Caption

- ④ Terminal covers with degree of protection IP40 (compulsory) provided
- ⑤ Front terminal for multicable connection




1SDC21084CF0001

Terminals R


Caption

- ① Adjustable rear terminals
- ② Bottom terminal covers with degree of protection IP30 (optional) not provided
- ③ Drilling template for circuit-breaker III fixing on sheet
- ④ Drilling template for circuit-breaker IV fixing on sheet



1SDC21085CF0001

Rotary handle operating mechanism on the compartment door (RHE)



1SDC21068FF0001


Caption

- ① Transmitted rotary handle
- ③ Door drilling template with transmitted rotary mandly
- ⑤ Transmission unit
- ⑥ 25mm insulating barriers between phases provided with circuit-breaker

Overall dimensions



Tmax XT1 - Accessories for fixed circuit-breaker

Large rotary handle operating mechanism on the compartment door (RHE-LH)



Caption

- ① Transmission unit
- ② 25mm insulating barriers between phases provided with circuit-breaker
- ③ Optional wiring ducts
- ④ Wide type rotary handle
- ⑤ Door drilling template with transmitted rotary handle



Caption

- ① Transmission unit
- ② 25mm insulating barriers between phases (compulsory) provided
- ③ Optional wiring ducts
- ④ Wide type rotary handle
- ⑤ Door drilling template with transmitted rotary handle

1SDC21060FF0001


Overall dimensions

Tmax XT1 - Accessories for fixed circuit-breaker

Direct motor operator (MOD)

Caption

- ③ Key lock (on request)
- ④ Direct motor operator (MOD)
- ⑤ Drilling template of door with MOD without flange
- ⑥ Drilling template of door with MOD with flange
- ⑦ Cables connection
- ⑧ 25mm phase barriers



[illegible]1SDC:21095GE0001


Overall dimensions

Tmax XT1 - Accessories for fixed circuit-breaker

RC Inst and RC Sel residual current release for 4 poles circuit-breaker

Caption

- ① Front terminals for busbars connection
- ② Terminal covers with degree of protection IP40
- ③ Drilling template of door with direct rotary handle with flange
- ④ Drilling template of door with direct rotary handle without flange
- ⑤ Drilling template for circuit-breaker fixing on sheet



1SDC21096CF0001

		A
With standard flange	IV	74
Without flange	IV	71

Technical drawings of the SDC21087CF0001 device, showing front, side, and top views with dimensions and callouts.

Front View (Top Left): Shows the main body with dimensions: 153.2 (total width), 101.2 (4P) (width of the main body), 38.1 (width of the top section), 65 (height of the main body), 96 (width of the main body), 45 (width of the main body), 35.5 (width of the main body), 168.2 (total width), and 25 (width of the main body). Callouts include X, Y, and 2.

Side View (Top Right): Shows the side profile with dimensions: 70 (total width), 24.5 (width of the top section), 11.5 (height of the top section), 115 (height of the main body), 71 (width of the main body), 101 (total width), 45 (height of the main body), and 7Nm (torque). Callouts include 1, X, and Y.

Top View (Bottom Left): Shows the top profile with dimensions: 83 (height of the main body), 70 (height of the main body), 78 (height of the main body), and 36.5 (width of the main body). Callouts include X, Y, and 3.

Bottom View (Bottom Right): Shows the bottom profile with dimensions: 152.5 (total width), 36.5 (width of the main body), 47 (height of the main body), 107 (total width), 53.5 (height of the main body), 87.5 (width of the main body), 25 (width of the main body), 25 (width of the main body), and 101 (total width). Callouts include 4, X, Y, and Ø 4.5 - M4.

Legend:

- 1: Torque 7Nm
- 2: Callout for the main body
- 3: Callout for the top profile
- 4: Callout for the bottom profile

Dimensions:

- 153.2 (total width)
- 101.2 (4P) (width of the main body)
- 38.1 (width of the top section)
- 65 (height of the main body)
- 96 (width of the main body)
- 45 (width of the main body)
- 35.5 (width of the main body)
- 168.2 (total width)
- 25 (width of the main body)
- 70 (total width)
- 24.5 (width of the top section)
- 11.5 (height of the top section)
- 115 (height of the main body)
- 71 (width of the main body)
- 101 (total width)
- 45 (height of the main body)
- 7Nm (torque)
- 83 (height of the main body)
- 70 (height of the main body)
- 78 (height of the main body)
- 36.5 (width of the main body)
- 47 (height of the main body)
- 107 (total width)
- 53.5 (height of the main body)
- 87.5 (width of the main body)
- 25 (width of the main body)
- 25 (width of the main body)
- 101 (total width)

Callouts:

- X
- Y
- 2
- 1
- 3
- 4
- Ø 4.5 - M4

Overall dimensions

Tmax XT1 - Installation for plug-in circuit-breaker


Fixing on support sheet

Caption


- ① Fixed part
- ② Moving part

Fixing at 50mm		A
With standard flange	III - IV	124
Without flange	III - IV	121
	III - IV	129

Fixing at 70mm for extended front terminals		A
With standard flange	III - IV	144
Without flange	III - IV	141
	III - IV	149








Drilling template for fixing circuit-breaker



Flanges

Caption

- ① Flange for plug-in circuit-breaker III
- ② Flange for circuit-breaker IV
- ⑤ Flange for plug-in circuit-breaker III-IV with direct motor operator (MOD)
- ⑥ Flange for plug-in circuit-breaker III-IV with direct rotary handle RHD
- ⑦ Optional flange




1SDC21003D0203

Overall dimensions


Tmax XT1 - Installation for plug-in circuit-breaker

Drilling templates compartment door


With standard flange



Without flange




With optional flange



Overall dimensions

Tmax XT1 - Terminals for plug-in circuit-breaker


Terminals EF



Caption

- ④ Front extended terminals
- ⑤ 100mm insulating barriers between phases (compulsory) provided

Terminals ES



Caption

- ③ Front extended spread terminals
- ⑥ 200mm insulating barriers between phases (compulsory) provided
- ⑦ Adaptor (compulsory) not provided



Overall dimensions

Tmax XT1 - Terminals for plug-in circuit-breaker

1x1.5...50mm² terminals FCCuAl

Caption

- ① 1x1.5...50mm² front terminal FCCuAl
- ⑤ Adaptor (compulsory) optional
- ⑥ 25mm insulating barriers between phases (compulsory) provided





FIXING AT 50mm

1x35...95mm² terminals FCCuAl

Caption



- ① External terminal FCCuAl
- ② High terminal covers with degree of protection IP40 (optional) provided



Terminals FCCu

Caption

- ④ Terminals FCCu
- ⑤ Adaptor (compulsory) not provided
- ⑥ 25mm insulating barriers between phases (compulsory) provided





FIXING AT 50mm

Terminals MC



Caption

- ② Terminal covers with degree of protection IP40 (optional) provided
- ③ Front terminal for multicable connection
- ⑤ Adaptor (compulsory) not provided




FIXING AT 50mm

Terminals HR/VR





FIXING AT 50mm



FIXING AT 50mm

Caption

- ① Rear vertical terminals
- ② Rear horizontal terminals
- ③ 90mm insulating barriers between phases (compulsory) not provided



1SDC21091CF0001

1SDC21092CF0001



Overall dimensions

Tmax XT1 - Accessories for plug-in circuit-breaker

Direct motor operator (MOD)

Caption

- ① Fixed part
- ② Moving part
- ③ Key lock (on request)
- ④ Direct motor operator (MOD)
- ⑤ Drilling template of door with MOD without flange
- ⑥ Drilling template of door with MOD with flange
- ⑦ Cables connection



Overall dimensions


Tmax XT2 - Installation for fixed circuit-breaker

Fixed circuit-breaker fixing on sheet

Caption

- ② Optional wiring ducts
- ③ 25mm insulating barriers between phases (compulsory) provided

		A
With standard flange	III - IV	86
	III - IV	83.5
Without flange	III - IV	91.5




1SDC21063FF0001

Fixed circuit-breaker fixing on DIN EN 50022 rail


Caption

- ① Bracket for fixing
- ③ 25mm insulating barriers between phases (compulsory) provided



1SDC21064FF0001

Drilling templates and support sheet



1SDC21021DF0001


Overall dimensions

Tmax XT2 - Installation for fixed circuit-breaker

Flanges

Caption

- ① Flange for fixed circuit-breaker III
- ② Flange for fixed circuit-breaker IV
- ③ Flange for fixed circuit-breaker III-IV with MOE and FLD
- ④ Flange for circuit-breaker III-IV with direct rotary handle RHD
- ⑧ Flange for circuit-breaker IV with fixed residual current and front terminals
- ⑨ Optional flange




1SDC21044CF0001


1SDC21045CF0001

Drilling templates compartment door

With standard flange




Without flange




With optional flange

1 Optional flange



	Execution	A	B	C
With optional flange	fixed	92		3-4 poles
	plug-in, fixing at 50mm		142	3-4 poles
	plug-in, fixing at 70mm			162 3-4 poles




Overall dimensions

Tmax XT2 - Terminals for fixed circuit-breaker

Terminals F

Caption


- ① 25mm insulating barriers between phases (compulsory) not provided
- ② Front terminals for busbars connection



Terminals EF

Caption


- ③ Front extended terminals
- ④ Terminal covers with degree of protection IP40 (optional) not provided
- ⑤ 100mm insulating barriers between phases (compulsory) provided
- ⑥ Insulated plate (compulsory) provided for XT2 Ue>440V
- ⑦ Drilling template for 3p circuit-breaker Ue>440V (compulsory)
- ⑧ Drilling template for 4p circuit-breaker Ue>440V (compulsory)




Terminals ES

Caption


- ① Drilling template for 3p circuit-breaker $U_e > 440V$ (compulsory)
- ② Drilling template for 4p circuit-breaker $U_e > 440V$ (compulsory)
- ③ Front extended spread terminals
- ④ 200mm insulating barriers between phases (compulsory) provided for $U_e > 440V$
- ⑤ Insulated plate (compulsory) provided for XT2 $U_e > 440V$



3 POLES



4 POLES





1SDC21088FF0001

1x1...95mm² terminals FCCuAl

Caption

- ① 1x1...95mm² terminals FCCuAl
- ③ 25mm insulating barriers between phases (compulsory) provided



1SDC21096EF0001



Overall dimensions

Tmax XT2 - Terminals for fixed circuit-breaker

1x70...185mm² terminals FCCuAl




Caption

- ① External terminal FCCuAl
- ② High terminal covers with degree of protection IP40 (optional) provided



1SDC21019FF0001

2x35...95mm² terminals FCCuAl



1SDC21020FF0001



Caption

- ② 2x35...95mm² terminals FCCuAl
- ④ Terminal covers with degree of protection IP40 (optional) provided

Terminals FCCu

Caption

- ③ 25mm insulating barriers between phases (compulsory) provided as standard with the circuit-breaker
- ⑥ Terminals FCCu




1SDC21069FF0001

Terminals MC

Caption

- ⑥ Multicable terminals




1SDC21098EF0001


Terminals R

Caption


- ① Rear adjustable terminals
② Bottom terminal covers with degree of protection IP30 (optional) provided
③ Drilling template for circuit-breaker III fixing on sheet
④ Drilling template for circuit-breaker IV fixing on sheet




1SDC21006CF0001



1SDC21002CF0001



3 POLES




4 POLES

1SDC21007CF0001

Overall dimensions

Tmax XT2 - Accessories for fixed circuit-breaker


Rotary handle operating mechanism on circuit-breaker (RHD)



Caption

- ② Rotary handle operating mechanism on circuit-breaker
- ④ Drilling template of door with direct rotary handle
- ⑥ 25mm insulating barriers between phases provided with circuit-breaker

Rotary handle operating mechanism on the compartment door (RHE)




Caption

- ① Transmission mechanism
- ② Rotary handle operating mechanism for compartment door
- ③ Compartment door shett steel drilling
- ④ Tightening torque 1.1Nm

Overall dimensions

Tmax XT2 - Accessories for fixed circuit-breaker

Stored energy motor operator (MOE)





3 POLES

4 POLES


Caption

- ① Stored energy motor operator (MOE)
- ② Key lock optional
- ③ Drilling template of door with MOE with flange
- ④ Door drilling template with MOE without flange
- ⑤ Drilling template for circuit-breaker 3p fixing on sheet
- ⑥ Drilling template for circuit-breaker 4p fixing on sheet
- ⑦ 25mm insulating barriers between phases provided with circuit-breaker



1SDC21072FF0001

Front for lever operating mechanism (FLD)



Caption

- ① Key lock optional
- ② Front for lever operating mechanism (FLD)
- ③ Drilling template of door with FLD with flange
- ④ Drilling template of door with FLD without flange
- ⑤ 25mm insulating barriers between phases provided with circuit-breaker


Overall dimensions

Tmax XT2 - Accessories for fixed circuit-breaker

Ekip Display or Ekip LED Meter


Caption

- ① 25mm insulating barriers between phases provided with circuit-breaker
- ② Ekip Display or Ekip LED Meter



1SDC21074FF001

Residual current RC Sel



		A
With standard flange	IV	86
Without flange	IV	83.5

Overall dimensions

Tmax XT2 - Installation for plug-in circuit-breaker


Plug-in circuit-breaker fixing on sheet

Caption


- ① Fixed part
- ② Moving part

Fixing at 50mm		A
With standard flange	III - IV	136
	III - IV	133.5
Without flange	III - IV	141.5

Fixing at 70mm for extended front terminals		A
With standard flange	III - IV	156
	III - IV	153.5
Without flange	III - IV	161.5







Drilling templates for support sheet





Flanges

Caption

- ① Flange for circuit-breaker rimovibile III
- ② Flange for circuit-breaker IV
- ③ Flange for plug-in circuit-breaker III-IV with MOE and FLD
- ④ Flange for circuit-breaker III-IV with direct rotary handle (RHD)
- ⑧ Flange for circuit-breaker IV with residual current and plug-in with front terminals
- ⑨ Optional flange



1SDC21044CF0001




1SDC21045CF0001

Overall dimensions


Tmax XT2 - Terminals for plug-in circuit-breaker

Drilling templates compartment door


With standard flange




Without flange



With optional flange



Terminals EF




1SDC21003CF0001

Caption


- ④ Front extended terminals
- ⑤ 100mm insulating barriers between phases (compulsory) provided

Terminals ES



Caption

- ① Front extended spread terminals
- ② 200mm insulating barriers between phases (compulsory) provided
- ③ Insulated plate (compulsory) provided
- ④ Drilling template for 3p circuit-breaker $U_e > 440V$ (compulsory)
- ⑤ Drilling template for 4p circuit-breaker $U_e > 440V$ (compulsory)



1SDC21075FF0001


Overall dimensions

Tmax XT2 - Terminals for plug-in circuit-breaker

1x1...95mm² terminals FCCuAl

Caption

- ① 1x1...95mm² front terminal FCCuAl
- ② 25mm insulating barriers between phases (compulsory) provided
- ⑥ Adaptor (compulsory) not provided




1SDC21011CF0001

1x70...185mm² terminals FCCuAl

Caption

- ① External terminal FCCuAl
- ② High terminal covers with degree of protection IP40 (optional) provided




1SDC21021FF0001

2x35...95mm² terminals FCCuAl

Caption

- ① External terminal FCCuAl
- ② High terminal covers with degree of protection IP40 (optional) provided





1SDC21022FF0001

Terminals FCCu

Caption

- ③ Terminals FCCu
- ④ Adaptor (compulsory) not provided

Note: 25mm insulating barriers between phases (compulsory) provided as standard with the circuit-breaker





FIXING AT 50mm

1SDC21076FF0001

Terminals MC

Caption

- ③ High terminal covers with degree of protection IP40 (optional) provided
- ④ Multicable terminals
- ⑥ Adaptor (compulsory) not provided




FIXING AT 50mm

1SDC21003FC0001

Tmax XT2 - Terminals for plug-in circuit-breaker

Terminals HR/VR




Caption

- ① Rear vertical terminals
- ② Rear horizontal terminals
- ③ 90mm insulating barriers between phases (compulsory) not provided

Overall dimensions

Tmax XT2 - Accessories for plug-in circuit-breaker

Stored energy motor operator (MOE)




Caption

- ① Fixed part
- ② Moving part
- ③ MOE
- ④ Key lock optional
- ⑤ 100mm insulating barriers between phases (compulsory) provided
- ⑥ Drilling template of door with direct rotary handle with flange
- ⑦ Drilling template of door with direct rotary handle without flange

Overall dimensions

Tmax XT2 - Accessories for plug-in circuit-breaker



Front for lever operating mechanism (FLD)




Caption

- ① Fixed part
- ② Moving part
- ③ Front for lever operating mechanism (FLD)
- ④ Key lock optional
- ⑤ 100mm insulating barriers between phases (compulsory) provided
- ⑥ Drilling template of door with direct rotary handle with flange
- ⑦ Drilling template of door with direct rotary handle without flange

Ekip Display or Ekip LED Meter



FIXING AT 50mm



FIXING AT 50mm

Caption


- ① 100mm insulating barriers between phases
- ② Ekip Display or Ekip LED Meter

1SDC21077FF0001

Overall dimensions

Tmax XT2 - Accessories for plug-in circuit-breaker

Residual current RC Sel



Caption


- ① Residual current
- ③ Fixed part
- ④ Moving part
- ⑤ 100mm insulating barriers between phases (compulsory) provided
- ⑥ Extended terminals
- ⑦ Drilling template of door with direct rotary handle and fixing with flange
- ⑧ Drilling template of door with direct rotary handle and fixing without flange
- ⑨ Drilling template for circuit-breaker fixing on sheet

		A
With standard flange	IV	136
Without flange	IV	133,5

Overall dimensions

Tmax XT2 - Installation for withdrawable circuit-breaker

Fixing on sheet



Caption


- ① Fixed part
- ② Moving part
- ③ FLD (FLD o RHD o RHE o MOE) mandatory for withdrawable version
- ⑥ Optional wiring ducts

			A
With standard flange	III - IV	Fixing at 50mm	170
	III - IV	Fixing at 70mm for extended front terminals	190

Overall dimensions

Tmax XT2 - Installation for withdrawable circuit-breaker


Drilling templates for support sheet



Flanges

Caption


- ⑤ Flange for circuit-breaker III-IV withdrawable
- ⑥ Flange for circuit-breaker withdrawable III-IV with direct rotary handle RHD
- ⑦ Flange for circuit-breaker residual current IV withdrawable with front extended terminals




	C	D
RHD	111	124.5
FLD - MOE	114.3	134.5

Drilling templates compartment door


With standard flange



Without flange




With standard flange



Overall dimensions

Tmax XT2 - Terminals for withdrawable circuit-breaker

Terminals EF




Caption

- ② Moving part
- ③ FLD (FLD or RHD or RHE or MOE) mandatory for withdrawable version
- ④ Front extended terminals
- ⑤ 100mm insulating barriers between phases (compulsory) provided

Note: insulated plate (compulsory) provided


Terminals ES



FIXING AT 50mm

Caption

- ① 200mm insulating barriers between phases (compulsory) provided
- ③ Front extended spread terminals
- ⑤ Adaptor (compulsory) not provided
- ⑥ Insulated plate (compulsory) provided
- ⑦ Drilling template for 3p circuit-breaker Ue>440V (compulsory)
- ⑧ Drilling template for 4p circuit-breaker Ue>440V (compulsory)



1SDC21078FF0001



Overall dimensions

Tmax XT2 - Terminals for withdrawable circuit-breaker

1x1...95mm² terminals FCCuAl

Caption

- ② 25mm insulating barriers between phases (compulsory) provided
- ④ 1x1...95mm² front terminals FCCuAl
- ⑤ Adaptor (compulsory) not provided





1SDC21016CF0001

FIXING AT 50mm

1x70...185mm² terminals FCCuAl

Caption

- ① External terminal FCCuAl
- ② High terminal covers with degree of protection IP40 (optional) provided





1SDC21023FF0001

2x35...95mm² terminals FCCuAl

Caption

- ① External terminal FCCuAl 2x95mm²
- ② High terminal covers with degree of protection IP40 (optional) provided




1SDC21024FF0001


Terminals FCCu

Caption

- ② Terminals FCCu
- ④ Adaptor (compulsory) not provided
- ⑤ 25mm insulating barriers between phases (compulsory) provided as standard with the circuit-breaker



FIXING AT 50mm




1SDC21033GF001


Terminals MC

Caption

- ① Multicable terminals
- ③ High terminal covers with degree of protection IP40 (optional) provided
- ④ Adaptor (compulsory) not provided



FIXING AT 50mm




1SDC21008FF001

Overall dimensions

Tmax XT2 - Terminals for withdrawable circuit-breaker

Terminals HR/VR




Caption

- ① Rear vertical terminals
- ② Rear horizontal terminals
- ③ 90mm insulating barriers between phases (compulsory) not provided

Overall dimensions

Tmax XT2 - Accessories for withdrawable circuit-breaker

Rotary handle operating mechanism on circuit-breakers (RHD)





Caption

- ① Fixed part
- ② Moving part
- ③ Rotary handle operating mechanism on circuit-breaker
- ④ 100mm insulating barriers between phases (compulsory) provided
- ⑤ Extended terminals
- ⑥ Drilling template of door with direct rotary handle


Tmax XT2 - Accessories for withdrawable circuit-breaker

Rotary handle operating mechanism on the compartment door (RHE)




Caption

- ① Fixed part
- ② Moving part
- ③ Rotary handle operating mechanism on the compartment door (RHE)
- ④ 100mm insulating barriers between phases (compulsory) provided
- ⑤ Extended terminals
- ⑥ Door drilling template with transmitted rotary handle
- ⑦ Transmission unit



Stored energy motor operator (MOE)



Caption


- ① Fixed part
- ② Moving part
- ④ 100mm insulating barriers between phases (compulsory) provided
- ⑤ Extended terminals
- ⑥ Key lock optional
- ⑦ Stored energy motor operator (MOE)

		A
Motor operator MOE	III - IV	222

Overall dimensions

Tmax XT2 - Accessories for withdrawable circuit-breaker

Front for lever operating (FLD)




Caption

- ① Fixed part
- ② Moving part
- ③ Front for lever operating (FLD)
- ④ 100mm insulating barriers between phases (compulsory provided)
- ⑤ Extended terminals
- ⑥ Key lock optional

		A
Front for lever operating FLD	III - IV	170

Residual current RC Sel 4 poles



Caption

- ① Fixed part
- ② Moving part
- ③ Front for lever operating
- ④ Residual current connector (optional)
- ⑤ 100mm insulating barriers between phases (compulsory) provided
- ⑥ Residual current
- ⑦ Extended terminals
- ⑧ Fixing screws for fixed part of connector
- ⑨ Door drilling template and flange fixing


Overall dimensions

Tmax XT3 - Installation for fixed circuit-breaker


Fixing on sheet

Caption

- ② Overall dimension of optional wiring ducts
- ③ 25mm insulating barriers between phases (compulsory) provided



		A
With standard flange	III - IV	74
Without flange	III - IV	71
	III - IV	79





1SDC21079FF0001

Fixing on DIN EN 50022 rail


Caption

- ① Bracket for fixing
- ② Optional wiring ducts
- ③ Optional front cover for DIN rail
- ④ 25mm insulating barriers between phases (compulsory) provided



1SDC21080FF0001


Drilling template for circuit-breaker fixing



Flanges

Caption

- ① Flange for fixed circuit-breaker III
- ② Flange for fixed circuit-breaker IV
- ③ Flange for circuit-breaker with direct motor operator MOD
- ④ Flange for circuit-breaker with direct rotary handle (RHD)
- ⑤ Flange for circuit-breaker III with residual current
- ⑥ Flange for circuit-breaker IV with residual current
- ⑦ Optional flange




Overall dimensions


Tmax XT3 - Installation for fixed circuit-breaker

Drilling templates compartment door

With standard flange





Without flange



With optional flange

Caption

- ① Optional flange




Overall dimensions

Tmax XT3 - Terminals for fixed circuit-breaker

Terminals F

Caption


- ① Front terminals for busbars connection
- ⑦ 25mm insulating barriers between phases (compulsory) provided



Terminals EF

Caption


- ② Front extended terminals
- ③ Terminal covers with degree of protection IP40 (optional) not provided
- ⑤ 100mm insulating barriers between phases (compulsory) provided



Terminals ES

Caption

- ④ Front extended spread terminals for busbars connection
- ⑥ 200mm insulating barriers between phases (compulsory) provided




Overall dimensions

Tmax XT3 - Terminals for fixed circuit-breaker


1x90...185mm² terminals FCCuAl

Caption

- ① 1x90...185mm² terminals FCCuAl
- ⑨ 25mm insulating barriers between phases (compulsory) provided as standard with the circuit-breaker




2x35...150mm² terminals FCCuAl



Caption


- ② 2x35...150mm² terminals FCCuAl
- ③ Terminal covers with degree of protection IP40 (optional) provided
- ④ Provided rear insulated plate (mandatory for CuAl 2x150mm² cables)
- ⑦ Drilling template for circuit-breaker fixing on sheet III with rear insulated plate
- ⑧ Drilling template for circuit-breaker fixing on sheet IV with rear insulated plate



30...150mm² terminals FCCuAl

Caption

- ① 30...150mm² terminals FCCuAl
- ② 25mm insulating barriers between phases (compulsory) provided as standard with the circuit-breaker




1SDC21084FF0001

Terminals FCCu

Caption

- ⑥ Front terminals FCCu
- ⑨ 25mm insulating barriers between phases (compulsory) provided as standard with the circuit-breaker




1SDC21084FF0001

Terminals MC

Caption

- ③ Terminal covers with degree of protection IP40 (optional) provided
- ⑤ Front terminal for multicable connection



1SDC21007FF0001


Overall dimensions

Tmax XT3 - Terminals for fixed circuit-breaker

Terminals R

Caption

- ① Adjustable rear terminals
- ② Bottom terminal covers with degree of protection IP30 (optional) provided
- ③ Drilling template for circuit-breaker IV fixing on sheet
- ④ Drilling template for circuit-breaker III fixing on sheet



1SDC21053GF0001


Overall dimensions

Tmax XT3 - Accessories for fixed circuit-breaker

Rotary handle operating mechanism on circuit-breaker (RHD)


Caption

- ② Rotary handle operating mechanism on circuit-breaker RHD
- ④ Drilling template of door with direct rotary handle
- ⑥ 25mm insulating barriers between phases (compulsory) provided as standard with the circuit-breaker



Tmax XT3 - Accessories for fixed circuit-breaker

Rotary handle operating mechanism on the compartment door (RHE)



Caption

- ① Transmission mechanism
- ② Rotary handle operating mechanism for compartment door (RHE)
- ⑤ Compartment door shett steel drilling
- ④ Tightening torque 1.1Nm

Technical drawings of the 3P 125 A circuit breaker, showing dimensions and callouts:

- Front View (Top Left):** Shows the main body with a width of 140 (4P) and a mounting hole spacing of 105 (3P). The central terminal spacing is 52.5. Callouts 1, 2, 3, and X indicate specific components and features.
- Side View (Top Right):** Shows the side profile with a total width of 144.25. The mounting hole spacing is 30.5. The main body width is 70. The handle assembly is shown with a length of 463. The handle width is 46, and the handle height is 33. The handle is labeled 4. The side view also shows the internal mechanism and the handle's movement range.
- Top View (Bottom Right):** Shows the top of the main body with a width of 47. The mounting hole spacing is 23.5. The central terminal diameter is $\varnothing 55$. The side terminal diameter is $\varnothing 5$. The handle assembly is shown with a width of 45 and a height of 11. The handle is labeled 5. The top view also shows the internal mechanism and the handle's movement range.
- Dimensions and Callouts:**
 - 140 (4P): Overall width of the main body.
 - 105 (3P): Mounting hole spacing.
 - 52.5: Central terminal spacing.
 - 144.25: Overall width including handle assembly.
 - 30.5: Mounting hole spacing including handle assembly.
 - 70: Main body width.
 - 463: Handle assembly length.
 - 46: Handle width.
 - 33: Handle height.
 - 47: Top view width.
 - 23.5: Top view mounting hole spacing.
 - 45: Top view handle width.
 - 11: Top view handle height.
 - $\varnothing 55$: Central terminal diameter.
 - $\varnothing 5$: Side terminal diameter.
- Callouts:**
 - 1: Main body.
 - 2: Mounting holes.
 - 3: Internal mechanism.
 - 4: Handle assembly.
 - 5: Top view handle assembly.
 - X: Specific components and features.
- Additional Information:**
 - 1, 1 Nm: Torque specification for the handle.
 - HEIGHTS FOR DOOR WITH MAXIMUM DISTANCE 568.5: Dimension for the door height.
 - MINIMUM DISTANCE FROM DOOR HINGE R min 200: Requirement for the door hinge distance.

- ① Transmission unit
- ② 25mm insulating barriers between phases (compulsory) provided as standard with the circuit-breaker
- ③ Optional wiring ducts
- ④ Large transmitted rotary handle
- ⑤ Drilling template of door with large transmitted rotary handle


Overall dimensions

Tmax XT3 - Accessories for fixed circuit-breaker

Direct motor operator (MOD)

Caption


- ③ Key lock (on request)
- ④ Direct motor operator MOD
- ⑤ Drilling template of door with MOD with flange
- ⑥ Drilling template of door with MOD without flange
- ⑦ 25mm insulating barriers



RC Inst and RC Sel residual current release for 3 poles circuit-breaker

Caption

- ① Front terminals for cables connection
- ② Terminal covers with degree of protection IP40
- ③ Drilling template of door with direct rotary handle with flange
- ④ Drilling template of door with direct rotary handle without flange
- ⑤ Drilling template for circuit-breaker fixing on sheet



		A
With standard flange	III	74
Without flange	III	71

1SDC210610CF0001


Overall dimensions

Tmax XT3 - Accessories for fixed circuit-breaker

RC Inst and RC Sel residual current release for 4 poles circuit-breaker

Caption

- ① Front terminals for cables connection
- ② Terminal covers with degree of protection IP40
- ③ Drilling template of door with direct rotary handle with flange
- ④ Drilling template of door with direct rotary handle without flange
- ⑤ Drilling template for circuit-breaker fixing on sheet




		A
With standard flange	IV	74
Without flange	IV	71

Tmax XT3 - Installation for plug-in circuit-breaker

Caption

- ① Fixed part
- ② Moving part




Fixing at 50mm		A
With standard flange	III - IV	124
Without flange	III - IV	121
	III - IV	129

Fixing at 70mm for extended front terminals		A
With standard flange	III - IV	144
Without flange	III - IV	141
	III - IV	149

Overall dimensions

Tmax XT3 - Installation for plug-in circuit-breaker

Drilling templates for support sheet




1SDC21070CF001

Flanges

Caption


- ① Flange for plug-in circuit-breaker III
- ② Flange for plug-in circuit-breaker IV
- ③ Flange for plug-in circuit-breaker with direct motor operator MOD
- ⑦ Optional flange




1SDC21024DF001

Drilling templates compartment door


With standard flange



Without flange




With optional flange



Overall dimensions

Tmax XT3 - Terminals for plug-in circuit-breaker


Terminals EF



Caption

- ④ Front extended terminals
- ⑤ 100mm insulating barriers between phases (compulsory) provided

Terminals ES




Caption

- ③ Front extended spread terminals for busbars connection
- ⑤ Adapter for fixed part (compulsory) not provided
- ⑥ 200mm insulating barriers between phases (compulsory) provided

1x90...185mm² terminals FCCuAl


Caption

- ① 1x90...185mm² front terminal FCCuAl
- ⑤ Adapter for fixed part (compulsory) not provided
- ⑥ 25mm insulating barriers between phases (compulsory) provided




1SDC21000FF0001

2x35...150mm² terminals FCCuAl



Caption

- ① 1x35...95 mm² external terminal FCCuAl
- ② High terminal covers with degree of protection IP40
- ③ Rear insulated plate (compulsory with 2x150mm²)
- ④ Drilling template for fixing circuit-breaker III with rear insulated plate
- ⑤ Drilling template for fixing circuit-breaker IV with rear insulated plate



1SDC21025FF0001



Overall dimensions

Tmax XT3 - Terminals for plug-in circuit-breaker

30...150mm² terminals FCCuAl

Caption

- ① 30...150mm² terminals FCCuAl
- ② 25mm insulating barriers between phases (compulsory) provided as standard with the circuit-breaker
- ③ Adapter for fixed part (compulsory) not provided





1SDC21001FF0001

Terminals FCCu

Caption

- ④ Front terminals FCCu
- ⑤ Adapter for fixed part (compulsory) not provided
- ⑥ 25mm insulating barriers between phases (compulsory) provided as standard with the circuit-breaker





FIXING AT 50mm

1SDC21002FF0001

Terminals MC

Caption


- ② High terminal covers with degree of protection IP40 (compulsory with multicable)
- ③ Front terminal for multicable connection
- ⑤ Adapter for fixed part (compulsory) not provided



FIXING AT 50mm

1SDC21003FF0001

- ① Rear vertical terminals
- ② Rear horizontal terminals
- ③ 90mm insulating barriers between phases (compulsory) not provided




FIXING AT 50mm


Overall dimensions

Tmax XT3 - Accessories for plug-in circuit-breaker

Direct motor operator (MOD)



FIXING AT 50mm



1SDC21065CF0001

Caption

- ① Fixed part
- ② Moving part
- ③ Key lock (on request)
- ④ Direct motor operator MOD
- ⑤ Drilling template of door with MOD with flange
- ⑥ Drilling template of door with MOD without flange

Overall dimensions



Tmax XT4 - Installation for fixed circuit-breaker

Fixing on sheet

Caption

- ② Overall dimension of optional wiring ducts
- ③ 25mm insulating barriers between phases (compulsory) provided

		A
With standard flange	III - IV	86
Without flange	III - IV	83.5
	III - IV	91.5





1SDC21094FF0001

Fixing on DIN 50022 rail



Caption

- ① Bracket for fixing
- ③ 25mm insulating barriers between phases (compulsory) provided



1SDC21096FF0001

Drilling templates for support sheet



1SDC21035DF0001


Overall dimensions

Tmax XT4 - Installation for fixed circuit-breaker

Flanges


Caption

- ① Flange for fixed circuit-breaker III
- ② Flange for fixed circuit-breaker IV
- ③ Flange for fixed circuit-breaker III-IV with MOE and FLD
- ④ Flange for circuit-breaker III-IV with direct rotary handle RHD
- ⑦ Flange for fixed circuit-breaker IV with front extended terminals and residual current
- ⑧ Optional flange




Drilling templates compartment door


With standard flange



Without flange



With optional flange




Overall dimensions

Tmax XT4 - Terminals for fixed circuit-breaker

Terminals F

Caption


- ① 25mm insulating barriers between phases (compulsory) provided
- ② Top terminal covers with degree of protection IP30 (optional) not provided




Terminals EF

Caption


- ③ Front extended terminals
- ④ Terminal covers with degree of protection IP40 (optional) not provided
- ⑤ 100mm insulating barriers between phases (compulsory) provided
- ⑥ Insulated plate provided compulsory for $U_e > 440V$
- ⑦ Drilling template for 3p circuit-breaker
- ⑧ Drilling template for 4p circuit-breaker



3 POLES




4 POLES




Terminals ES

Caption


- ① Drilling template for 3p circuit-breaker
- ② Drilling template for 4p circuit-breaker
- ③ Front extended spread terminals
- ④ 200mm insulating barriers between phases (compulsory) provided
- ⑤ Insulated plate provided compulsory for $U_e > 440V$



3 POLES





4 POLES



1x1...185mm² terminals FCCuAl

Caption


- ① 1x1...185mm² terminals
FCCuAl
- ③ 25mm insulating barriers
between phases (compulsory)
provided



Overall dimensions

Tmax XT4 - Terminals for fixed circuit-breaker

2x35...150mm² terminals FCCuAl





Caption

- ② 2x35...150mm² terminals FCCuAl
- ④ Terminal covers with degree of protection IP40 (optional) provided
- ⑤ Provided rear insulated plate (mandatory for CuAl 2x150mm² cables)
- ⑥ Drilling template for circuit-breaker IV fixing with insulating courtes plate
- ⑦ Drilling template for circuit-breaker III fixing with insulating courtes plate

Terminals FCCu

Caption



- ① Terminals FCCu
- ④ 25mm insulating barriers between phases (compulsory) provided as standard with the circuit-breaker



Terminals MC

Caption

- ② Multicable terminals
- ③ Terminal covers with degree of protection IP40 (optional) provided




Overall dimensions

Tmax XT4 - Terminals for fixed circuit-breaker

Terminals R

Caption

- ① Adjustable rear terminals
- ② Bottom terminal covers with degree of protection IP40 (optional) provided
- ③ Drilling template for circuit-breaker III fixing on sheet
- ④ Drilling template for circuit-breaker IV fixing on sheet




Overall dimensions

Tmax XT4 - Accessories for fixed circuit-breaker

Rotary handle operating mechanism on circuit-breaker (RHD)

Caption


- ② Rotary handle operating mechanism on circuit-breaker
- ④ Drilling template of door with direct rotary handle
- ⑥ 25mm insulating barriers between phases



Overall dimensions

Tmax XT4 - Accessories for fixed circuit-breaker


Rotary handle operating mechanism of the compartment door (RHE)



Caption

- ① Rotary handle operating mechanism of the compartment door
- ③ Drilling template for RHE
- ⑤ Transmission unit
- ⑥ 25mm insulating barriers between phases

Stored energy motor operator (MOE)



Caption


- ① Stored energy motor operator (MOE)
- ② Key lock optional
- ③ Drilling template of door with direct rotary handle with flange (MOE)
- ④ Drilling template of door with direct rotary handle without flange (MOE)
- ⑤ Drilling template for circuit-breaker III fixing on sheet
- ⑥ Drilling template for circuit-breaker IV fixing on sheet
- ⑦ 25mm insulating barriers between phases

1SDC21002GF0001

Overall dimensions


Tmax XT4 - Accessories for fixed circuit-breaker

Front for lever operating mechanism (FLD)



Caption

- ① Front for lever operating mechanism (FLD)
- ② Key lock optional
- ③ Drilling template of door with direct rotary handle with flange (FLD)
- ④ Drilling template of door with direct rotary handle without flange (FLD)
- ⑤ Drilling template for circuit-breaker III fixing on sheet
- ⑥ Drilling template for circuit-breaker IV fixing on sheet
- ⑦ 25mm insulating barriers between phases




1SDC210033D0001

Ekip Display or LED Meter

Caption

- ① Ekip Display or LED Meter
- ② Optional wiring ducts
- ③ 25mm insulating barriers between phases




1SDC21004GR0001

Overall dimensions

Tmax XT4 - Accessories for fixed circuit-breaker

Residual current RC Sel



Caption

- ① Residual current
- ② Front terminals
- ⑦ Drilling template of door with direct rotary handle and fixing with flange
- ⑧ Drilling template of door with direct rotary handle and fixing without flange
- ⑨ Drilling template for circuit-breaker fixing on sheet

		A
With standard flange	IV	86
Without flange	IV	83.5


Overall dimensions

Tmax XT4 - Installation for plug-in circuit-breaker

Fixing on sheet

Caption

- ① Fixed part
- ② Moving part



Fixing at 50mm		A
With standard flange	III - IV	136
Without flange	III - IV	133.5
	III - IV	141.5


Fixing at 70mm for front extended terminals		A
With standard flange	III - IV	156
Without flange	III - IV	153.5
	III - IV	161.5

1SDC21053DF0001

Overall dimensions

Tmax XT4 - Installation for plug-in circuit-breaker

Drilling templates for support sheet




1SDC21054DF0001

Flanges

Caption

- ① Flange for plug-in circuit-breaker III
- ② Flange for plug-in circuit-breaker IV
- ③ Flange for plug-in circuit-breaker III-IV with MOE and FLD
- ④ Flange for circuit-breaker III-IV with direct rotary handle
- ⑦ Flange for plug-in circuit-breaker IV with front extended terminals and residual current
- ⑧ Optional flange




Overall dimensions


Tmax XT4 - Installation for plug-in circuit-breaker

Drilling templates compartment door


With standard flange



Without flange




With optional flange



Overall dimensions

Tmax XT4 - Terminals for plug-in circuit-breaker

Terminals EF



Caption


- ④ Front extended terminals
- ⑤ 100mm insulating barriers between phases (compulsory) provided

Note: insulated plate to be provided by customer

Overall dimensions

Tmax XT4 - Terminals for plug-in circuit-breaker

Terminals ES




Caption

- ① Front extended spread terminals
- ② 200mm insulating barriers between phases (compulsory) provided
- ③ Insulated plate (compulsory) provided
- ④ Drilling template for 3p circuit-breaker
- ⑤ Drilling template for 4p circuit-break
- ⑥ Adaptor (compulsory) not provided

1x1...185mm² terminals FCCuAl

Caption


- ① 1x1...185mm² front terminals FCCuAl
- ② 25mm insulating barriers between phases (compulsory) provided
- ⑥ Adaptor (compulsory) not provided



2x35...150mm² terminals FCCuAl

Caption


- ① 2x150mm² external terminal FCCuAl
- ② High terminal covers with degree of protection IP40 (optional) provided



Terminals FCCu

Caption

- ② 25mm insulating barriers between phases (compulsory) provided as standard with the circuit-breaker
- ⑤ Terminals FCCu
- ⑥ Adaptor (compulsory) not provided




Overall dimensions

Tmax XT4 - Terminals for plug-in circuit-breaker


Terminals MC

Caption

- ③ Provided high terminal covers with degree of protection IP40 (mandatory for multicables terminals)
- ④ Multicable terminals
- ⑥ Adaptor (compulsory) not provided




Terminals HR/VR



Caption


- ① Rear vertical terminals
- ② Rear horizontal terminals
- ③ 90mm insulating barriers between phases (compulsory) not provided



Overall dimensions

Tmax XT4 - Accessories for plug-in circuit-breaker

Stored energy motor operator (MOE)



Caption


- ① Fixed part
- ② Moving part
- ③ Stored energy motor operator (MOE)
- ④ Key lock optional
- ⑤ 100mm insulating barriers between phases (compulsory) provided
- ⑥ Drilling template of door with direct rotary handle with flange
- ⑦ Drilling template of door with direct rotary handle without flange
- ⑧ Extended terminals

1SDC21065DF0001

Overall dimensions

Tmax XT4 - Accessories for plug-in circuit-breaker

Front for lever operating mechanism (FLD)





Caption

- ① Fixed part
- ② Moving part
- ③ Front for lever operating mechanism (FLD)
- ④ 100mm insulating barriers between phases (compulsory) provided
- ⑤ Drilling template of door with direct rotary handle with flange
- ⑥ Drilling template of door with direct rotary handle without flange

Ekip Display or LED Meter

Caption

- ① 100mm insulating barriers between phases (compulsory) provided
- ② Ekip Display or LED Meter



1SDC21073GF0001


Overall dimensions

Tmax XT4 - Accessories for plug-in circuit-breaker

Residual current RC Sel

Caption

- ① Residual current
- ③ Fixed part
- ④ Moving part
- ⑤ 100mm insulating barriers between phases (compulsory) provided
- ⑥ Extended terminals
- ⑦ Drilling template of door with direct rotary handle and fixing with flange
- ⑧ Drilling template of door with direct rotary handle and fixing without flange
- ⑨ Drilling template for circuit-breaker fixing on sheet



1SDC210670F0001

		B
With standard flange	IV	136
Without flange	IV	133.5


Overall dimensions

Tmax XT4 - Installation for withdrawable circuit-breaker

Fixing on sheet

Caption

- ① Fixed part
- ② Moving part
- ③ FLD (FLD or RHD or RHE or MOE) mandatory with withdrawable version
- ⑥ Optional wiring ducts




			A
With standard flange	III - IV	Fixing at 50mm	170
	III - IV	Fixing at 70mm for front extended terminals	190

Overall dimensions


Tmax XT4 - Installation for withdrawable circuit-breaker

Drilling templates for support sheet



Flanges


- Caption**
- ⑤ Flange for circuit-breaker III-IV estraibile
 - ⑥ Flange for circuit-breaker residual current IV withdrawable with front extended terminals




	C	D
RHD	111	124.5
FLD - MOE	114.3	134.5

Drilling templates compartment door


With standard flange



Without flange




With optional flange



Overall dimensions

Tmax XT4 - Terminals for withdrawable circuit-breaker

Terminals EF




1SDC21074DF001

Caption



- ④ Front extended terminals
- ⑤ 100mm insulating barriers between phases (compulsory) provided

Note: insulated plate (compulsory) provided

Terminals ES



FIXING AT 50 mm



1S5DC21003D0203

Caption

- ① Front extended spread terminals
- ② 200mm insulating barriers between phases (compulsory) provided
- ③ Insulated plate provided compulsory for $U_e > 440V$
- ④ Drilling template for 3p circuit-breaker
- ⑤ Drilling template for 4p circuit-breaker
- ⑥ Adaptor (compulsory) not provided


Overall dimensions

Tmax XT4 - Terminals for withdrawable circuit-breaker

1x1...185mm² terminals FCCuAl

Caption


- ② 25mm insulating barriers between phases (compulsory) provided
- ④ Front terminals FCCuAl
- ⑤ Adaptor (compulsory) not provided



2x35...150mm² terminals FCCuAl

Caption


- ① 2x35...150mm² terminals FCCuAl
- ② Terminal covers with degree of protection IP40 (optional) provided
- ③ Provided rear insulated plate (mandatory for CuAl 2x150mm² cables)
- ④ Drilling template for circuit-breaker III fixing with insulating courtes plate
- ⑤ Drilling template for circuit-breaker IV fixing with insulating courtes plate




Terminals FCCu

Caption

- ① 25mm insulating barriers between phases (compulsory) provided as standard with the circuit-breaker
- ② Terminals FCCu
- ③ Adaptor (compulsory) not provided



FIXING AT 50 mm




1SDC21003GF0001


Terminals MC

Caption

- ① Multicable terminals
- ③ High terminal covers with degree of protection IP40 (optional) provided
- ④ Adaptor (compulsory) not provided



FIXING AT 50 mm




1SDC210790F0001

Overall dimensions

Tmax XT4 - Terminals for withdrawable circuit-breaker

Terminals HR/VR



Caption

- ① Rear vertical terminals
- ② Rear horizontal terminals
- ③ 90mm insulating barriers between phases (compulsory)
not provided

Tmax XT4 - Accessories for withdrawable circuit-breaker

DET "A"
1:1




- ① Fixed part
- ② Moving part
- ③ Front for lever operating mechanism FLD
- ④ Drilling template of door with direct rotary handle and fixed flange
- ⑤ 100mm insulating barriers between phases (compulsory) provided
- ⑥ Extended terminals

Overall dimensions

Tmax XT4 - Accessories for withdrawable circuit-breaker

Stored energy motor operator (MOE)



Caption

- ① Fixed part
- ② Moving part
- ③ Stored energy motor operator (MOE)
- ④ Drilling template of door with MOE and fixing flange
- ⑤ 100mm insulating barriers between phases (compulsory provided)
- ⑥ Extended terminals
- ⑦ Key lock optional

1SDC210820F0001


[illegible]

- ① Fixed part
- ② Moving part
- ③ Shape for compartment door sheet steel drilling for fixed part
- ④ Tightening torque 1.1 Nm
- ⑤ Tightening torque 1.4 Nm
- ⑥ Transmission mechanism
- ⑦ Rotary handle operating mechanism for compartment door
- ⑧ Compartment door sheet steel drilling

Overall dimensions

Tmax XT4 - Accessories for withdrawable circuit-breaker

Residual current RC Sel 4 poles



Caption

- ① Fixed part
- ② Moving part
- ③ Front for lever operating mechanism
- ④ Connector residual current (optional)
- ⑤ 100mm insulating barriers between phases (compulsory) provided
- ⑥ Residual current
- ⑦ Extended terminals
- ⑧ Fixing screws for fixed part of connector
- ⑨ Drilling template of door with direct rotary handle and fixed flange


Overall dimensions

Tmax XT - Common accessories

Horizontal interlock XT serie

Caption

- ① Interlocking mechanism
- ② Drilling template for fixing interlocking system
- ③ Drilling template for all version with rear terminals
- ④ Tightening torque 3.7Nm
- ⑤ Tightening torque 3Nm
- ⑥ Tightening torque 2.5Nm
- ⑦ Couplink plate for circuit-breakers
- ⑧ Breaking for 4p version
- ⑨ A = 35mm XT4 withdrawable with key lock for fixed part
A = 25mm XT2 withdrawable with key lock for fixed part



	B	C
XT1	104,25	129,25
XT2	101,75	131,75
XT3	99,75	133,75
XT4	99,25	134,25

1SDC21003D001

Overall dimensions


Distances to be respected

Insulation distances for installation in metallic cubicle

$U_e \leq 440V$ AC $U_e \leq 250V$ DC	A (mm)	B (mm)	C (mm)
XT1	25	20	20
XT2	30	10	25
XT3	50	20	20
XT4	30	20	25

$U_e > 440V$ AC	A (mm)	B (mm)	C (mm)
XT1	25	20	20
XT2	50	20	45
XT3	50	20	20
XT4	50	20	45


$250 < U_e \leq 500V$ DC	A (mm)	B (mm)	C (mm)
XT1	25	20	20
XT2	50	50	45
XT3	50	20	20
XT4	50	50	45



Minimum center distance between two circuit-breaker side-by-side


	Circuit-breaker width (mm)		Centre distance I (mm)	
	3 poles	4 poles	3 poles	4 poles
XT1	76	102	76 ⁽¹⁾	102 ⁽¹⁾
XT2	90	120	90 ⁽¹⁾	120 ⁽¹⁾
XT3	105	140	105	140
XT4	105	140	105 ⁽¹⁾	140 ⁽¹⁾

⁽¹⁾ with phases separator between two circuit-breakers



Minimum centre distance for superimposed circuit-breakers

	H (mm)
XT1	80
XT2	100
XT3	140
XT4	150



Caption

- ① Connection - not insulated
- ② Insulated cable
- ③ Cable terminal



Index

Information on how to read the diagrams	6/2
Graphic symbols (IEC 60617 and CEI 3-14...3-26 Standards)	6/3
Wiring Diagrams of the circuit-breakers.....	6/4
Wiring Diagrams of the accessories.....	6/8
Resetting instructions.....	6/22

Wiring Diagrams

Information on how to read the diagrams

State of operation shown

The diagrams are shown in the following conditions:

- fixed version circuit-breaker, open;
- withdrawable or plug-in version circuit-breaker, open and connected;
- contactor for starting the motor open;
- circuits de-energised;
- trip units not tripped;
- motor operator with springs charged.

The diagram shows a circuit-breaker or a switch-disconnector in the withdrawable or plug-in version, but is also valid for fixed version circuit-breakers or switch-disconnectors.

For the fixed version circuit-breakers, the auxiliary circuits are headed at terminal box XV: connectors J.. and XB.., XC.., XD.. and XE.. are not supplied.

For the plug-in version circuit-breakers, the auxiliary circuits are headed at connectors XB.., XC.., XD.. and XE..: connectors J.. are not supplied.

For the withdrawable version circuit-breakers, the auxiliary circuits are headed at connectors J..: connectors XB.., XC.., XD.. and XE.. are not supplied.


Wiring Diagrams

Graphic symbols (IEC 60617 and CEI 3-14 ...3-26 Standards)


	Thermal effect		Conductors with corded cables (example two conductors)		Opening contact		Overcurrent release with short adjustable time delay characteristic
	Electromagnetic effect		Connection of conductors		Changeover contact with momentary break		Overcurrent release with short inverse adjustable time delay characteristic
	Timing		Terminal or clamp		Closing position contact (limit switch)		Overcurrent release with long inverse adjustable time delay characteristic
	Mechanical connection		Socket and plug (female and male)		Opening position contact (limit switch)		Overcurrent release for earth fault with short inverse time characteristic
	Manual mechanical operating mechanism (general case)		Resistor (general symbol)		Changeover contact with momentary break (limit switch)		Current relay for unbalance between phases
	Rotary handle operating mechanism		Resistor dependent on the temperature		Contactor (closing contact)		Residual current release
	Pushbutton operating mechanism		Motor (general symbol)		Power cut-off of switch-disconnector power with automatic opening		Relay for detecting lack of phase in a three-phase system
	Key operating mechanism		Three-phase asynchronous motor, with short-circuited rotor (cage)		Switch-disconnector		Relay for detecting blocked rotor by means of current measurement
	Cam operating mechanism		Current transformer		Control coil (general symbol)		Lamp, general symbol
	Ground (general symbol)		Current transformer with primary consisting of 4 passing conductors and with wound secondary, with socket		Thermal trip unit		Motor with excitation in series
	Converter separated galvanically		Closing contact		Instantaneous overcurrent release		Brush
	Conductors in shielded cable (example two conductors)		Voltmeter		Ammeter		Wattmeter
	Watt-hour meter						

Wiring Diagrams of the circuit-breakers


State of operation




Four-pole circuit-breaker with thermomagnetic trip unit and RC Sel 200 or RC B type residual current release




Four-pole circuit-breaker with thermomagnetic trip unit and RC Sel residual current release




Four-pole circuit-breaker with electronic trip unit and RC Sel residual current release



Three-pole fixed version circuit-breaker with current transformer on the neutral conductor outside the circuit-breaker



Three-pole or four-pole XT4 circuit-breaker with Ekip E-LSIG microprocessor based release



Fixed version three-pole XT4 circuit-breaker with Ekip E-LSIG with current transformer on neutral conductor, external to circuit-breaker





Diagram recommended for three-pole plug-in or withdrawable version circuit-breakers with current transformer on the neutral conductor outside the circuit-breaker



Advisable diagram for plug-in or withdrawable version three-pole circuit-breakers with current transformer and voltage connection on neutral conductor, external to circuit-breaker

Description of Figures

- Fig. 47 = Current transformer circuit on the neutral conductor outside the circuit-breaker (for plug-in or withdrawable version circuit-breaker).
- Fig. 63 = Circuit of the voltage socket on the neutral conductor outside the circuit-breaker (for Ekip E_LSIG type microprocessor-based plug-in or withdrawable circuit-breaker).

Notes


- G) In the case of a three-pole fixed version circuit-breaker with a current transformer on the neutral conductor outside the circuit-breaker, when you want to remove the circuit-breaker it is necessary to short-circuit the terminals of the TI/N transformer.

Caption


- = Diagram figure number
- * = See the note indicated by the letter
- J.. = Connectors for the auxiliary contacts of the withdrawable version circuit-breaker; extraction of the connectors takes place at the same time as that of the circuit-breaker.
- K51 = Electronic trip unit:
- overcurrent release type Ekip LS/I, Ekip N-LS/I, Ekip LSI, Ekip LSIG, Ekip E-LSIG
 - of motor protection type Ekip I, Ekip M-I, Ekip M-LIU, Ekip M-LRIU
 - of generator protection Ekip G-LSI
- K87 = Residual current release type RC Inst, RC Sel, RC Sel 200, RC B Type
- Q = Main circuit-breaker
- S75I/1..4 = Contacts for electrical signalling of circuit-breaker in the connected position (only provided with plug-in or withdrawable version circuit-breakers)
- S75S/1-2 = Contacts for electrical signalling of circuit-breaker in the racked-out position (only provided with withdrawable version circuit-breakers)
- SD = Power supply switch-disconnector of the residual current release type RC Inst, RC Sel, RC Sel 200 or RC B Type
- TI = Toroidal current transformer
- TI/L1 = Current transformer placed on phase L1
- TI/L2 = Current transformer placed on phase L2
- TI/L3 = Current transformer placed on phase L3
- TI/N = Current transformer placed on the neutral
- V1 = Circuit-breaker applications
- X41 = Circuit connector for external neutral
- XG-XH = Electronic trip unit connectors
- XV = Terminal boxes of the circuit-breaker applications
- YO1 = Opening solenoid of the microprocessor-based overcurrent release
- YO2 = Opening solenoid of the residual current release

Wiring Diagrams of the circuit-breakers


State of operation




Three-pole or four-pole circuit-breaker with TMD, TMA or TMG thermomagnetic trip unit




Three-pole circuit-breaker with MA magnetic trip unit




Three-pole or four-pole XT1D, XT3D or XT4D switch-disconnector




Three-pole or four-pole circuit-breaker with Ekip LS/I or Ekip G-LSI electronic trip unit




Three-pole or four-pole circuit-breaker with Ekip I, Ekip LSI or Ekip LSIg electronic trip unit



Four-pole circuit-breaker with Ekip N-LS/I electronic trip unit



Three-pole circuit-breaker with Ekip M-I, Ekip M-LIU or Ekip M-LRIU electronic trip unit




Three-pole or four-pole circuit-breaker with thermomagnetic trip unit and RC Inst or RC Sel residual current release

Caption

□	=	Diagram figure number
*	=	See the note indicated by the letter
K51	=	Microprocessor-based release: – overcurrent release type Ekip LS/I, Ekip N-LS/I, Ekip LSI, Ekip LSIG, Ekip E-LSIG – motor protection release type Ekip I, Ekip M-I, Ekip M-LIU, Ekip M-LRIU – generator protection release type Ekip G-LSI
K87	=	Residual current release type RC Inst, RC Sel, RC Sel 200, RC B Type
Q	=	Main circuit-breaker
SD	=	Power supply switch-disconnector of the residual current release type RC Inst, RC Sel, RC Sel 200 or RC B Type
TI	=	Toroidal current transformer
TI/L1	=	Current transformer placed on phase L1
TI/L2	=	Current transformer placed on phase L2
TI/L3	=	Current transformer placed on phase L3
TI/N	=	Current transformer placed on the neutral
YO1	=	Opening solenoid of the microprocessor-based overcurrent release
YO2	=	Opening solenoid of the residual current release

Wiring Diagrams of the accessories

Service releases



Description of Figures

- Fig. 1 = Shunt opening release.
 Fig. 2 = Supplementary shunt opening release (only for four-pole circuit-breakers).
 Fig. 3 = Permanent shunt opening release.
 Fig. 4 = Supplementary permanent shunt opening release (only for four-pole circuit-breakers).
 Fig. 5 = Instantaneous undervoltage release (see Notes B and F).
 Fig. 6 = Undervoltage release with electronic time delay device outside the circuit-breaker, see note B).


Notes

- B) The undervoltage release is supplied for power supply branched on the supply side of the circuit-breaker or from an independent source: closing is only possible with the release energised (the lock on closing is made mechanically).
 F) Additional external resistor for undervoltage supplied at 380/440V AC and 480/525V AC.

Caption

- = Diagram figure number
 * = See the note indicated by the letter
 D = Undervoltage release electronic time delay device (outside the circuit-breaker) (only for voltages up to 250V)
 J.. = Connectors for the auxiliary contacts of the withdrawable version circuit-breaker; extraction of the connectors takes place at the same time as that of the circuit-breaker
 Q/0..7 = Circuit-breaker auxiliary contacts
 R = Resistor (see note F)
 SO = Pushbutton or contact for opening the circuit-breaker
 V1 = Circuit-breaker applications
 V4 = Indicative apparatus and connections for control and signalling, outside the circuit-breaker
 XB.. = Three-way connector for the plug-in version circuit-breaker auxiliary circuits
 XV = Terminal boxes of the circuit-breaker applications
 YO = Shunt opening release
 YU = Undervoltage release (see note B)

Service releases



Description of Figures

- Fig. 7 = Instantaneous undervoltage release in the version for machine tools with one contact in series (see notes B, C and F).
- Fig. 8 = Instantaneous undervoltage release in the version for machine tools with two contacts in series (see Notes B, C and F).
- Fig. 9 = First auxiliary early contact operated by the crank handle.
- Fig. 10 = Second auxiliary early contact operated by the crank handle.
- Fig. 11 = One changeover contact for electrical signalling of circuit-breaker open due to tripping of the residual current release type RC Inst, RC Sel, RC B Type or RC Sel 200.
- Fig. 12 = Residual current release circuits type RC Sel, RC B Type or RC Sel 200.
- Fig. 13 = Two contacts for electrical signalling of residual current release pre-alarm and alarm type RC Sel, RC B Type or RC Sel 200.

Notes


- B) The undervoltage release is supplied for power supply branched on the supply side of the circuit-breaker or from an independent source: closing is only possible with the release energised (the lock on closing is made mechanically).
- C) Contacts S4/1 and S4/2 shown in figures 7-8 open the circuit with the circuit-breaker open and reclose it when a manual closing command is given by means of the rotary handle, in accordance with the Standards regarding machine tools (in any case closing does not take place if the undervoltage release is not supplied).
- F) Additional external resistor for undervoltage supplied at 480/525V AC.

Caption

- = Diagram figure number
- * = See the note indicated by the letter
- J.. = Connectors for the auxiliary contacts of the withdrawable version circuit-breaker; extraction of the connectors takes place at the same time as that of the circuit-breaker
- K87 = Residual current release type RC Sel, RC Sel 200, RC B type
- R = Resistor (see note F)
- S4/1-4 = Auxiliary early contacts operated by the circuit-breaker mounted crank handle (see note C)
- S87/1 = Contact for electrical signalling of pre-alarm of the residual current release type RC Sel, RC B or RC Sel 200
- S87/2 = Contact for electrical signalling of alarm of the residual current release type RC Sel, RC B or RC Sel 200
- S87/3 = Contact for electrical signalling of circuit-breaker open due to tripping of the residual current release type RC Sel, RC Inst, RC B or RC Sel 200
- SO = Pushbutton or contact for opening the circuit-breaker
- V1 = Circuit-breaker applications
- V4 = Indicative apparatus and connections for control and signalling, outside the circuit-breaker
- XB.. = Three-way connector for the plug-in version circuit-breaker auxiliary circuits
- XC.. = Six-way connector for the plug-in version circuit-breaker auxiliary contacts
- XV = Terminal boxes of the circuit-breaker applications
- YU = Undervoltage release (see note B)

Wiring Diagrams of the accessories

Motor operator



Description of Figures

- Fig. 21 = Direct control motor operator (MOD) (only for XT1 and XT3 fixed or plug-in circuit-breakers) (see note I).
 Fig. 22 = Motor operator with stored energy (MOE) (only for circuit-breakers XT2 and XT4).
 Fig. 23 = A contact for electrical signalling of stored energy motor operator that can be operated remotely.


Notes

- F) Additional external resistor -supplied with the motor- for MOD/MOE with supply voltage starting from 480/525V AC.

Caption

- = Diagram figure number
 * = See the note indicated by the letter
 A17 = Actuator unit type MOE for the stored energy motor operator
 H2 = Signalling lamp for stored energy motor operator blocked
 J.. = Connectors for the auxiliary contacts of the withdrawable version circuit-breaker; extraction of the connectors takes place at the same time as that of the circuit-breaker
 M = Motor with excitation in series for opening and closing the circuit-breaker (fig. 21)
 M = Motor for opening the circuit-breaker and spring charging for closing the circuit-breaker (fig. 22)
 M1 = Three-phase asynchronous motor
 R1 = Resistor (see note F)
 S1 = Contact controlled by the cam of the motor operator
 S2 = Contact controlled by the key lock of the motor operator with direct action
 S3/1-2 = Contacts controlled by the Auto/Manual selector and key lock of the stored energy motor operator
 S4 = Contact controlled by the cam of the motor operator with direct action
 S6/1-2 = Contacts controlled by the Auto/Manual selector of the motor operator with direct action
 SC = Pushbutton or contact for closing the circuit-breaker
 SO = Pushbutton or contact for opening the circuit-breaker
 V2 = Motor operator applications
 V4 = Indicative apparatus and connections for control and signalling, outside the circuit-breaker
 XD.. = Nine-way connector for the auxiliary circuits of the plug-in version circuit-breaker
 XV = Terminal boxes of the circuit-breaker applications
 YC = Shunt closing release of the stored energy motor operator

Signalling contacts



Description of Figures

- Fig. 31 = One changeover contact for electrical signalling of circuit-breaker open or closed and one changeover contact for electrical signalling of circuit-breaker open due to tripping of the magnetic, thermomagnetic or electronic trip units, YO, YO1, YO2, YU (tripped position) (only for voltages up to 250V) (see notes E and I).
- Fig. 32 = Two changeover contacts for electrical signalling of circuit-breaker open or closed, two changeover contacts for electrical signalling of circuit-breaker open due to tripping of the magnetic, thermomagnetic or electronic trip units, YO, YO1, YO2, YU (tripped position) and one changeover contact for electrical signalling of circuit-breaker open due to tripping of the thermomagnetic or electronic trip unit (only for voltages up to 250V).
- Fig. 33 = Three changeover contacts for electrical signalling of circuit-breaker open or closed and two changeover contacts for electrical signalling of circuit-breaker open due to tripping of the magnetic, thermomagnetic or electronic trip units, YO, YO1, YO2, YU (tripped position) (only for voltages up to 250V).

Notes


- E) The 24V auxiliary power supply unit of fig. 48 must necessarily be installed in the circuit-breaker seats marked SY/1 and Q/2. Therefore, should you want to install the unit in fig. 48 and the contacts in fig. 31 at the same time, the contacts of fig. 31 must be installed in the adjacent slots; that is, contact SY/1 in the slot marked SY/2 and contact Q/2 in the slot marked Q/1.
- I) If MOD (application in figure 21) and auxiliary contacts 1Q+1SY (in figure 31) are installed at the same time, contact Q/2 must be installed in the slot marked as Q/1.

Caption

- = Diagram figure number
- * = See the note indicated by the letter
- J.. = Connectors for the auxiliary contacts of the withdrawable version circuit-breaker; extraction of the connectors takes place at the same time as that of the circuit-breaker
- Q/0..3 = Circuit-breaker auxiliary contacts
- S51 = Contact for electrical signalling of circuit-breaker open due to tripping of the thermomagnetic or electronic trip unit
- SY/1..2 = Contacts for electrical signalling of circuit-breaker open due to tripping of the thermomagnetic trip units, YO, YO1, YO2, YU (tripped position)
- V1 = Circuit-breaker applications
- V4 = Indicative apparatus and connections for control and signalling, outside the circuit-breaker
- XC.. = Six-way connector for the plug-in version circuit-breaker auxiliary contacts
- XD.. = Nine-way connector for the auxiliary circuits of the plug-in version circuit-breaker
- XE.. = Fifteen-way connector for the auxiliary circuits of the plug-in version circuit-breaker
- XV = Terminal boxes of the circuit-breaker applications

Wiring Diagrams of the accessories

Signalling contacts





Description of Figures

- Fig. 34 = Three changeover contacts for electrical signalling of circuit-breaker open and one changeover contact for electrical signalling of circuit-breaker open due to tripping of the magnetic, thermomagnetic or electronic trip units, YO, YO1, YO2, YU (tripped position) (only for voltages up to 250V).
- Fig. 35 = One changeover contact for electrical signalling of circuit-breaker open due to tripping of the thermomagnetic electronic trip unit (only for voltages up to 250V).
- Fig. 36 = Two changeover contacts for electrical signalling of circuit-breaker open or closed and one changeover contact for electrical signalling of circuit-breaker open due to tripping of the magnetic, thermomagnetic or electronic trip units, YO, YO1, YO2, YU (tripped position) (only for voltages up to 250V).
- Fig. 37 = One changeover contact for electrical signalling of circuit-breaker open or closed and one changeover contact for electrical signalling of circuit-breaker open due to tripping of the magnetic, thermomagnetic or electronic trip units, YO, YO1, YO2, YU (tripped position) (only for voltage up to 400V).
- Fig. 38 = Two changeover contacts for electrical signalling of circuit-breaker open or closed (only for voltage up to 400V).

Caption

- | | | |
|--------|---|---|
| □ | = | Diagram figure number |
| * | = | See the note indicated by the letter |
| J.. | = | Connectors for the auxiliary contacts of the withdrawable version circuit-breaker; extraction of the connectors takes place at the same time as that of the circuit-breaker |
| Q/0..3 | = | Circuit-breaker auxiliary contacts |
| S51 | = | Contact for electrical signalling of circuit-breaker open due to tripping of the thermomagnetic or electronic trip unit |
| SY/1 | = | Contacts for electrical signalling of circuit-breaker open due to tripping of the thermomagnetic trip units, YO, YO1, YO2, YU (tripped position) |
| V1 | = | Circuit-breaker applications |
| V4 | = | Indicative apparatus and connections for control and signalling, outside the circuit-breaker |
| XB.. | = | Three-way connector for the plug-in version circuit-breaker auxiliary circuits |
| XC.. | = | Six-way connector for the plug-in version circuit-breaker auxiliary contacts |
| XD.. | = | Nine-way connector for the auxiliary circuits of the plug-in version circuit-breaker |
| XE.. | = | Fifteen-way connector for the auxiliary circuits of the plug-in version circuit-breaker |
| XV | = | Terminal boxes of the circuit-breaker applications |

Signalling contacts



Wiring Diagrams of the accessories

Description of Figures

- Fig. 39 = Three supplementary changeover contacts for electrical signalling of circuit-breaker open or closed (only for fixed or plug-in version circuit-breakers).
- Fig. 41 = First changeover position contact of the circuit-breaker, for electrical signalling of connected (only for plug-in or withdrawable version circuit-breakers).
- Fig. 42 = Second changeover position contact of the circuit-breaker, for electrical signalling of connected (only for plug-in or withdrawable version circuit-breakers).
- Fig. 43 = Third changeover position contact of the circuit-breaker, for electrical signalling of connected (only for plug-in or withdrawable version circuit-breakers).
- Fig. 44 = Fourth changeover position contact of the circuit-breaker, for electrical signalling of connected (only for plug-in or withdrawable version circuit-breakers).
- Fig. 45 = First changeover position contact of the circuit-breaker, for electrical signalling of isolated (only for withdrawable version circuit-breakers).
- Fig. 46 = Second changeover position contact of the circuit-breaker, for electrical signalling of isolated (only for withdrawable version circuit-breakers).
- Fig. 48 = Auxiliary circuits of the 24V auxiliary power supply unit and of the HMI030 type interface unit (see note E).
- Fig. 104 = Auxiliary circuits of Ekip Com or Kit of 24V DC auxiliary voltage for electronic trip units and of Ekip Multimeter display.


Notes

- E) The 24V auxiliary power supply unit of fig. 48 must necessarily be installed in the circuit-breaker seats marked SY/1 and Q/2. Therefore, should you want to install the unit in fig. 48 and the contacts in fig. 31 at the same time, the contacts of fig. 31 must be installed in the adjacent slots; that is, contact SY/1 in the slot marked SY/2 and contact Q/2 in the slot marked Q/1.
- H) Having requested a Uaux insulated from earth, one must use "galvanically separated converters" in compliance with IEC 60950 (UL 1950) or equivalent standards that ensure a common mode current or leakage current (see IEC 478/1, CEI 22/3) no greater than 3.5 mA, IEC 60364-41 and CEI 64-8.

Caption

- = Diagram figure number
- * = See the note indicated by the letter
- J.. = Connectors for the auxiliary contacts of the withdrawable version circuit-breaker; extraction of the connectors takes place at the same time as that of the circuit-breaker
- K51 = Electronic trip unit:
- of overcurrent type Ekip LS/I, Ekip N-LS/I, Ekip LSI, Ekip LSIg
 - of motor protection type Ekip I, Ekip M-I, Ekip M-LIU, Ekip M-LRIU
 - of generator protection type Ekip G-LSI
- Q/0..7 = Circuit-breaker auxiliary contacts
- S75I/1..4 = Contacts for electrical signalling of circuit-breaker in connected position (only provided with plug-in or withdrawable version circuit-breakers)
- S75E/1-2 = Contacts for electrical signalling of circuit-breaker in racked-out position (only provided with withdrawable version circuit-breakers)
- V1 = Circuit-breaker applications
- V4 = Indicative apparatus and connections for control and signalling, outside the circuit-breaker
- WI = Serial interface with the trip unit accessories
- X3 = Connector of the circuit for the 24V auxiliary power supply unit
- XD.. = Nine-way connector for the auxiliary circuits of the plug-in version circuit-breaker
- XV = Terminal boxes of the circuit-breaker applications
- A18 = 24V auxiliary power supply unit (see note E)
- XH1 = Electronic trip unit contacts
- A15 = Ekip Multimeter.

Electronic trip unit Ekip E-LSIG connected with Ekip Display or Ekip LED Meter



1SDC21074GF0001

Description of Figures


Fig. 50 = Auxiliary circuits of the Ekip E-LSIG microprocessor-based release connected to the Ekip Display (display) or Ekip LED Meter (current display) display unit.

Caption

- = Reference number of diagram figure
- A11 = Display unit type Ekip Display (display) or Ekip LED Meter (current display)
- K51 = Microprocessor-based release:
 - overcurrent release type Ekip LS/I, Ekip N-LS/I, Ekip LSI, Ekip LSIg, Ekip E-LSIG
 - motor protection release type Ekip I, Ekip M-I, Ekip M-LIU, Ekip M-LRIU
 - generator protection release type Ekip G-LSI
- Q = Main switch
- TI/L1 = Current transformer located on phase L1
- TI/L2 = Current transformer located on phase L2
- TI/L3 = Current transformer located on phase L3
- TI/N = Current transformer located on neutral
- YO1 = Opening solenoid of microprocessor-based overcurrent release

Wiring Diagrams of the accessories

Electronic trip unit Ekip LSI, Ekip LSIG, Ekip M-LRIU connected with Ekip Display or Ekip LED Meter




Description of Figures

Fig. 51 = Auxiliary circuits of the electronic trip unit type Ekip LSI, Ekip LSIG or Ekip MLRIU connected to display unit type Ekip Display (display) or Ekip LED Meter (current display).

Caption

- = Diagram figure number
- A11 = Display unit type Ekip Display (display) or Ekip LED Meter (current display)
- K51 = Microprocessor-based release:
 - overcurrent release type Ekip LS/I, Ekip N-LS/I, Ekip LSI, Ekip LSIG, Ekip E-LSIG
 - motor protection release type Ekip I, Ekip M-I, Ekip M-LIU, Ekip M-LRIU
 - generator protection release type Ekip G-LSI
- Q = Main circuit-breaker
- TI/L1 = Current transformer placed on phase L1
- TI/L2 = Current transformer placed on phase L2
- TI/L3 = Current transformer placed on phase L3
- TI/N = Current transformer placed on the neutral
- YO1 = Opening solenoid of the microprocessor-based overcurrent release

Auxiliary circuit of Ekip-Com and HMI030



Description of Figures

Fig. 52 = Auxiliary circuits of the Ekip Com type interface unit and of the HMI030 type interface unit (see note E).


Notes

H) Having requested a Uaux insulated from earth, one must use “galvanically separated converters” in compliance with IEC 60950 (UL 1950) or equivalent standards that ensure a common mode current or leakage current (see IEC 478/1, CEI 22/3) no greater than 3.5 mA, IEC 60364-41 and CEI 64-8.

Caption

- | | | |
|---------|---|---|
| □ | = | Diagram figure number |
| A12 | = | Interface unit type Ekip Com (with MODBUS serial communication) |
| A13 | = | Signalling unit type LD030 DO |
| K51 | = | Electronic trip unit: <ul style="list-style-type: none"> – of overcurrent type Ekip LSI, Ekip LSIG – of motor protection type Ekip M-LRIU |
| Q | = | Main circuit-breaker |
| Q/0..7 | = | Circuit-breaker auxiliary contacts |
| SY/1..3 | = | Contacts for electrical signalling of circuit-breaker open due to tripping of the thermomagnetic trip units, YO, YO1, YO2, YU (tripped position) |
| TI/L1 | = | Current transformer placed on phase L1 |
| TI/L2 | = | Current transformer placed on phase L2 |
| TI/L3 | = | Current transformer placed on phase L3 |
| TI/N | = | Current transformer placed on the neutral |
| WI | = | Serial interface with the trip unit accessories |
| WS | = | Serial interface with the control system (MODBUS EIA RS485 interface) |
| XF | = | Connector of the Interface unit type Ekip Com |
| XG-XH | = | Electronic trip unit connectors |
| XV | = | Terminal boxes of the circuit-breaker applications |
| YO1 | = | Opening solenoid of the microprocessor-based overcurrent release |

Electronic trip unit Ekip LSI, Ekip LSIG or Ekip M-LRIU connected to interface unit Ekip Com and with actuator unit type MOE-E for the stored energy motor operator



Description of Figures

- Fig. 23 = One Contact for electrical signalling of stored energy motor operator that can be operated remotely.
Fig. 53 = Auxiliary circuits of the electronic trip unit type Ekip LSI, Ekip LSIg or Ekip M-LRIU connected to interface unit type Ekip Com and with actuator unit type MOE-E for the stored energy motor operator.

Notes


- H) Having requested a Uaux insulated from earth, one must use “galvanically separated converters” in compliance with IEC 60950 (UL 1950) or equivalent standards that ensure a common mode current or leakage current (see IEC 478/1, CEI 22/3) no greater than 3.5 mA, IEC 60364-41 and CEI 64-8.

Caption

- = Diagram figure number
A12 = Interface unit type Ekip Com (with MODBUS serial communication)
A14 = Actuator unit type MOE-E for the stored energy motor operator
H2 = Signalling lamp for blocked stored energy motor operator
J.. = Connectors for the auxiliary contacts of the withdrawable version circuit-breaker; extraction of the connectors takes place at the same time as that of the circuit-breaker
K51 = Electronic trip unit:
– of overcurrent type Ekip LSI, Ekip LSIg
– of motor protection type Ekip M-LRIU
M = Motor with excitation in series for opening and closing the circuit-breaker (fig. 21)
Q = Main circuit-breaker
Q/0..7 = Circuit-breaker auxiliary contacts
R1 = Resistor (see note H)
S1 = Contact controlled by the cam of the motor operator
S3/1-2 = Contacts controlled by the Auto/Manual selector and key lock of the stored energy motor operator
SC = Pushbutton or contact for closing the circuit-breaker
SO = Pushbutton or contact for opening the circuit-breaker
SY/1..3 = Contacts for electrical signalling of circuit-breaker open due to tripping of the thermomagnetic trip units, YO, YO1, YO2, YU (tripped position)
TI = Toroidal current transformer
TI/L1 = Current transformer placed on phase L1
TI/L2 = Current transformer placed on phase L2
TI/L3 = Current transformer placed on phase L3
TI/N = Current transformer placed on the neutral
WI = Serial interface with the trip unit accessories
WS = Serial interface with the control system (MODBUS EIA RS485 interface)
XC.. = Six-way connector for the plug-in version circuit-breaker auxiliary contacts
XD.. = Nine-way connector for the auxiliary circuits of the plug-in version circuit-breaker
XF = Connector of the Interface unit type Ekip Com
XG-XH = Electronic trip unit connectors
XV = Terminal boxes of the circuit-breaker applications
YC = Shunt closing release of the stored energy motor operator
YO1 = Opening solenoid of the microprocessor-based overcurrent release

Wiring Diagrams of the accessories

Auxiliary circuits of the electronic trip unit Ekip M-LRIU connected to the contactor control unit for starting the motor PR212/CI (the circuit to the motor thermistor is optional)



Description of Figures

- Fig. 54 = Auxiliary circuits of the electronic trip unit type Ekip M-LRIU connected to the contactor control unit for starting the motor type PR212/CI (the circuit to the motor thermistor is optional).
 Fig. 62 = Motor thermistor circuit.

Caption

- = Diagram figure number
 A15 = Contactor control unit for starting the motor type PR212/CI
 H1 = Signalling lamp
 J.. = Connectors for the auxiliary contacts of the withdrawable version circuit-breaker; extraction of the connectors takes place at the same time as that of the circuit-breaker
 K = Contactor for starting the motor
 K51 = Electronic trip unit Ekip M-LRIU
 M1 = Three-phase asynchronous motor
 Q = Main circuit-breaker
 R2 = Motor thermistor
 SC3 = Pushbutton for starting the motor
 SO3 = Pushbutton for stopping the motor
 TI/L1 = Current transformer placed on phase L1
 TI/L2 = Current transformer placed on phase L2
 TI/L3 = Current transformer placed on phase L3
 X42 = Circuit connector for the motor thermistor
 X5 = Circuit connector towards PR212/CI unit
 XG-XH = Electronic trip unit connectors
 YO1 = Opening solenoid of the microprocessor-based overcurrent release

[illegible]

Fig. 55 = Auxiliary circuits of the electronic trip unit type Ekip M-LRIU connected to the contactor control unit for starting the motor type PR212/CI and with ABB AF series contactor (the circuit to the motor thermistor is optional).

□	=	Diagram figure number
A15	=	Contactors control unit for starting the motor type PR212/CI
H1	=	Signalling lamp
J..	=	Connectors for the auxiliary contacts of the withdrawable version circuit-breaker; extraction of the connectors takes place at the same time as that of the circuit-breaker
K	=	Contactors for starting the motor
K51	=	Electronic trip unit Ekip M-LRIU
M1	=	Three-phase asynchronous motor
Q	=	Main circuit-breaker
R2	=	Motor thermistor
SC3	=	Pushbutton for starting the motor
SO3	=	Pushbutton for stopping the motor
TI/L1	=	Current transformer placed on phase L1
TI/L2	=	Current transformer placed on phase L2
TI/L3	=	Current transformer placed on phase L3
X42	=	Circuit connector for the motor thermistor
X5	=	Circuit connector towards PR212/CI unit
XG-XH	=	Electronic trip unit connectors
YO1	=	Opening solenoid of the microprocessor-based overcurrent release

Resetting instructions

Instructions for resetting the circuit-breaker following release tripping

Selection of the type of circuit-breaker resetting depends on design requirements and on service conditions.

Resetting can take place following tripping of the following releases:

- overcurrent;
- undervoltage;
- shunt opening.

The following three possibilities are suggested (see diagrams below):

1. Only manual resetting

To be wired (by the customer): contact SO1, contact SY/1 and the auxiliary relay KO (only for MOD).

Opening is prevented until the circuit-breaker is in the tripped position.

To reset the circuit-breaker it is necessary to activate the special lever on the front of the motor until the circuit-breaker goes into the open position.

2. Electrical resetting making the operator responsible

To be wired (by the customer): contact SO1, SO2, contact SY/1 and the auxiliary relay KO (only for MOD).

Opening is allowed by means of contact SO2, which must be placed in custody and can only be used if the information the person in charge of the control station has received makes it possible to exclude tripping due to a short-circuit, or if the causes of the short-circuit have been removed.


3. Electrical resetting always allowed

To be wired (by the customer): contact SO1, SO2, contact SY/1 and the auxiliary relay KO (only for MOD).


Opening is always allowed by means of contact SO2.

NB: If the magnetic, thermomagnetic or electronic trip unit is present, it is necessary to find the causes which led to the circuit-breaker being in the tripped position so as to prevent reclosing under short-circuit conditions. In all cases, manual resetting is always allowed.

MOD



MOE or MOE-E



Notes

- H) Having requested a Uaux insulated from earth, one must use "galvanically separated converters" in compliance with IEC 60950 (UL 1950) or equivalent standards that ensure a common mode current or leakage current (see IEC 478/1, CEI 22/3) no greater than 3.5 mA, IEC 60364-41 and CEI 64-8.

Caption

- A17 = Actuator unit type MOE for the stored energy motor operator H2 = Signalling lamp for blocked stored energy motor operator
- J.. = Connectors for the auxiliary contacts of the withdrawable version circuit-breaker; extraction of the connectors takes place at the same time as that of the circuit-breaker
- KO = Auxiliary opening relay
- M = Motor with excitation in series for opening and closing the circuit-breaker (fig. 21)
- M = Motor for opening the circuit-breaker and spring charging for closing the circuit-breaker (fig. 22)
- R1 = Resistor supplied with the motor (see note H)
- S1 = Contact controlled by the cam of the motor operator
- S2 = Contact controlled by the key lock of the motor operator with direct action
- S3/1-2 = Contacts controlled by the Auto/Manual selector and key lock of the stored energy motor operator
- S6/1-2 = Contacts controlled by the Auto/Manual selector of the motor operator with direct action
- SC = Pushbutton or contact for closing the circuit-breaker
- SO1,SO2 = Pushbuttons or contacts for opening the circuit-breaker (see "Instructions for resetting the circuit-breaker following release tripping")
- SY/1..3 = Contacts for electrical signalling of circuit-breaker open due to tripping of the thermomagnetic trip units, YO, YO1, YO2, YU (tripped position)
- V1 = Circuit-breaker applications
- V2 = Motor operator applications
- V4 = Indicative apparatus and connections for control and signalling, outside the circuit-breaker
- XB.. = Three-way connector for the plug-in version circuit-breaker auxiliary circuits
- XC.. = Six-way connector for the plug-in version circuit-breaker auxiliary contacts
- XD.. = Nine-way connector for the auxiliary circuits of the plug-in version circuit-breaker
- XV = Terminal boxes of the circuit-breaker applications
- YC = Shunt closing release of the stored energy motor operator



Index

Examples of ordering	7/2
-----------------------------------	------------

Ordering codes for XT1

Circuit-breakers	7/4
------------------------	-----

Accessories	7/5
-------------------	-----

Ordering codes for XT2

Circuit-breakers	7/12
------------------------	------

Accessories	7/19
-------------------	------

Ordering codes for XT3

Circuit-breakers	7/29
------------------------	------

Accessories	7/31
-------------------	------

Ordering codes for XT4

Circuit-breakers	7/38
------------------------	------

Accessories	7/46
-------------------	------

Ordering codes

Examples of ordering

EXAMPLE 1: Terminals for fixed or fixed part of plug-in/withdrawable circuit-breaker

To fit the circuit-breaker with terminals other than those supplied on the basic circuit-breaker, the whole kits (6 or 8 pieces) or half-kits (3 or 4 pieces) can be requested. In the case of a mixed solution, the first code indicates the terminals to be mounted in the top part of the circuit-breaker, whereas the second code indicates the terminals to be mounted in the lower part. However, when only 3 or 4 pieces are requested, you must expressly specify whether the half-kit is to be mounted at the top or at the bottom. The fixed parts of plug-in and withdrawable version circuit-breakers can be fitted with the terminals (EF or HR/VR) specifically for the fixed parts, or with the same terminals used for the fixed version (ES, FCCu, FCCuAl, MC, FB) after the installation of the specific adapter for the fixed part.

XT1B 160A 3p fixed with EF top and FCCuAl bottom terminals for 240mm² cables

	1SDA...R1
XT1B 160 TMD 160-1600 3p F F	066809
EF Extended front terminals 3 pieces	066865
FCCuAl Terminals for Copper/Aluminium cables 1x95...240mm ² 3 pieces	067159

XT1 plug-in with EF top and HR/VR bottom terminals

	1SDA...R1
XT1B 160 TMD 160-1600 3p F F	066809
KIT P PF EF (Fixed part of plug-in with EF terminals)	068183
KIT P MP (Kit for conversion from Fixed to Moving Part of Plug-in version)	066276
R - Rear HR/VR terminals (terminals for the fixed parts)	066268

XT2 withdrawable with ES top and MC bottom terminals

	1SDA...R1
XT2S 160 TMA 160-1600 3p F F	067560
KIT W PF EF (Fixed part of withdrawable with EF extended front terminals)	068200
KIT W MP (Kit for conversion from Fixed to Moving Part of Withdrawable version)	066284
ADP Adapter for mounting terminals of the fixed version on the fixed part (2 pieces)	066307
ES Extended spread front terminals	066893
MC Multic-cable terminals 6x2.5...35mm ²	066925

EXAMPLE 2: Electrical accessories for plug-in circuit-breaker

With the plug-in version circuit-breakers, disconnection of the auxiliary circuits can be made by means of two types of connectors:

- socket plug adapter to be fixed at the back of the panel for XT1, XT2, XT3 and XT4;
- socket plug adapter placed in the fixed part of plug-in and on the rear of the circuit-breaker for XT2 and XT4.

XT2N in plug-in version with SOR, AUX 1Q+1SY, connector on rear of panel

	1SDA...R1
XT2N 160 TMA 160-1600 3p F F	067560
KIT P MP	066278
KIT P PF EF (Fixed part of plug-in with EF terminals)	068187
SOR-C 220-240V AC / 220-250V DC	066325
AUX-C 1Q+1SY 250V AC	066431
Socket plug connector for panel with 9PINS	066411

XT2N in plug-in version with SOR, AUX 1Q+1SY, connector on rear of circuit-breaker

	1SDA...R1
XT2N 160 TMA 160-1600 3p F F	067560
KIT P MP	066278
KIT P PF EF (Fixed part of plug-in with EF terminals)	068187
SOR-C 220-240V AC / 220-250V DC	066325
AUX-C 1Q+1SY 250V	066431
SOCKET-PLUG CONNECTOR MP 12PINS XT2-XT4	066413
SOCKET-PLUG CONNECTOR FP 12PINS XT2-XT4	066414

EXAMPLE 3: Electrical accessories for withdrawable version

With the circuit-breakers in the withdrawable version it is necessary to only and exclusively order the accessories dedicated to this version. The electrical accessories specified for the withdrawable version are fitted both with the connector for fixed part to be installed in the side of the fixed part, and with the connector for the moving part.

XT2N in withdrawable version with SOR, AUX 1Q+1SY, RHD

	1SDA...R1
XT2N 160 TMA 160-1600 3p F F	067560
KIT W PF EF (Fixed part of withdrawable with EF terminals)	068200
KIT W MP (Kit for conversion from fixed to withdrawable version)	066284
SOR-C 220-240V AC / 220-250V DC for Withdrawable	066332
AUX-C 1Q+1SY 250V for Withdrawable	066432
RHD Normal Direct Handle for Withdrawable	066476

EXAMPLE 4: Connector for 4th pole of withdrawable circuit-breaker

Should it be necessary to insert a SOR, a UVR, or a PS-SOR in the slot of the fourth pole of a withdrawable version circuit-breaker, it is necessary to order the connector for 4th pole of withdrawable circuit-breaker.

XT2S 4p Withdrawable with SOR(4p), UVR(3p)

	1SDA...R1
XT2S 160 TMA 160-1600 4p F F	067583
KIT W PF EF (Fixed part of withdrawable with EF terminals)	068202
KIT W MP (Kit for conversion from fixed to withdrawable version)	066285
Connector 4th Pole SOR-PS-SOR	066415
SOR-C 220-240V AC / 220-250V DC for Withdrawable	066332
UVR-C 220-240V AC / 220-250V DC for Withdrawable	066406

EXAMPLE 5: Rear mechanical interlock

The rear interlock is made up of the (horizontal) MIR-H or (vertical) MIR-V frame unit and the MIR-P plates. To be able to receive the circuit-breakers directly mounted on the interlock plate, it is necessary to specify:

- the sales code of the frame;
- the sales codes of the plates associated with the circuit-breakers/fixed parts which are to be interlocked.

Horizontal mechanical interlock XT1 - XT1 in fixed version

	1SDA...R1
Pos. 1	XT1B TMD 160-1600A, 3p
	MIR-H - Horizontal mechanical interlock
	PLATE - XT1 Fixed
Pos. 2	XT1B TMD 160-1600A, 3p
	PLATE - XT1 Fixed

Ordering codes for XT1

Circuit-breakers



XT1 circuit-breaker

XT1 160 TMD /TMF - Fixed (F) - 3 poles - Front terminals (F)

Thermomagnetic trip unit - TMD /TMF			I _{cu} (415V)	1SDA...R1				
	In	I _s		B	C	N	S	H
				18kA	25kA	36kA	50kA	70kA
TMD/TMF	16	450		066799	080825	080827*	080830*	080835*
TMD/TMF	20	450		066800	080826	080828*	080831*	080836*
TMD	25	450		066801	067391	080829	080832	080837
TMD	32	450		066802	067392	067411	080833	080838
TMD	40	450		066803	067393	067412	080834	080839
TMD	50	500		066804	067394	067413	067431	067449
TMD	63	630		066805	067395	067414	067432	067450
TMD	80	800		066806	067396	067415	067433	067451
TMD	100	1000		066807	067397	067416	067434	067452
TMD	125	1250		066808	067398	067417	067435	067453
TMD	160	1600		066809	067399	067418	067436	067454

* TMF trip unit

XT1 160 TMD /TMF - Fixed (F) - 4 poles - Front terminals (F)

Thermomagnetic trip unit - TMD /TMF			I _{cu} (415V)	1SDA...R1				
	In	I _s		B	C	N	S	H
				18kA	25kA	36kA	50kA	70kA
TMD/TMF	16	450		066810	080840	080842*	080845*	080850*
TMD/TMF	20	450		066811	080841	080843*	080846*	080851*
TMD	25	450		066812	067400	080844	080847	080852
TMD	32	450		066813	067401	067419	080848	080853
TMD	40	450		066814	067402	067420	080849	080854
TMD	50	500		066815	067403	067421	067439	067457
TMD	63	630		066816	067404	067422	067440	067458
TMD	80	800		066817	067405	067423	067441	067459
TMD	100	1000		066818	067406	067424	067442	067460
In N=50%	125	1250		066819	067407	067425	067443	067461
In N=50%	160	1600		066820	067408	067426	067444	067462
In N=100%	125	1250		066888	067409	067427	067445	067463
In N=100%	160	1600		066821	067410	067428	067446	067464

* TMF trip unit

XT1 160 MA - Fixed (F) - 3 poles - Front terminals (F)

Magnetic only trip unit - MA			1SDA...R1	
	In	I _s	N	
			36kA ⁽¹⁾	
MA	3.2	13...35	080855	
MA	6.3	25...69	080856	
MA	16	48...176	080857	
MA	32	96...352	080858	
MA	52	156...572	080859	
MA	63	189...693	080860	
MA	80	240...880	080861	
MA	100	360...1100	080862	
MA	125	375...1375	080863	

(1) I_{cu}@415V = 5kA In<16A



XT1D switch-disconnector

XT1D - Switch-disconnector

		1SDA...R1	
		3 poles	4 poles
XT1D		068208	068209

Ordering codes for XT1

Accessories

Fixed Parts, conversion kit and accessories for fixed parts



Fixed part of plug-in

Fixed part of plug-in (P)

Type	1SDA...R1		
	3 poles		4 poles
Kit P PF EF	068183		068185
Kit P PF HR/VR ⁽¹⁾	068184		068186

⁽¹⁾ The terminals are factory-mounted in the horizontal position (HR)

Terminals for the fixed parts

Type	1SDA...R1		
	3 pcs	4 pcs	6 pcs
EF - Front Extended terminals	066260	066261	
R - Rear terminals HR/VR	066268	066269	
PS - Rear phase separators 90mm		068953	068954



Conversion kit for turning a fixed circuit-breaker into the moving part of a plug-in circuit-breaker

Conversion kit of the circuit-breaker from fixed into moving part of plug-in

Type	1SDA...R1		
	3 poles		4 poles
P MP KIT	066276		066277



Fixed part adapter

Adapter for mounting the terminals of the fixed circuit-breaker on the fixed part

Type	1SDA...R1		
	3 poles		4 poles
ADP adapter for fixed part (2 pieces)	066305		066306

Note: when use ADP with F/EF/MC terminal, order also "Kit F Front Terminals" - see page 7/11

Service releases

Shunt Opening release -SOR-

Type	1SDA...R1	
Uncabled Version		
SOR 12V DC	066313	
SOR 24-30V AC/DC	066314	
SOR 48-60V AC/DC	066315	
SOR 110...127V AC / 110...125V DC	066316	
SOR 220...240V AC / 220...250V DC	066317	
SOR 380-440V AC	066318	
SOR 480-525V AC	066319	
Cabled Version		
SOR-C 12V DC	066321	
SOR-C 24-30V AC/DC	066322	
SOR-C 48-60V AC/DC	066323	
SOR-C 110-127V AC / 110-125V DC	066324	
SOR-C 220-240V AC / 220-250V DC	066325	
SOR-C 380-440V AC	066326	
SOR-C 480-525V AC	066327	



SOR uncabled



SOR cabled



YO Test Unit

YO Test Unit

Type	1SDA...R1
YO Test Unit	050228

Ordering codes for XT1

Accessories



PS-SOR uncabled



PS-SOR cabled



UVR uncabled



UVR cabled



Time delay device for undervoltage release

Shunt Opening release with permanent operation -PS -SOR-

Type	1SDA...R1	
Uncabled Version		
PS-SOR 24-30V AC/DC	066336	
PS-SOR 48V AC/DC	066295	
PS-SOR 60V AC/DC	066337	
PS-SOR 110...127V AC / 110...125V DC	066338	
PS-SOR 220...240V AC / 220...250V DC	066339	
PS-SOR 380-440V AC	066340	
PS-SOR 480-525V AC	066341	
Cabled Version		
PS-SOR-C 24-30V AC/DC	066343	
PS-SOR-C 48V AC/DC	066296	
PS-SOR-C 60V AC/DC	066344	
PS-SOR-C 110-127V AC / 110-125V DC	066345	
PS-SOR-C 220-240V AC / 220-250V DC	066346	
PS-SOR-C 380-440V AC	066347	
PS-SOR-C 480-525V AC	066348	

Undervoltage release -UVR-

Type	1SDA...R1	
Uncabled Version		
UVR 24-30V AC/DC	066389	
UVR 48V AC/DC	069064	
UVR 60V AC/DC	066390	
UVR 110...127V AC / 110...125V DC	066391	
UVR 220...240V AC / 220...250V DC	066392	
UVR 380-440V AC	066393	
UVR 480-525V AC	066394	
Cabled Version		
UVR-C 24-30V AC/DC	066396	
UVR-C 48V AC/DC	069065	
UVR-C 60V AC/DC	066397	
UVR-C 110-127V AC / 110-125V DC	066398	
UVR-C 220-240V AC / 220-250V DC	066399	
UVR-C 380-440V AC	066400	
UVR-C 480-525V AC	066401	

Delay device for undervoltage release -UVD-

Type	1SDA...R1	
UVD 24...30V AC/DC	051357	
UVD 48...60V AC/DC	051358	
UVD 110...125V AC/DC	051360	
UVD 220...250V AC/DC	051361	



Socket Plug Connector

Connectors

Socket Plug Connector on rear of panel

Type	1SDA...R1	
Socket-plug panel connector with 3PINS	066409	
Socket-plug panel connector with 6PINS	066410	
Socket-plug panel connector with 9PINS	066411	
Socket-plug panel connector with 15PINS	066412	



AUX uncabled



AUX cabled

Electrical signals

Auxiliary Contacts -AUX-

Type	1SDA...R1	
Uncabled Version		
AUX 250V AC	066422	
AUX 24V DC	066423	
Cabled Version		
AUX-C 3Q 250V Left	066426	
AUX-C 1Q+1SY 250V	066431	
AUX-C 2Q+1SY 250V	066433	
AUX-C 1Q+1SY 24V DC	066446	



AUP - Auxiliary position contacts

Auxiliary Position Contacts -AUP-

Type	1SDA...R1	
Cabled Version		
AUP-I – Four Racked-in contacts 250V AC for plug-in circuit-breaker	066450	
AUP-I – Four Racked-in contacts 24V DC for plug-in circuit-breaker	066451	



AUE - Early auxiliary contacts

Early Auxiliary Contacts -AUE-

Type	1SDA...R1	
AUE – Two contacts in the rotary handle RHx (Closed)	066454	
AUE – Two contacts in the rotary handle RHx (Open)	067118	

Ordering codes for XT1

Accessories



Motor operator

Motor Operators

Motor Operator with direct action -MOD-

Type	1SDA...R1	
MOD 24V DC	066457	
MOD 48...60V DC	066458	
MOD 110...125V AC/DC	066459	
MOD 220...250V AC/DC	066460	
MOD 380...440V AC	066461	
MOD 480...525V AC	066462	

Rotary Handle Operating Mechanisms

Rotary Handle Operating Mechanism

Type	1SDA...R1	
RHD Normal Direct Handle	066475	
RHD Direct Emergency Handle	066477	
RHE Normal Transmitted Handle	066479	
RHE Emergency Transmitted Handle	066481	
RHS-L Normal left lateral handle	066579	
RHS-L Emergency left lateral handle	066580	
RHS-R Normal right lateral handle	066581	
RHS-R Emergency right lateral handle	066582	
Transmitted Handle Spare Parts		
RHE_B Base for Transmitted Handle	066483	
RHE_S Rod of 500mm	066576	
RHE_H Normal Transmitted Handle	066577	
RHE_H Emergency Transmitted Handle	066578	
LH Normal large handle	066583	
LH Large emergency handle	066585	



Direct rotary handle



Transmitted rotary handle



IP54

IP54 Protection for transmitted rotary handle

Type	1SDA...R1	
IP54 PROTECTION for transmitted handle -RHE-	066587	



Fixed padlock



Key lock on the circuit-breaker



Key lock on the handle



Key lock on the motor



Interlock

Locks

Padlock on the circuit-breaker

Type	1SDA...R1	
PLL Removable lock with padlocks in open position	066588	
PLL Fixed lock with padlocks in open position	066589	
PLL Fixed lock with padlocks in open/closed position	066591	

Key lock on the circuit-breaker

Type	1SDA...R1	
KLC Ronis key lock open, different keys, removable in open position	066593	
KLC Ronis key lock open, same Type A keys, removable in open position	066594	
KLC Ronis key lock open, same Type B keys, removable in open position	066595	
KLC Ronis key lock open, same Type C keys, removable in open position	066596	
KLC Ronis key lock open, same Type D keys, removable in open position	066597	
KLC Ronis key lock open, same keys, removable in both position	066598	

Key lock on the handle

Type	1SDA...R1	
RHL Ronis key lock open, different keys - RHx	066617	
RHL Ronis key lock open, same Type A keys - RHx	066618	
RHL Ronis key lock open, same Type B keys - RHx	066619	
RHL Ronis key lock open, same Type C keys - RHx	066620	
RHL Ronis key lock open, same Type D keys - RHx	066621	
RHL Ronis key lock open/closed, different keys - RHx	066622	

Key lock on the motor

Type	1SDA...R1	
MOL-D Ronis key lock open, different keys	066623	
MOL-S Ronis key lock open, same Type A keys	066624	
MOL-S Ronis key lock open, same Type B keys	066625	
MOL-S Ronis key lock open, same Type C keys	066626	
MOL-S Ronis key lock open, same Type D keys	066627	

Mechanical interlock

Type	1SDA...R1	
MIR-H	066637	
MIR-V	066638	
Plate XT1 F	066639	
Plate XT1 P	066640	
Plate XT3 F	066643	
Plate XT3 P	066644	

Sealable Lock of Thermal Setting

Type	1SDA...R1	
Lock on thermal setting for TMD trip unit	066651	

Ordering codes for XT1

Accessories



RC Inst / RC Sel

Residual current devices

Residual current devices

Type	1SDA...R1			
	3 poles		4 poles	
RC Sel Low 200mm			067121	
RC Inst	067122		067124	
RC Sel	067123		067125	

Panel type residual current relay

Type	1SDA...R1			
RCQ020/A 115-230V AC			065979	
RCQ020/A 415V AC			065980	
Toroid closed Ø 60mm			037394	
Toroid closed Ø 110mm			037395	
Toroid closed Ø 185mm			050543	

Installation

Bracket for fixing onto DIN rail

Type	1SDA...R1			
	3 poles		4 poles	
KIT DIN50022	066652		066419	
DIN50022 KIT XT1+RC Low 200mm			067134	
KIT DIN50022 XT1+RC Sel/RC Inst	067135		067135	



DIN Guide

Terminals, terminal covers and phase separators

Insulating terminal covers

Type	1SDA...R1			
	3 poles		4 poles	
LTC Low terminal covers	066655		066656	
HTC High terminal covers	066664		066665	



Terminal covers



Sealable screw

Sealable screws for terminal covers

Type	1SDA...R1			
Kit (2 pcs) sealable screws			066672	



Phase separators



EF Terminal



FCCuAl Terminal

Phase separators

Type	1SDA...R1			
	4 pcs		6 pcs	
PB Height 25mm	066674		066679	
PS Height 100mm	066676		066681	
PS Height 200mm	066678		066683	

Terminals

Type	1SDA...R1			
	3 pcs	4 pcs	6 pcs	8 pcs
F Front Terminals	066849	066850	066851	066852
EF Extended front terminals	066865	066866	066867	066868
ES Extended spread front terminals	066889	066890	066891	066892
FC CuAl Terminals for CuAl cables 1x1.5...50mm ²	067151	067152	067153	067154
FC CuAl Terminals for CuAl cables 1x35...95mm ²	067155	067156	067157	067158
FC CuAl Terminals for CuAl cables 1x120...240mm ² + ADP	067159	067160	067161	067162
FC Cu Terminals for Cu cables	066905	066906	066907	066908
MC Multi-cable Terminals 6x2.5...35mm ²	066921	066922	066923	066924
R Rear Adjustable Terminals	066937	066938	066939	066940
R-RC Rear terminals for Residual current		066953		
FB Flexible busbar Terminals	066957	066958	066959	066960

Automatic transfer devices

ATS021- ATS022 Automatic transfer devices

Type	1SDA...R1	
ATS021	065523	
ATS022	065524	



ATS021

Spare parts

Type	1SDA...R1	
SA RC Sel / RC Inst - Opening solenoid of the residual current device	066990	
AUX-C - Loose cabled auxiliary contact 250V ⁽¹⁾	066994	
AUX-C - Loose cabled auxiliary contact 20V ⁽¹⁾	066996	

⁽¹⁾ un-numbered cables



Flange

Flange for compartment door

Type	1SDA...R1			
	3 poles		4 poles	
Small flange for circuit-breaker	068657		068657	
Large flange for circuit-breaker	068639		068640	
Flange MOD	068648		068648	
Flange for direct handle RHD	068651		068651	
Flange for residual current RC Sel / Inst	068653		068654	

Ordering codes for XT2

Circuit-breakers



XT2 circuit-breaker

XT2 160 TMD/TMA - Fixed (F) - 3 poles - Front terminals (F)

Thermomagnetic trip unit - TMD/TMA			I _{cu} (415V)	1SDA...R1				
	In	I _Δ		N	S	H	L	V
				36kA	50kA	70kA	120kA	150kA
TMD	1.6	16		067000	067540	067584	067628	067672
TMD	2	20		067001	067541	067585	067629	067673
TMD	2.5	25		067002	067542	067586	067630	067674
TMD	3.2	32		067003	067543	067587	067631	067675
TMD	4	40		067004	067544	067588	067632	067676
TMD	5	50		067005	067545	067589	067633	067677
TMD	6.3	63		067006	067546	067590	067634	067678
TMD	8	80		067007	067547	067591	067635	067679
TMD	10	100		067008	067548	067592	067636	067680
TMD	12.5	125		067009	067549	067593	067637	067681
TMD	16	300		067010	067550	067594	067638	067682
TMD	20	300		067011	067551	067595	067639	067683
TMD	25	300		067012	067552	067596	067640	067684
TMD	32	320		067013	067553	067597	067641	067685
TMA	40	400		067014	067554	067598	067642	067686
TMA	50	500		067015	067555	067599	067643	067687
TMA	63	630		067016	067556	067600	067644	067688
TMA	80	800		067017	067557	067601	067645	067689
TMA	100	1000		067018	067558	067602	067646	067690
TMA	125	1250		067019	067559	067603	067647	067691
TMA	160	1600		067020	067560	067604	067648	067692

XT2 160 TMD/TMA - Fixed (F) - 4 poles - Front terminals (F)

Thermomagnetic trip unit - TMD/TMA			I _{cu} (415V)	1SDA...R1				
	In	I _Δ		N	S	H	L	V
				36kA	50kA	70kA	120kA	150kA
TMD	1.6	16		067021	067561	067605	067649	067693
TMD	2	20		067022	067562	067606	067650	067694
TMD	2.5	25		067023	067563	067607	067651	067695
TMD	3.2	32		067024	067564	067608	067652	067696
TMD	4	40		067025	067565	067609	067653	067697
TMD	5	50		067026	067566	067610	067654	067698
TMD	6.3	63		067027	067567	067611	067655	067699
TMD	8	80		067028	067568	067612	067656	067700
TMD	10	100		067029	067569	067613	067657	067701
TMD	12.5	125		067030	067570	067614	067658	067702
TMD	16	300		067031	067571	067615	067659	067703
TMD	20	300		067032	067572	067616	067660	067704
TMD	25	300		067033	067573	067617	067661	067705
TMD	32	320		067034	067574	067618	067662	067706
TMA	40	400		067035	067575	067619	067663	067707
TMA	50	500		067036	067576	067620	067664	067708
TMA	63	630		067037	067577	067621	067665	067709
TMA	80	800		067038	067578	067622	067666	067710
TMA	100	1000		067039	067579	067623	067667	067711
TMA In N=50%	125	1250		067040	067580	067624	067668	067712
TMA In N=50%	160	1600		067041	067581	067625	067669	067713
TMA In N=100%	125	1250		067042	067582	067626	067670	067714
TMA In N=100%	160	1600		067043	067583	067627	067671	067715



XT2 circuit-breaker

XT2 160 TMG - Fixed (F) - 3 poles - Front terminals (F)

Thermomagnetic trip unit - TMG			Icu (415V)	1SDA...R1				
	In	I _Δ		N	S			
				36kA	50kA			
TMG	16	160		067716	067738			
TMG	20	160		067717	067739			
TMG	25	160		067718	067740			
TMG	32	160		067719	067741			
TMG	40	160		067720	067742			
TMG	50	200		067721	067743			
TMG	63	200		067722	067744			
TMG	80	240		067723	067745			
TMG	100	300		067724	067746			
TMG	125	375		067725	067747			
TMG	160	480		067726	067748			

XT2 160 TMG - Fixed (F) - 4 poles - Front terminals (F)

Thermomagnetic trip unit - TMG			Icu (415V)	1SDA...R1				
	In	I _Δ		N	S			
				36kA	50kA			
TMG	16	160		067727	067749			
TMG	20	160		067728	067750			
TMG	25	160		067729	067751			
TMG	32	160		067730	067752			
TMG	40	160		067731	067753			
TMG	50	200		067732	067754			
TMG	63	200		067733	067755			
TMG	80	240		067734	067756			
TMG	100	300		067735	067757			
TMG	125	375		067736	067758			
TMG	160	480		067737	067759			

XT2 160 MF/MA - Fixed (F) - 3 poles - Front terminals (F)

Thermomagnetic trip unit - MF/MA			Icu (415V)	1SDA...R1				
	In	I _Δ		N	S	H	L	V
				36kA	50kA	70kA	120kA	150kA
MF	1	14		067044	067760	067770	067780	067790
MF	2	28		067045	067761	067771	067781	067791
MF	4	56		067046	067762	067772	067782	067792
MF	8.5	120		067047	067763	067773	067783	067793
MF	12.5	175		067048	067764	067774	067784	067794
MA	20	120...280		067049	067765	067775	067785	067795
MA	32	192...448		067050	067766	067776	067786	067796
MA	52	314...728		067051	067767	067777	067787	067797
MA	80	480...1120		067052	067768	067778	067788	067798
MA	100	600...1400		067053	067769	067779	067789	067799
MA	160	960...2240		076529	076530	076535	076536	076537

Ordering codes for XT2

Circuit-breakers



XT2 circuit-breaker

XT2 160 Ekip LS/I - Fixed (F) - 3 poles - Front terminals (F)

Electronic trip unit - Ekip LS/I			Icu (415V)	1SDA...R1				
	In			N	S	H	L	V
			36kA	50kA	70kA	120kA	150kA	
Ekip LS/I	10		067054	067800	067857	067914	067971	
Ekip LS/I	25		067055	067801	067858	067915	067972	
Ekip LS/I	63		067056	067802	067859	067916	067973	
Ekip LS/I	100		067057	067803	067860	067917	067974	
Ekip LS/I	160		067058	067804	067861	067918	067975	

XT2 160 Ekip I - Fixed (F) - 3 poles - Front terminals (F)

Electronic trip unit - Ekip I			Icu (415V)	1SDA...R1				
	In			N	S	H	L	V
			36kA	50kA	70kA	120kA	150kA	
Ekip I	10		067059	067805	067862	067919	067976	
Ekip I	25		067060	067806	067863	067920	067977	
Ekip I	63		067061	067807	067864	067921	067978	
Ekip I	100		067062	067808	067865	067922	067979	
Ekip I	160		067063	067809	067866	067923	067980	

XT2 160 Ekip LSI - Fixed (F) - 3 poles - Front terminals (F)

Electronic trip unit - Ekip LSI		Icu (415V)	1SDA...R1				
	In		N	S	H	L	V
			36kA	50kA	70kA	120kA	150kA
Ekip LSI	10		067067	067810	067867	067924	067981
Ekip LSI	25		067068	067811	067868	067925	067982
Ekip LSI	63		067069	067812	067869	067926	067983
Ekip LSI	100		067070	067813	067870	067927	067984
Ekip LSI	160		067071	067814	067871	067928	067985

XT2 160 Ekip LSIG - Fixed (F) - 3 poles - Front terminals (F)

Electronic trip unit - Ekip LSIG			Icu (415V)	1SDA...R1				
				N	S	H	L	V
	In		36kA	50kA	70kA	120kA	150kA	
Ekip LSIG	10		067072	067815	067872	067929	067986	
Ekip LSIG	25		067073	067816	067873	067930	067987	
Ekip LSIG	63		067074	067817	067874	067931	067988	
Ekip LSIG	100		067075	067818	067875	067932	067989	
Ekip LSIG	160		067076	067819	067876	067933	067990	

XT2 160 Ekip M-I - Fixed (F) - 3 poles - Front terminals (F)

Electronic trip unit - Ekip M-I			Icu (415V)	1SDA...R1				
	In			N	S	H	L	V
			36kA		50kA	70kA	120kA	150kA
Ekip M-I	20		067086		067829	067886	067943	068000
Ekip M-I	32		067087		067830	067887	067944	068001
Ekip M-I	52		067088		067831	067888	067945	068002
Ekip M-I	100		067089		067832	067889	067946	068003



XT2 circuit-breaker

XT2 160 Ekip LS/I - Fixed (F) - 4 poles - Front terminals (F)

Electronic trip unit - Ekip LS/I		Icu (415V)	1SDA...R1					
	In		N	S	H	L	V	
			36kA	50kA	70kA	120kA	150kA	
Ekip LS/I	10		067090	067833	067890	067947	068004	
Ekip LS/I	25		067091	067834	067891	067948	068005	
Ekip LS/I	63		067092	067835	067892	067949	068006	
Ekip LS/I	100		067093	067836	067893	067950	068007	
Ekip LS/I	160		067095	067838	067895	067952	068009	

XT2 160 Ekip I - Fixed (F) - 4 poles - Front terminals (F)

Electronic trip unit - Ekip I		Icu (415V)	1SDA...R1					
	In		N	S	H	L	V	
			36kA	50kA	70kA	120kA	150kA	
Ekip I	10		067096	067839	067896	067953	068010	
Ekip I	25		067097	067840	067897	067954	068011	
Ekip I	63		067098	067841	067898	067955	068012	
Ekip I	100		067099	067842	067899	067956	068013	
Ekip I	160		067101	067844	067901	067958	068015	

XT2 160 Ekip LSI - Fixed (F) - 4 poles - Front terminals (F)

Electronic trip unit - Ekip LSI		Icu (415V)	1SDA...R1					
	In		N	S	H	L	V	
			36kA	50kA	70kA	120kA	150kA	
Ekip LSI	10		067102	067845	067902	067959	068016	
Ekip LSI	25		067103	067846	067903	067960	068017	
Ekip LSI	63		067104	067847	067904	067961	068018	
Ekip LSI	100		067105	067848	067905	067962	068019	
Ekip LSI	160		067107	067850	067907	067964	068021	

XT2 160 Ekip LSIG - Fixed (F) - 4 poles - Front terminals (F)

Electronic trip unit - Ekip LSIG		Icu (415V)	1SDA...R1					
	In		N	S	H	L	V	
			36kA	50kA	70kA	120kA	150kA	
Ekip LSIG	10		067108	067851	067908	067965	068022	
Ekip LSIG	25		067109	067852	067909	067966	068023	
Ekip LSIG	63		067110	067853	067910	067967	068024	
Ekip LSIG	100		067111	067854	067911	067968	068025	
Ekip LSIG	160		067113	067856	067913	067970	068027	

Ordering codes for XT2

Circuit-breakers

XT2 160 - Breaking part

	1SDA...R1				
	N	S	H	L	V
3 poles	068163	068164	068165	068166	068167
4 poles	068168	068169	068170	068171	068172



Loose trip unit

Loose trip units XT2

Thermomagnetic - TMA/TMD

	In	I _Δ	1SDA...R1					
			3 poles	4 poles				
TMD	16	300	067226	067247				
TMD	20	300	067227	067248				
TMD	25	300	067228	067249				
TMD	32	320	067229	067250				
TMA	40	400	067230	067251				
TMA	50	500	067231	067252				
TMA	63	630	067232	067253				
TMA	80	800	067233	067254				
TMA	100	1000	067234	067255				
TMA	125	1250	067235	067258				
TMA	160	1600	067236	067259				
TMA In N=50%	125	1250		067256				
TMA In N=50%	160	1600		067257				

Loose trip units XT2

Thermomagnetic - TMG

	In	I _Δ	1SDA...R1					
			3 poles	4 poles				
TMG	80	240	067267	067278				
TMG	100	300	067268	067279				
TMG	125	375	067269	067280				
TMG	160	480	067270	067283				

Loose trip units XT2

Thermomagnetic - MA

	In	I _Δ	1SDA...R1					
			3 poles					
MA	20	120...280	067290					
MA	32	192...448	067291					
MA	52	314...728	067292					
MA	80	480...1120	067293					
MA	100	600...1400	067294					
MA	160	960...2240	076538					



Loose trip unit

Loose trip units XT2

Electronic - Ekip LS/I			1SDA...R1					
			3 poles	4 poles				
	In							
Ekip LS/I	25		067296	067329				
Ekip LS/I	63		067297	067330				
Ekip LS/I	100		067298	067331				
Ekip LS/I	160		067299	067333				

Loose trip units XT2

Electronic - Ekip I			1SDA...R1					
			3 poles	4 poles				
	In							
Ekip I	25		067301	067335				
Ekip I	63		067302	067336				
Ekip I	100		067303	067337				
Ekip I	160		067304	067339				

Loose trip units XT2

Electronic - Ekip LSI			1SDA...R1					
			3 poles	4 poles				
	In							
Ekip LSI	25		067306	067341				
Ekip LSI	63		067307	067342				
Ekip LSI	100		067308	067343				
Ekip LSI	160		067309	067345				

Loose trip units XT2

Electronic - Ekip LSIG			1SDA...R1					
			3 poles	4 poles				
	In							
Ekip LSIG	25		067311	067347				
Ekip LSIG	63		067312	067348				
Ekip LSIG	100		067313	068052				
Ekip LSIG	160		067314	067350				

Loose trip units XT2

Electronic - Ekip M-I			1SDA...R1					
			3 poles					
	In							
Ekip M-I	20		067324					
Ekip M-I	32		067325					
Ekip M-I	52		067326					
Ekip M-I	100		067327					

Ordering codes for XT2

Circuit-breakers



Loose trip unit

Loose trip units XT2

Electronic - Ekip M-LIU

			1SDA...R1					
			3 poles					
	In							
Ekip M-LIU	25		067352					
Ekip M-LIU	63		067353					
Ekip M-LIU	100		067354					
Ekip M-LIU	160		067355					

Loose trip units XT2

Electronic - Ekip M-LRIU

			1SDA...R1					
			3 poles					
	In							
Ekip M-LRIU	25		067357					
Ekip M-LRIU	63		067358					
Ekip M-LRIU	100		067359					

Loose trip units XT2

Electronic - Ekip G-LS/I

			1SDA...R1					
			3 poles	4 poles				
	In							
Ekip G-LS/I	25		067362	067368				
Ekip G-LS/I	63		067363	067369				
Ekip G-LS/I	100		067364	067370				
Ekip G-LS/I	160		067365	067372				

Loose trip units XT2

Electronic - Ekip N-LS/I

			1SDA...R1					
				4 poles				
	In							
Ekip N-LS/I	63			067375				
Ekip N-LS/I	100			067376				

Ordering codes for XT2

Accessories



Fixed part of plug-in



Fixed part of withdrawable



Conversion kit for turning a fixed circuit-breaker into the moving part of a plug-in circuit-breaker



Conversion kit for turning a fixed circuit-breaker into the moving part of a withdrawable circuit-breaker

Fixed parts, conversion kit and accessories for fixed parts

Fixed part of plug-in (P)

Type	1SDA...R1			
	3 poles		4 poles	
Kit P PF EF	068187		068190	
Kit P PF HR/VR ⁽¹⁾	068189		068191	

⁽¹⁾ The terminals are factory-mounted in the horizontal position (HR)

Fixed part of withdrawable (W)

Type	1SDA...R1			
	3 poles		4 poles	
Kit W PF EF	068200		068202	
Kit W PF HR/VR ⁽¹⁾	068201		068203	

⁽¹⁾ The terminals are factory-mounted in the horizontal position (HR)

Terminals for the fixed parts

Type	1SDA...R1					
	3 pcs		4 pcs		6 pcs	
EF - Front Extended Terminals	066262		066263			
R - Rear Terminals HR/VR	066270		066271			
PS - Rear phase separators 90mm			068953		068954	

Conversion Kit of the circuit-breaker from fixed to the moving part of plug-in

Type	1SDA...R1			
	3 poles		4 poles	
P MP KIT	066278		066279	

Conversion Kit of the circuit-breaker from fixed to the moving part of withdrawable

Type	1SDA...R1			
	3 poles		4 poles	
W MP KIT	066284		066285	

Conversion Kit of the fixed part from plug-in to withdrawable

Type	1SDA...R1	
FP P>W KIT	066288	

Conversion Kit of RC Sel from Fixed to Plug-in

Type	1SDA...R1	
	4 poles	
P MP RC Sel 4p KIT	066290	

Ordering codes for XT2

Accessories

Conversion Kit of RC Sel from plug-in to withdrawable

Type	1SDA...R1	
	4 poles	
W MP RC Sel 4p KIT	066292	

Key lock for fixed part of withdrawable

Type	1SDA...R1	
KL-D Key Lock FP, different keys	066293	
KL-S Key Lock FP, same keys N.20005	066294	

Ronis key lock for fixed part of withdrawable

Type	1SDA...R1	
KL-D Ronis FP key lock, different keys	066298	
KL-S Ronis FP key lock, same Type A keys	066300	

Adapter for mounting the terminals of the fixed circuit-breaker on the fixed part

Type	1SDA...R1		
	3 poles		4 poles
ADP Adapter fixed part (2 pieces)	066307		066308

Note: when use ADP with F/EF/MC terminal, order also "Kit F Front Terminals" - see page 7/27

Service releases

Shunt opening release -SOR-

Type	1SDA...R1	
	Fixed/Plug-in	Withdrawable
Uncabled Version		
SOR 12V DC	066313	
SOR 24-30V AC/DC	066314	
SOR 48-60V AC/DC	066315	
SOR 110...127V AC / 110...125V DC	066316	
SOR 220...240V AC / 220...250V DC	066317	
SOR 380-440V AC	066318	
SOR 480-525V AC	066319	
Cabled Version		
SOR-C 12V DC	066321	066328
SOR-C 24-30V AC/DC	066322	066329
SOR-C 48-60V AC/DC	066323	066330
SOR-C 110-127V AC / 110-125V DC	066324	066331
SOR-C 220-240V AC / 220-250V DC	066325	066332
SOR-C 380-440V AC	066326	066333
SOR-C 480-525V AC	066327	066334

YO Test Unit

Type	1SDA...R1	
YO Test Unit	050228	



Key lock/Padlock for fixed part



Ronis key lock/Padlock for fixed part



Fixed part adapter



SOR uncabled



SOR cabled



SOR for withdrawable



YO Test Unit



PS-SOR uncabled



PS-SOR cabled



PS-SOR for withdrawable

Shunt Opening release with permanent operation -PS -SOR-

Type	1SDA...R1		
	Fixed/Plug-in		Withdrawable
Uncabled Version			
PS-SOR 24-30V AC/DC	066336		
PS-SOR 48V AC/DC	066295		
PS-SOR 60V AC/DC	066337		
PS-SOR 110...127V AC / 110...125V DC	066338		
PS-SOR 220...240V AC / 220...250V DC	066339		
PS-SOR 380-440V AC	066340		
PS-SOR 480-525V AC	066341		
Cabled Version			
PS-SOR-C 24-30V AC/DC	066343		066350
PS-SOR-C 48V AC/DC	066296		066297
PS-SOR-C 60V AC/DC	066344		066351
PS-SOR-C 110-127V AC / 110-125V DC	066345		066352
PS-SOR-C 220-240V AC / 220-250V DC	066346		066354
PS-SOR-C 380-440V AC	066347		066355
PS-SOR-C 480-525V AC	066348		066356



UVR uncabled



UVR cabled



UVR for withdrawable

Undervoltage release -UVR-

Type	1SDA...R1		
	Fixed/Plug-in		Withdrawable
Uncabled Version			
UVR 24-30V AC/DC	066389		
UVR 48V AC/DC	069064		
UVR 60V AC/DC	066390		
UVR 110...127V AC / 110...125V DC	066391		
UVR 220...240V AC / 220...250V DC	066392		
UVR 380-440V AC	066393		
UVR 480-525V AC	066394		
Cabled Version			
UVR-C 24-30V AC/DC	066396		066403
UVR-C 48V AC/DC	069065		069066
UVR-C 60V AC/DC	066397		066404
UVR-C 110-127V AC / 110-125V DC	066398		066405
UVR-C 220-240V AC / 220-250V DC	066399		066406
UVR-C 380-440V AC	066400		066407
UVR-C 480-525V AC	066401		066408



Time delay device for undervoltage release

Delay device for undervoltage release -UVD-

Type	1SDA...R1	
UVD 24...30V AC/DC	051357	
UVD 48...60V AC/DC	051358	
UVD 110...125V AC/DC	051360	
UVD 220...250V AC/DC	051361	

Ordering codes for XT2

Accessories

Connectors

Connector of fourth pole for Withdrawable

Type	1SDA...R1	
Connector 4 th Pole SOR-PS-SOR	066415	
Connector 4 th Pole UVR	066418	

Socket-Plug Connector on rear of panel

Type	1SDA...R1	
Socket-plug panel connector with 3PINS	066409	
Socket-plug panel connector with 6PINS	066410	
Socket-plug panel connector with 9PINS	066411	
Socket-plug panel connector with 15PINS	066412	

Fixed part socket-plug connector

Type	1SDA...R1	
Socket-plug connector of Moving Part 12PINS	066413	
Socket-plug connector of Fixed Part 12PINS	066414	

Electrical signals

Auxiliary Contacts -AUX-

Type	1SDA...R1			
	Fixed/Plug-in		Withdrawable	
Uncabled Version				
AUX 24V DC	066423			
AUX-SA 24V DC	066425			
AUX 250V AC	066422			
AUX-SA 250V AC	066424			
Cabled Version				
AUX-SA-C 24V DC	067116		067117	
AUX-C 1Q+1SY 24V DC	066446		066447	
AUX-C 3Q+1SY 24V DC	066448		066449	
AUX-SA-C 250V AC	066429		066430	
AUX-C 1Q+1SY 250V AC	066431		066432	
AUX-C 2Q+1SY 250V AC	066433			
AUX-C 2Q+2SY+1SA 250V AC	066438		066439	
AUX-C 3Q 250V AC Left	066427			
AUX-C 3Q+1SY 250V AC	066434		066435	
AUX-C 3Q+2SY 250V AC	066436		066437	
AUX-C 1Q+1SY 400V AC	066444		066445	
AUX-C 2Q 400V AC	066440		066443	



Socket-plug panel connector



Fixed part socket-plug connector



AUX uncabled

AUX cabled

AUX for withdrawable



AUP - Auxiliary position contacts

Auxiliary Position Contacts -AUP-

Type	1SDA...R1	
Cabled Version		
AUP-I – Four Racked-in contacts 250V AC for plug-in/withdrawable circuit-breaker	066450	
AUP-I – Four Racked-in contacts 24V DC for plug-in/withdrawable circuit-breaker	066451	
AUP-R – Two Racked-out contacts 250V AC for withdrawable circuit-breaker	066452	
AUP-R – Two Racked-out contacts 24V DC for withdrawable circuit-breaker	066453	



AUE - Early auxiliary contacts

Early Auxiliary Contacts -AUE-

Type	1SDA...R1		
	Fixed/Plug-in		Withdrawable
AUE – Two contacts in the rotary handle RHx (Open)	067118		067119
AUE – Two contacts in the rotary handle RHx (Close)	066454		066455

Motor Operators



MOE - Motor operator

Stored energy Motor Operator MOE

Type	1SDA...R1	
MOE 24V DC	066463	
MOE 48...60V DC	066464	
MOE 110...125V AC/DC	066465	
MOE 220...250V AC/DC	066466	
MOE 380...440V AC	066467	
MOE 480...525V AC	066468	

Electronic stored energy motor operator MOE-E

Type	1SDA...R1	
MOE-E 24V DC	066469	
MOE-E 48...60V DC	066470	
MOE-E 110...125V AC/DC	066471	
MOE-E 220...250V AC/DC	066472	
MOE-E 380...440V AC	066473	
MOE-E 480...525V AC	066474	

Ordering codes for XT2

Accessories

Rotary Handle Operating Mechanism



Direct handle



Transmitted handle



IP54



Lateral handle

Fixed padlock

Rotary Handles

Type	1SDA...R1		
	Fixed/Plug-in	Withdrawable	
RHD Normal Direct Handle	069053		066476
RHD Direct Emergency Handle	069054		066478
RHE Normal Transmitted Handle	069055		066480
RHE Emergency Transmitted Handle	069056		066482
RHS L Normal Left Lateral Handle	069058		
RHS L Emergency Left Lateral Handle	069059		
RHS R Normal Right Lateral Handle	069060		
RHS R Emergency Right Lateral Handle	069061		
Transmitted Handle Spare Parts			
RHE_B Base for Transmitted Handle	069057		066484
RHE_S Rod of 500mm	066576		
RHE_H Normal Transmitted Handle	066577		
RHE_H Emergency Transmitted Handle	066578		
LH Wide Normal Handle	066583		
LH Wide Emergency Handle	066585		

IP54 Protection for transmitted rotary handle

Type	1SDA...R1	
IP54 protection for transmitted handle -RHE-	066587	

Locks

Lock and Padlocks on the circuit-breaker

Type	1SDA...R1	
PLL Fixed lock with padlocks in open position	066590	
PLL Fixed lock with padlocks in open/closed position	066592	



Key lock on the circuit-breaker

Key lock on the circuit-breaker

Type	1SDA...R1	
KLC Ronis key lock open, different keys, removable in open position	066599	
KLC Ronis key lock open, same Type A keys, removable in open position	066600	
KLC Ronis key lock open, same Type B keys, removable in open position	066601	
KLC Ronis key lock open, same Type C keys, removable in open position	066602	
KLC Ronis key lock open, same Type D keys, removable in open position	066603	
KLC Ronis key lock open, same keys, removable in both position	066604	



Key lock on the handle

Key lock on the handle / front for locks

Type	1SDA...R1	
RHL Ronis key lock open, different keys - RHx/FLD	066617	
RHL Ronis key lock open, same Type A keys - RHx/FLD	066618	
RHL Ronis key lock open, same Type B keys - RHx/FLD	066619	
RHL Ronis key lock open, same Type C keys - RHx/FLD	066620	
RHL Ronis key lock open, same Type D keys - RHx/FLD	066621	
RHL Ronis key lock open/closed, different keys - RHx	066622	
RHL Ronis key lock open/closed, different keys - FLD	069182	



Key lock on the motor

Key lock on the motor

Type	1SDA...R1	
MOL-D Ronis key lock open, different keys	066629	
MOL-S Ronis key lock open, same Type A keys	066630	
MOL-S Ronis key lock open, same Type B keys	066631	
MOL-S Ronis key lock open, same Type C keys	066632	
MOL-S Ronis key lock open, same Type D keys	066633	
MOL-M Key lock against manual operation	066634	



Front for locks

Front for FLD locks

Type	1SDA...R1	
	Fixed/Plug-in	Withdrawable
Front for FLD locks	066635	066636



Interlock

Mechanical interlock*

Type	1SDA...R1	
MIR-H	066637	
MIR-V	066638	
Plate XT2 F	066641	
Plate XT2 P/W	066642	
Plate XT4 F	066645	
Plate XT4 P/W	066646	

* If the CB interlocked has got a stored energy motor operator (MOE/MOE-E) a key lock between MOL-D and MOL-S is mandatory

Ordering codes for XT2

Accessories



RC Sel

Residual current devices

Residual current devices

Type	1SDA...R1	
	4 poles	
RC Sel	067126	

Panel type residual current relay

Type	1SDA...R1	
RCQ020/A 115-230V AC	065979	
RCQ020/A 415V AC	065980	
Toroid closed Ø 60mm	037394	
Toroid closed Ø 110mm	037395	
Toroid closed Ø 185mm	050543	



DIN guide

Installation

Bracket for fixing onto DIN rail

Type	1SDA...R1	
	3 poles	4 poles
DIN50022 KIT	066653	066653

Terminals, terminal cover and phase separators

Insulating terminal covers

Type	1SDA...R1	
	3 poles	4 poles
LTC Low terminal covers	066657	066659
HTC High terminal covers	066666	066667



Terminal cover

Sealable screws for terminal covers

Type	1SDA...R1	
Kit with two sealable screws	066672	



Sealable screw

Phase separators

Type	1SDA...R1	
	4 pcs	6 pcs
PB Height 25mm	069062	069063
PB Height 100mm	066675	066680
PB Height 200mm	066677	066682



Phase separators



EF Terminal



FCCuAl Terminal

Terminals

Type	1SDA...R1			
	3 pcs	4 pcs	6 pcs	8 pcs
F Front Terminals	066853	066854	066855	066856
EF Extended front terminals	066869	066870	066871	066872
ES Extended spread front terminals	066893	066894	066895	066896
FC CuAl Terminals for CuAl cables 1x1...95mm ²	067163	067164	067165	067166
FC CuAl Terminals for CuAl cables 1x70...185mm ²	067167	067168	067169	067170
FC CuAl Terminals for CuAl cables 1x120...240mm ² + ADP	067171	067172	067173	067174
FC CuAl Terminals for CuAl cables 2x35...95mm ²	067175	067176	067177	067178
FC Cu Terminals for Cu cables	066909	066910	066911	066912
MC Multi-cable Terminals 6x2.5...35mm ²	066925	066926	066927	066928
R Rear adjustable Terminals	066941	066942	066943	066944
FB Flexible busbar Terminals	066961	066962	066963	066964

Accessories for electronic trip units



Ekip Display



Ekip LED Meter

Type	1SDA...R1		
	Fixed/Plug-in	Withdrawable	
Ekip Display	068659	068659	
Ekip LED Meter	068660	068660	
Ekip Com	068661	068662	
Ekip Multimeter Display on front of switchboard	074192	074192	
PR212/CI Contactor control unit	050708	050708	
HMI030 Interface on front of panel	063143	063143	

CT External neutral

Type	1SDA...R1	
CT External neutral of 10A	067211	
CT External neutral of 25A	067212	
CT External neutral of 63A	069142	
CT External neutral of 100A	069143	
CT External neutral of 160A	069144	

Connection Kit

Type	1SDA...R1		
	Fixed/Plug-in	Withdrawable	
Kit of 24V DC auxiliary voltage for electronic trip units	066980	066981	
Kit for PTC Connection	066982	066983	
Kit for external neutral Connection	066984	066985	
Kit for PR212/CI Connection	066986	066987	

Test and Configuration Unit

Type	1SDA...R1	
Ekip TT Trip Test Unit	066988	
Ekip T&P Programming and test Unit	066989	



Ekip T&P unit

Ordering codes for XT2

Accessories



ATS021

Automatic transfer devices

ATS021- ATS022 Automatic transfer devices

Type	1SDA...R1	
ATS021	065523	
ATS022	065524	

Spare parts

Type	1SDA...R1	
	Fixed/Plug-in	Withdrawable
SA RC Sel - Opening solenoid of the residual current device	066991	066993
AUX-C -Loose cabled Auxilliary Contact 250V AC ⁽¹⁾	066994	066995
AUX-C -Loose cabled Auxilliary Contact 24V DC ⁽¹⁾	066996	066997

⁽¹⁾ un-numbered cables



Fixed/Moving part connector
for withdrawable

Fixed Part Connector for Withdrawable

Type	1SDA...R1	
1 connector for fixed part/moving part of withdrawable with 2 PINS for SOR/UVR up to 400V	067213	
1 connector for fixed part/moving part of withdrawable with 3 PINS for AUX up to 400V	067214	



Flange

Flange for Compartment door

Type	1SDA...R1			
	3 poles	4 poles	3 poles	4 poles
	Fixed/ Plug-in	Fixed/ Plug-in	With- drawable	With- drawable
Small flange for circuit-breaker	068657	068657		
Large flange for circuit-breaker	068641	068642		
Flange for MOE/MOE-E/FLD	068649	068649	068650	068650
Flange for direct handle RHD	068651	068651	068652	068652
Flange for residual current RC Sel		066647		066648

Ordering codes for XT3

Circuit-breakers



XT3 circuit-breaker

XT3 250 TMD - Fixed (F) - 3 poles - Front terminals (F)

Thermomagnetic trip unit - TMD			Icu (415V)	N		S		1SDA...R1			
In	I _Δ			36kA		50kA					
TMD	63	630		068053		068215					
TMD	80	800		068054		068216					
TMD	100	1000		068055		068217					
TMD	125	1250		068056		068218					
TMD	160	1600		068057		068219					
TMD	200	2000		068058		068220					
TMD	250	2500		068059		068221					

XT3 250 TMD - Fixed (F) - 4 poles - Front terminals (F)

Thermomagnetic trip unit - TMD			Icu (415V)	N		S		1SDA...R1			
In	I _Δ			36kA		50kA					
TMD	63	630		068060		068222					
TMD	80	800		068061		068223					
TMD	100	1000		068062		068224					
In N=50%	125	1250		068063		068225					
In N=50%	160	1600		068064		068226					
In N=50%	200	2000		068065		068227					
In N=50%	250	2500		068066		068228					
In N=100%	125	1250		068067		068229					
In N=100%	160	1600		068068		068230					
In N=100%	200	2000		068069		068231					
In N=100%	250	2500		068070		068232					

XT3 250 TMG - Fixed (F) - 3 poles - Front terminals (F)

Thermomagnetic trip unit - TMG			Icu (415V)	N		S		1SDA...R1			
In	I _Δ			36kA		50kA					
TMG	63	400		068251		068265					
TMG	80	400		068252		068266					
TMG	100	400		068253		068267					
TMG	125	400		068254		068268					
TMG	160	480		068255		068269					
TMG	200	600		068256		068270					
TMG	250	750		068257		068271					

XT3 250 TMG - Fixed (F) - 4 poles - Front terminals (F)

Thermomagnetic trip unit - TMG			Icu (415V)	N		S		1SDA...R1			
In	I _Δ			36kA		50kA					
TMG	63	400		068258		068272					
TMG	80	400		068259		068273					
TMG	100	400		068260		068274					
TMG	125	400		068261		068275					
TMG	160	480		068262		068276					
TMG	200	600		068263		068277					
TMG	250	750		068264		068278					

Ordering codes for XT3

Circuit-breakers



XT3 circuit-breaker

XT3 250 MA - Fixed (F) - 3 poles - Front terminals (F)									
Thermomagnetic trip unit - MA			Icu (415V)	1SDA...R1					
	In	I _Δ		N	S				
				36kA	50kA				
MA	100	600...1200		068071	068279				
MA	125	750...1500		068072	068280				
MA	160	960...1920		068073	068281				
MA	200	1200...2400		068074	068282				



XT3D switch-disconnector

XT3D - Switch-disconnector			
		1SDA...R1	
		3 poles	4 poles
XT3D		068210	068211

Ordering codes for XT3

Accessories

Fixed parts, conversion kit and accessories for fixed parts



Fixed part of plug-in



Conversion kit for turning a fixed circuit-breaker into the moving part of a plug-in circuit-breaker



Fixed part adapter



SOR uncabled



SOR cabled



YO Test Unit

Fixed part of plug-in (P)

Type	1SDA...R1		
	3 poles		4 poles
Kit P PF EF	068192		068194
Kit P PF HR/VR ⁽¹⁾	068193		068195

⁽¹⁾ The terminals are factory-mounted in the horizontal position (HR)

Terminals for the fixed parts

Type	1SDA...R1		
	3 pcs	4 pcs	6 pcs
EF - Front Extended Terminals	066264	066265	
R - Rear Terminals HR/VR	066272	066273	
PS - Rear phase separators 90mm		068953	068954

Conversion Kit of the circuit-breaker from fixed into moving part of plug-in

Type	1SDA...R1		
	3 poles		4 poles
P MP KIT	066280		066281

Adapter for mounting the terminals of the fixed circuit-breaker on the fixed part

Type	1SDA...R1		
	3 poles		4 poles
ADP adapter fixed part (2 pieces)	066309		066310

Note: when use ADP with F/EF/MC terminal, order also "Kit F Front Terminals" - see page 7/37

Service releases

Shunt Opening release -SOR-

Type	1SDA...R1	
Uncabled Version		
SOR 12V DC	066313	
SOR 24-30V AC/DC	066314	
SOR 48-60V AC/DC	066315	
SOR 110...127V AC / 110...125V DC	066316	
SOR 220...240V AC / 220...250V DC	066317	
SOR 380-440V AC	066318	
SOR 480-525V AC	066319	
Cabled Version		
SOR-C 12V DC	066321	
SOR-C 24-30V AC/DC	066322	
SOR-C 48-60V AC/DC	066323	
SOR-C 110-127V AC / 110-125V DC	066324	
SOR-C 220-240V AC / 220-250V DC	066325	
SOR-C 380-440V AC	066326	
SOR-C 480-525V AC	066327	

YO Test Unit

Type	1SDA...R1	
YO Test Unit	050228	

Ordering codes for XT3

Accessories



PS-SOR uncabled



PS-SOR cabled



UVR uncabled



UVR cabled



Time delay device for undervoltage release

Shunt Opening release with permanent operation -PS -SOR-

Type	1SDA...R1	
Uncabled Version		
PS-SOR 24-30V AC/DC	066336	
PS-SOR 48V AC/DC	066295	
PS-SOR 60V AC/DC	066337	
PS-SOR 110...127V AC / 110...125V DC	066338	
PS-SOR 220...240V AC / 220...250V DC	066339	
PS-SOR 380-440V AC	066340	
PS-SOR 480-525V AC	066341	
Cabled Version		
PS-SOR-C 24-30V AC/DC	066343	
PS-SOR-C 48V AC/DC	066296	
PS-SOR-C 60V AC/DC	066344	
PS-SOR-C 110-127V AC / 110-125V DC	066345	
PS-SOR-C 220-240V AC / 220-250V DC	066346	
PS-SOR-C 380-440V AC	066347	
PS-SOR-C 480-525V AC	066348	

Undervoltage release -UVR-

Type	1SDA...R1	
Uncabled Version		
UVR 24-30V AC/DC	066389	
UVR 48V AC/DC	069064	
UVR 60V AC/DC	066390	
UVR 110...127V AC - 110...125V DC	066391	
UVR 220...240V AC - 220...250V DC	066392	
UVR 380-440V AC	066393	
UVR 480-525V AC	066394	
Cabled Version		
UVR-C 24-30V AC/DC	066396	
UVR-C 48V AC/DC	069065	
UVR-C 60V AC/DC	066397	
UVR-C 110-127V AC - 110-125V DC	066398	
UVR-C 220-240V AC - 220-250V DC	066399	
UVR-C 380-440V AC	066400	
UVR-C 480-525V AC	066401	

Delay device for undervoltage release -UVD-

Type	1SDA...R1	
UVD 24...30V AC/DC	051357	
UVD 48...60V AC/DC	051358	
UVD 110...125V AC/DC	051360	
UVD 220...250V AC/DC	051361	



Socket-plug panel connector

Connectors

Socket Plug Connector on rear of panel

Type	1SDA...R1	
Socket-plug panel connector with 3PINS	066409	
Socket-plug panel connector with 6PINS	066410	
Socket-plug panel connector with 9PINS	066411	
Socket-plug panel connector with 15PINS	066412	

Electrical signals

Auxiliary Contacts -AUX-

Type	1SDA...R1	
Uncabled Version		
AUX 24V DC	066423	
AUX 250V AC	066422	
Cabled Version		
AUX-C 1Q+1SY 24V DC	066446	
AUX-C 3Q+1SY 24V DC	066448	
AUX-C 1Q+1SY 250V AC	066431	
AUX-C 2Q+1SY 250V AC	066433	
AUX-C 3Q 250V AC Left	066428	
AUX-C 3Q+1SY 250V AC	066434	



AUX uncabled



AUX cabled



AUP - Auxiliary position contacts

Auxiliary position contacts -AUP-

Type	1SDA...R1	
Cabled Version		
AUP-I – Four Racked-in contacts 250V AC for plug-in circuit-breaker	066450	
AUP-I – Four Racked-in contacts 24V DC for plug-in circuit-breaker	066451	



AUE - Early auxiliary contacts

Early auxiliary contacts -AUE-

Type	1SDA...R1	
AUE – Two contacts in the rotary handle RHx (closed)	066454	
AUE – Two contacts in the rotary handle RHx (open)	067118	

Ordering codes for XT3

Accessories



Motor operator

Motor Operators

Motor operator with direct action -MOD-

Type	1SDA...R1	
MOD 24V DC	066457	
MOD 48...60V DC	066458	
MOD 110...125V AC/DC	066459	
MOD 220...250V AC/DC	066460	
MOD 380...440V AC	066461	
MOD 480...525V AC	066462	

Rotary Handle Operating Mechanism

Rotary Handles

Type	1SDA...R1	
Rotary Handle Operating Mechanism		
RHD Normal Direct Handle	066475	
RHD Direct Emergency Handle	066477	
RHE Normal Transmitted Handle	066479	
RHE Emergency Transmitted Handle	066481	
RHS-L Normal left lateral handle	066579	
RHS-L Emergency left lateral handle	066580	
RHS-R Normal right lateral handle	066581	
RHS-R Emergency right lateral handle	066582	
Transmitted Handle Spare Parts		
RHE_B Base for Transmitted Handle	066483	
RHE_S Rod of 500mm	066576	
RHE_H Normal Transmitted Handle	066577	
RHE_H Emergency Transmitted Handle	066578	
LH Normal large handle	066583	
LH Large emergency handle	066585	



Rotary Handles



Transmitted rotary handle



IP54

IP54 Protection for transmitted rotary handle

Type	1SDA...R1	
IP54 Protection for transmitted handle -RHE-	066587	



Fixed padlock



Key lock on the circuit-breaker



Key lock on the handle



Key lock on the motor



Interlock

Locks

Padlock on the circuit-breaker

Type	1SDA...R1	
PLL Removable lock with padlocks in open position	066588	
PLL Fixed lock with padlocks in open position	066589	
PLL Fixed lock with padlocks in open/closed position	066591	

Key lock on the circuit-breaker

Type	1SDA...R1	
KLC Ronis key lock open, different keys, removable in open position	066605	
KLC Ronis key lock open, same Type A keys, removable in open position	066606	
KLC Ronis key lock open, same Type B keys, removable in open position	066607	
KLC Ronis key lock open, same Type C keys, removable in open position	066608	
KLC Ronis key lock open, same Type D keys, removable in open position	066609	
KLC Ronis key lock open, same keys, removable in both position	066610	

Key lock on the handle

Type	1SDA...R1	
RHL Ronis key lock open, different keys - RHx	066617	
RHL Ronis key lock open, same Type A keys - RHx	066618	
RHL Ronis key lock open, same Type B keys - RHx	066619	
RHL Ronis key lock open, same Type C keys - RHx	066620	
RHL Ronis key lock open, same Type D keys - RHx	066621	
RHL Ronis key lock open/closed, different keys - RHx	066622	

Key lock on the motor

Type	1SDA...R1	
MOL-D Ronis key lock open, different keys	066623	
MOL-S Ronis key lock open, same Type A keys	066624	
MOL-S Ronis key lock open, same Type B keys	066625	
MOL-S Ronis key lock open, same Type C keys	066626	
MOL-S Ronis key lock open, same Type D keys	066627	

Mechanical interlock

Type	1SDA...R1	
MIR-H	066637	
MIR-V	066638	
Plate XT1 F	066639	
Plate XT1 P	066640	
Plate XT3 F	066643	
Plate XT3 P	066644	

Sealable Lock of Thermal Setting

Type	1SDA...R1	
Lock on thermal setting for TMD trip unit	066651	

Ordering codes for XT3

Accessories



RC Inst / RC Sel

Residual current devices

Residual current devices

Type	1SDA...R1			
	3 poles		4 poles	
RC Inst	067127		067129	
RC Sel	067128		067130	
RC B Type			067132	

Panel type residual current relay

Type	1SDA...R1			
RCQ020/A 115-230V AC			065979	
RCQ020/A 415V AC			065980	
Toroid closed Ø 60mm			037394	
Toroid closed Ø 110mm			037395	
Toroid closed Ø 185mm			050543	

Installation

Bracket for fixing onto DIN rail

Type	1SDA...R1			
	3 poles		4 poles	
DIN50022 KIT	066420		066421	
DIN50022 XT3+RC Inst / RC Sel	067139		067139	



DIN Guide

Terminals, terminal covers, phase separators

Insulating terminal covers

Type	1SDA...R1			
	3 poles		4 poles	
LTC Low terminal covers	066660		066661	
HTC High terminal covers	066668		066669	



Terminal covers

Sealable screws for terminal covers

Type	1SDA...R1			
Kit (2 pcs) sealable screws			066672	



Sealable screw

Phase separators

Type	1SDA...R1			
	4 pcs		6 pcs	
PB Height 25mm	066674		066679	
PB Height 100mm	066676		066681	
PB Height 200mm	066678		066683	



Phase separators



EF Terminal



FCCuAl Terminal

Terminals

Type	1SDA...R1			
	3 pcs	4 pcs	6 pcs	8 pcs
F Front Terminals	066857	066858	066859	066860
EF Extetnded front terminals	066873	066874	066875	066876
ES Extended spread front terminals	066897	066898	066899	066900
FC CuAl terminals for CuAl cables 1x95...185mm ²	067179	067180	067181	067182
FC CuAl terminals for CuAl cables 1x120...240mm ² + ADP	067183	067184	067185	067186
FC CuAl terminals for CuAl cables 2x35...150mm ²	067187	067188	067189	067190
FC CuAl terminals for CuAl cables 1x35...150mm ²	066274	066275	066584	066586
FC Cu terminals for Cu cables	066913	066914	066915	066916
MC Multi-cable Terminals 6x2.5...35mm ²	066929	066930	066931	066932
R Rear adjustable terminals	066945	066946	066947	066948
FB Flexible busbar Terminals	066965	066966	066967	066968
R-RC Rear terminal for Residual current Inst-Sel		066954		

Automatic transfer devices

ATS021 - ATS022 Automatic transfer devices

Type	1SDA...R1	
ATS021	065523	
ATS022	065524	



ATS021

Spare parts

Type	1SDA...R1	
SA RC Sel/RC Inst/RC B Type - Opening solenoid of the residual current device	066992	
SA RC B Type - Opening solenoid of the residual current device	067208	
AUX-C - Loose uncabled Auxiliary Contact 250V ⁽¹⁾	066994	
AUX-C - Loose cabled auxiliary contact 24V ⁽¹⁾	066996	

⁽¹⁾ un-numbered cables



Flange

Flange for Compartment door

Type	1SDA...R1			
	3 poles		4 poles	
Small flange for Circuit-breaker	068657		068657	
Large flange for Circuit-breaker	068644		068645	
Flange for MOD	068648		068648	
Flange for direct handle RHD	068651		068651	
Flange for residual current RC Sel/RC Inst	068655		068656	

Ordering codes for XT4

Circuit-breakers



XT4 circuit-breaker

XT4 160 TMD/TMA - Fixed (F) - 3 poles - Front terminals (F)

Thermomagnetic trip unit - TMD/TMA			I _{cu} (415V)	1SDA...R1				
				N	S	H	L	V
	I _n	I _Δ		36kA	50kA	70kA	120kA	150kA
TMD	16	300		068076	068299	068332	068365	068398
TMD	20	300		068080	068300	068333	068366	068399
TMD	25	300		068081	068301	068334	068367	068400
TMD	32	320		068082	068302	068335	068368	068401
TMA	40	400		068083	068303	068336	068369	068402
TMA	50	500		068084	068304	068337	068370	068403
TMA	63	630		068085	068305	068338	068371	068404
TMA	80	800		068086	068306	068339	068372	068405
TMA	100	1000		068087	068307	068340	068373	068406
TMA	125	1250		068088	068308	068341	068374	068407
TMA	160	1600		068089	068309	068342	068375	068408

XT4 250 TMD/TMA - Fixed (F) - 3 poles - Front terminals (F)

Thermomagnetic trip unit - TMD/TMA			I _{cu} (415V)	1SDA...R1				
				N	S	H	L	V
	I _n	I _Δ		36kA	50kA	70kA	120kA	150kA
TMA	200	2000		068090	068310	068343	068376	068409
TMA	225	2250		068091	068311	068344	068377	068410
TMA	250	2500		068092	068312	068345	068378	068411

XT4 160 TMD/TMA - Fixed (F) - 4 poles - Front terminals (F)

Thermomagnetic trip unit - TMD/TMA			I _{cu} (415V)	1SDA...R1				
				N	S	H	L	V
	I _n	I _Δ		36kA	50kA	70kA	120kA	150kA
TMD	16	300		068093	068313	068346	068379	068412
TMD	20	300		068094	068314	068347	068380	068413
TMD	25	300		068095	068315	068348	068381	068414
TMD	32	320		068096	068316	068349	068382	068415
TMA	40	400		068097	068317	068350	068383	068416
TMA	50	500		068098	068318	068351	068384	068417
TMA	63	630		068099	068319	068352	068385	068418
TMA	80	800		068100	068320	068353	068386	068419
TMA	100	1000		068101	068321	068354	068387	068420
TMA In N=50%	125	1250		068102	068322	068355	068388	068421
TMA In N=50%	160	1600		068103	068323	068356	068389	068422
TMA In N=100%	125	1250		068107	068327	068360	068393	068426
TMA In N=100%	160	1600		068108	068328	068361	068394	068427

XT4 250 TMD/TMA - Fixed (F) - 4 poles - Front terminals (F)

Thermomagnetic trip unit - TMD/TMA			I _{cu} (415V)	1SDA...R1				
				N	S	H	L	V
	I _n	I _Δ		36kA	50kA	70kA	120kA	150kA
TMA In N=50%	200	2000		068104	068324	068357	068390	068423
TMA In N=50%	225	2250		068105	068325	068358	068391	068424
TMA In N=50%	250	2500		068106	068326	068359	068392	068425
TMA In N=100%	200	2000		068109	068329	068362	068395	068428
TMA In N=100%	225	2250		068110	068330	068363	068396	068429
TMA In N=100%	250	2500		068111	068331	068364	068397	068430



XT4 circuit-breaker

XT4 160 MA - Fixed (F) - 3 poles - Front terminals (F)

Thermomagnetic trip unit - MA			Icu (415V)	1SDA...R1					
	In	I _Δ		N	S	H	L	V	
				36kA	50kA	70kA	120kA	150kA	
MA	10 ⁽¹⁾	50...100		068112	068431	068441	068451	068461	
MA	12.5 ⁽¹⁾	62.5...125		068113	068432	068442	068452	068462	
MA	20	100...200		068114	068433	068443	068453	068463	
MA	32	160...320		068115	068434	068444	068454	068464	
MA	52	260...520		068116	068435	068445	068455	068465	
MA	80	400...800		068117	068436	068446	068456	068466	
MA	100	500...1000		068118	068437	068447	068457	068467	
MA	125	625...1250		068119	068438	068448	068458	068468	
MA	160	800...1600		068120	068439	068449	068459	068469	

⁽¹⁾ Available shortly, please ask ABB SACE

XT4 250 MA - Fixed (F) - 3 poles - Front terminals (F)

Thermomagnetic trip unit - MA			Icu (415V)	1SDA...R1					
	In	I _Δ		N	S	H	L	V	
				36kA	50kA	70kA	120kA	150kA	
MA	200	1000...2000		068121	068440	068450	068460	068470	

XT4 160 Ekip LS/I - Fixed (F) - 3 poles - Front terminals (F)

Electronic trip unit - Ekip LS/I			Icu (415V)	1SDA...R1					
	In			N	S	H	L	V	
				36kA	50kA	70kA	120kA	150kA	
Ekip LS/I	40			068122	068471	068511	068551	068591	
Ekip LS/I	63			068123	068472	068512	068552	068592	
Ekip LS/I	100			068124	068473	068513	068553	068593	
Ekip LS/I	160			068125	068474	068514	068554	068594	

XT4 250 Ekip LS/I - Fixed (F) - 3 poles - Front terminals (F)

Electronic trip unit - Ekip LS/I			Icu (415V)	1SDA...R1					
	In			N	S	H	L	V	
				36kA	50kA	70kA	120kA	150kA	
Ekip LS/I	250			068126	068475	068515	068555	068595	

XT4 160 Ekip I - Fixed (F) - 3 poles - Front terminals (F)

Electronic trip unit - Ekip I			Icu (415V)	1SDA...R1					
	In			N	S	H	L	V	
				36kA	50kA	70kA	120kA	150kA	
Ekip I	40			068127	068476	068516	068556	068596	
Ekip I	63			068128	068477	068517	068557	068597	
Ekip I	100			068129	068478	068518	068558	068598	
Ekip I	160			068130	068479	068519	068559	068599	

XT4 250 Ekip I - Fixed (F) - 3 poles - Front terminals (F)

Electronic trip unit - Ekip I			Icu (415V)	1SDA...R1					
	In			N	S	H	L	V	
				36kA	50kA	70kA	120kA	150kA	
Ekip I	250			068131	068480	068520	068560	068600	

Ordering codes for XT4

Circuit-breakers



XT4 circuit-breaker

XT4 160 Ekip LSI - Fixed (F) - 3 poles - Front terminals (F)

Electronic trip unit - Ekip LSI			Icu (415V)	1SDA...R1				
	In			N	S	H	L	V
				36kA	50kA	70kA	120kA	150kA
Ekip LSI	40			068132	068481	068521	068561	068601
Ekip LSI	63			068133	068482	068522	068562	068602
Ekip LSI	100			068134	068483	068523	068563	068603
Ekip LSI	160			068135	068484	068524	068564	068604

XT4 250 Ekip LSI - Fixed (F) - 3 poles - Front terminals (F)

Electronic trip unit - Ekip LSI			Icu (415V)	1SDA...R1				
	In			N	S	H	L	V
				36kA	50kA	70kA	120kA	150kA
Ekip LSI	250			068136	068485	068525	068565	068605

XT4 160 Ekip LSIg - Fixed (F) - 3 poles - Front terminals (F)

Electronic trip unit - Ekip LSIg			Icu (415V)	1SDA...R1				
	In			N	S	H	L	V
				36kA	50kA	70kA	120kA	150kA
Ekip LSIg	40			068137	068486	068526	068566	068606
Ekip LSIg	63			068138	068487	068527	068567	068607
Ekip LSIg	100			068139	068488	068528	068568	068608
Ekip LSIg	160			068140	068489	068529	068569	068609

XT4 250 Ekip LSIg - Fixed (F) - 3 poles - Front terminals (F)

Electronic trip unit - Ekip LSIg			Icu (415V)	1SDA...R1				
	In			N	S	H	L	V
				36kA	50kA	70kA	120kA	150kA
Ekip LSIg	250			068141	068490	068530	068570	068610

XT4 160 Ekip E-LSIg - Fixed (F) - 3 poles - Front terminals (F)

Electronic trip unit - Ekip E-LSIg			Icu (415V)	1SDA...R1				
	In			N	S	H	L	V
				36kA	50kA	70kA	120kA	150kA
Ekip E-LSIg	40			069601	069611	069621	069631	069641
Ekip E-LSIg	63			069602	069612	069622	069632	069642
Ekip E-LSIg	100			069603	069613	069623	069633	069643
Ekip E-LSIg	160			069604	069614	069624	069634	069644

XT4 250 Ekip E-LSIg - Fixed (F) - 3 poles - Front terminals (F)

Electronic trip unit - Ekip E-LSIg			Icu (415V)	1SDA...R1				
	In			N	S	H	L	V
				36kA	50kA	70kA	120kA	150kA
Ekip E-LSIg	250			069605	069615	069625	069635	069645



XT4 circuit-breaker

XT4 160 Ekip LS/I - Fixed (F) - 4 poles - Front terminals (F)

Electronic trip unit - Ekip LS/I		Icu (415V)	1SDA...R1					
	In		N	S	H	L	V	
			36kA	50kA	70kA	120kA	150kA	
Ekip LS/I	40		068142	068491	068531	068571	068611	
Ekip LS/I	63		068144	068492	068532	068572	068612	
Ekip LS/I	100		068145	068493	068533	068573	068613	
Ekip LS/I	160		068146	068494	068534	068574	068614	

XT4 250 Ekip LS/I - Fixed (F) - 4 poles - Front terminals (F)

Electronic trip unit - Ekip LS/I		Icu (415V)	1SDA...R1					
	In		N	S	H	L	V	
			36kA	50kA	70kA	120kA	150kA	
Ekip LS/I	250		068147	068495	068535	068575	068615	

XT4 160 Ekip I - Fixed (F) - 4 poles - Front terminals (F)

Electronic trip unit - Ekip I		Icu (415V)	1SDA...R1					
	In		N	S	H	L	V	
			36kA	50kA	70kA	120kA	150kA	
Ekip I	40		068148	068496	068536	068576	068616	
Ekip I	63		068149	068497	068537	068577	068617	
Ekip I	100		068150	068498	068538	068578	068618	
Ekip I	160		068151	068499	068539	068579	068619	

XT4 250 Ekip I - Fixed (F) - 4 poles - Front terminals (F)

Electronic trip unit - Ekip I		Icu (415V)	1SDA...R1					
	In		N	S	H	L	V	
			36kA	50kA	70kA	120kA	150kA	
Ekip I	250		068152	068500	068540	068580	068620	

XT4 160 Ekip LSI - Fixed (F) - 4 poles - Front terminals (F)

Electronic trip unit - Ekip LSI		Icu (415V)	1SDA...R1					
	In		N	S	H	L	V	
			36kA	50kA	70kA	120kA	150kA	
Ekip LSI	40		068153	068501	068541	068581	068621	
Ekip LSI	63		068154	068502	068542	068582	068622	
Ekip LSI	100		068155	068503	068543	068583	068623	
Ekip LSI	160		068156	068504	068544	068584	068624	

XT4 250 Ekip LSI - Fixed (F) - 4 poles - Front terminals (F)

Electronic trip unit - Ekip LSI		Icu (415V)	1SDA...R1					
	In		N	S	H	L	V	
			36kA	50kA	70kA	120kA	150kA	
Ekip LSI	250		068157	068505	068545	068585	068625	

Ordering codes for XT4

Circuit-breakers



XT4 circuit-breaker

XT4 160 Ekip L SIG - Fixed (F) - 4 poles - Front terminals (F)

Electronic trip unit - Ekip L SIG			Icu (415V)	1SDA...R1				
	In			N	S	H	L	V
				36kA	50kA	70kA	120kA	150kA
Ekip L SIG	40			068158	068506	068546	068586	068626
Ekip L SIG	63			068159	068507	068547	068587	068627
Ekip L SIG	100			068160	068508	068548	068588	068628
Ekip L SIG	160			068161	068509	068549	068589	068629

XT4 250 Ekip L SIG - Fixed (F) - 4 poles - Front terminals (F)

Electronic trip unit - Ekip L SIG			Icu (415V)	1SDA...R1				
	In			N	S	H	L	V
				36kA	50kA	70kA	120kA	150kA
Ekip L SIG	250			068162	068510	068550	068590	068630

XT4 160 Ekip E-LSIG - Fixed (F) - 4 poles - Front terminals (F)

Electronic trip unit - Ekip E-LSIG			Icu (415V)	1SDA...R1				
	In			N	S	H	L	V
				36kA	50kA	70kA	120kA	150kA
Ekip E-LSIG	40			069606	069616	069626	069636	069646
Ekip E-LSIG	63			069607	069617	069627	069637	069647
Ekip E-LSIG	100			069608	069618	069628	069638	069648
Ekip E-LSIG	160			069609	069619	069629	069639	069649

XT4 250 Ekip E-LSIG - Fixed (F) - 4 poles - Front terminals (F)

Electronic trip unit - Ekip E-LSIG			Icu (415V)	1SDA...R1				
	In			N	S	H	L	V
				36kA	50kA	70kA	120kA	150kA
Ekip E-LSIG	250			069610	069620	069630	069640	069650



XT4D switch-disconnector

XT4 D - Switch-disconnector

			1SDA...R1			
			3 poles		4 poles	
XT4 D			068212		068213	

XT4 160 - Breaking part

	1SDA...R1					
	N	S	H	L	V	
3 poles	068289	068290	068291	068292	068293	
4 poles	068294	068295	068296	068297	068298	

XT4 250 - Breaking part

	1SDA...R1					
	N	S	H	L	V	
3 poles	068173	068174	068175	068176	068177	
4 poles	068178	068179	068180	068181	068182	



Loose trip units

Loose trip units XT4

Thermomagnetic - TMD/TMA			1SDA...R1			
			3 poles		4 poles	
	I_n	I_Δ				
TMD	16	300	067377		067465	
TMD	20	300	067378		067468	
TMD	25	300	067379		067469	
TMD	32	320	067380		067470	
TMA	40	400	067381		067471	
TMA	50	500	067382		067472	
TMA	63	630	067383		067473	
TMA	80	800	067384		067474	
TMA	100	1000	067385		067475	
TMA	125	1250	067386		067481	
TMA	160	1600	067387		067482	
TMA	200	2000	067388		067483	
TMA	225	2250	067389		067484	
TMA	250	2500	067390		067485	
TMA In N=50%	125	1250			067476	
TMA In N=50%	160	1600			067477	
TMA In N=50%	200	2000			067478	
TMA In N=50%	225	2250			067479	
TMA In N=50%	250	2500			067480	

Loose trip units XT4

Thermomagnetic - MA			1SDA...R1			
			3 poles			
	I_n	I_Δ				
MA	20	100...200	067490			
MA	32	160...320	067491			
MA	52	260...520	067492			
MA	80	400...800	067493			
MA	100	500...1000	067494			
MA	125	625...1250	067495			
MA	160	800...1600	067496			
MA	200	1000...2000	067497			

Ordering codes for XT4

Circuit-breakers



Loose trip units

Loose trip units XT4

Electronic - Ekip LS/I

		1SDA...R1	
		3 poles	4 poles
	In		
Ekip LS/I	40	067498	067518
Ekip LS/I	63	067499	067519
Ekip LS/I	100	067500	067520
Ekip LS/I	160	067501	067521
Ekip LS/I	250	067502	067522

Loose trip units XT4

Electronic - Ekip I

		1SDA...R1	
		3 poles	4 poles
	In		
Ekip I	40	067503	067523
Ekip I	63	067504	067524
Ekip I	100	067505	067525
Ekip I	160	067506	067526
Ekip I	250	067507	067527

Loose trip units XT4

Electronic - Ekip LSI

		1SDA...R1	
		3 poles	4 poles
	In		
Ekip LSI	40	067508	067528
Ekip LSI	63	067509	067529
Ekip LSI	100	067510	067530
Ekip LSI	160	067511	067531
Ekip LSI	250	067512	067532

Loose trip units XT4

Electronic - Ekip LSIG

		1SDA...R1	
		3 poles	4 poles
	In		
Ekip LSIG	40	067513	067533
Ekip LSIG	63	067514	067534
Ekip LSIG	100	067515	067535
Ekip LSIG	160	067516	067536
Ekip LSIG	250	067517	067537

Loose trip units XT4

Electronic - Ekip E-LSIG

		1SDA...R1	
		3 poles	4 poles
	In		
Ekip E-LSIG	40	069591	069596
Ekip E-LSIG	63	069592	069597
Ekip E-LSIG	100	069593	069598
Ekip E-LSIG	160	069594	069599
Ekip E-LSIG	250	069595	069600



Loose trip units

Loose trip units XT4

Electronic - Ekip M-LIU			1SDA...R1			
			3 poles			
	In					
Ekip M-LIU	40		068028			
Ekip M-LIU	63		068029			
Ekip M-LIU	100		068030			
Ekip M-LIU	160		068031			

Loose trip units XT4

Electronic - Ekip M-LRIU			1SDA...R1			
			3 poles			
	In					
Ekip M-LRIU	40		068033			
Ekip M-LRIU	63		068034			
Ekip M-LRIU	100		068035			
Ekip M-LRIU	160		068036			
Ekip M-LRIU	200		068037			

Loose trip units XT4

Electronic - Ekip G-LS/I			1SDA...R1			
			3 poles		4 poles	
	In					
Ekip G-LS/I	40		068038		068043	
Ekip G-LS/I	63		068039		068044	
Ekip G-LS/I	100		068040		068045	
Ekip G-LS/I	160		068041		068046	
Ekip G-LS/I	250		068042		068047	

Loose trip units XT4

Electronic - Ekip N-LS/I			1SDA...R1			
					4 poles	
	In					
Ekip N-LS/I	40				068048	
Ekip N-LS/I	63				068049	
Ekip N-LS/I	100				068050	
Ekip N-LS/I	160				068051	

Ordering codes for XT4

Accessories



Fixed part of plug-in



Fixed part of withdrawable



Conversion kit for turning a fixed circuit-breaker into the moving part of a plug-in circuit-breaker



Conversion kit for turning a fixed circuit-breaker into the moving part of a withdrawable circuit-breaker

Fixed parts, conversion kit and accessories for fixed parts

Fixed part of plug-in (P)

Type	1SDA...R1			
	3 poles		4 poles	
Kit P PF EF	068196		068198	
Kit P PF HR/VR ⁽¹⁾	068197		068199	

⁽¹⁾ The terminals are factory-mounted in the horizontal position (HR)

Fixed part of withdrawable (W)

Type	1SDA...R1			
	3 poles		4 poles	
Kit W PF EF	068204		068206	
Kit W PF HR/VR ⁽¹⁾	068205		068207	

⁽¹⁾ The terminals are factory-mounted in the horizontal position (HR)

Terminals for the fixed parts

Type	1SDA...R1				
	3 pcs		4 pcs		6 pcs
EF - Front Extended Terminals	066266		066267		
R - Rear Terminals HR/VR	066272		066273		
PS - Rear phase separators 90mm			068953		068954

Conversion Kit of the circuit-breaker from fixed into moving part of plug-in

Type	1SDA...R1			
	3 poles		4 poles	
P MP KIT	066282		066283	

Conversion Kit of the circuit-breaker from fixed into moving part of withdrawable

Type	1SDA...R1			
	3 pcs		4 pcs	
W MP KIT	066286		066287	

Conversion Kit of the fixed part from plug-in to withdrawable

Type	1SDA...R1	
FP P>W KIT	066289	

Conversion Kit of RC from fixed to plug-in

Type	1SDA...R1	
	4 poles	
P MP RC Sel XT2 4p KIT	066291	



Key lock/padlock for fixed part



Ronis key lock/padlock for fixed part



Fixed part adapter



SOR uncabled



SOR cabled



SOR for withdrawable



YO Test Unit

Conversion Kit of RC from plug-in to withdrawable

Type	1SDA...R1	
	4 poles	
W MP RC Sel KIT	067115	

Key lock/padlock for fixed part of withdrawable

Type	1SDA...R1	
KL-D Key Lock FP, different keys	066293	
KL-S Key Lock FP, same keys N.20005	066294	

Ronis key/padlock lock for fixed part of withdrawable

Type	1SDA...R1	
KL-D Ronis FP key lock, different keys	066298	
KL-S Ronis FP key lock, same Type A keys	066300	

Adapter for mounting the terminals of the fixed circuit-breaker on the fixed part

Type	1SDA...R1		
	3 poles		4 poles
ADP adapter fixed part (2 pieces)	066311		066312

Note: when use ADP with F/EF/MC terminal, order also "Kit F Front Terminals" - see page 7/54

Service releases

Shunt Opening release -SOR-

Type	1SDA...R1		
	Fixed/Plug-in		Withdrawable
Uncabled Version			
SOR 12V DC	066313		
SOR 24-30V AC/DC	066314		
SOR 48-60V AC/DC	066315		
SOR 110...127V AC / 110...125V DC	066316		
SOR 220...240V AC / 220...250V DC	066317		
SOR 380-440V AC	066318		
SOR 480-525V AC	066319		
Cabled Version			
SOR-C 12V DC	066321		066328
SOR-C 24-30V AC/DC	066322		066329
SOR-C 48-60V AC/DC	066323		066330
SOR-C 110-127V AC / 110-125V DC	066324		066331
SOR-C 220-240V AC / 220-250V DC	066325		066332
SOR-C 380-440V AC	066326		066333
SOR-C 480-525V AC	066327		066334

YO Test Unit

Type	1SDA...R1	
YO Test Unit	050228	

Ordering codes for XT4

Accessories



PS-SOR uncabled



PS-SOR cabled



PS-SOR for withdrawable



UVR uncabled



UVR cabled



SOR for withdrawable



Time delay device for undervoltage release

Shunt Opening release with permanent operation -PS -SOR-

Type	1SDA...R1			
	Fixed/Plug-in		Withdrawable	
Uncabled Version				
PS-SOR 24-30V AC/DC	066336			
PS-SOR 48V AC/DC	066295			
PS-SOR 60V AC/DC	066337			
PS-SOR 110...127V AC / 110...125V DC	066338			
PS-SOR 220...240V AC / 220...250V DC	066339			
PS-SOR 380-440V AC	066340			
PS-SOR 480-525V AC	066341			
Cabled Version				
PS-SOR-C 24-30V AC/DC	066343		066350	
PS-SOR-C 48V AC/DC	066296		066297	
PS-SOR-C 60V AC/DC	066344		066351	
PS-SOR-C 110-127V AC / 110-125V DC	066345		066352	
PS-SOR-C 220-240V AC / 220-250V DC	066346		066354	
PS-SOR-C 380-440V AC	066347		066355	
PS-SOR-C 480-525V AC	066348		066356	

Undervoltage release -UVR-

Type	1SDA...R1			
	Fixed/Plug-in		Withdrawable	
Uncabled Version				
UVR 24-30V AC/DC	066389			
UVR 48V AC/DC	069064			
UVR 60V AC/DC	066390			
UVR 110...127V AC / 110...125V DC	066391			
UVR 220...240V AC / 220...250V DC	066392			
UVR 380-440V AC	066393			
UVR 480-525V AC	066394			
Cabled Version				
UVR-C 24-30V AC/DC	066396		066403	
UVR-C 48V AC/DC	069065		069066	
UVR-C 60V AC/DC	066397		066404	
UVR-C 110-127V AC / 110-125V DC	066398		066405	
UVR-C 220-240V AC / 220-250V DC	066399		066406	
UVR-C 380-440V AC	066400		066407	
UVR-C 480-525V AC	066401		066408	

Delay device for undervoltage release -UVD-

Type	1SDA...R1	
UVD 24...30V AC/DC	051357	
UVD 48...60V AC/DC	051358	
UVD 110...125V AC/DC	051360	
UVD 220...250V AC/DC	051361	

Connectors

Connector of fourth pole for withdrawable

Type	1SDA...R1	
	Withdrawable	
Connector 4 th Pole SOR-PS-SOR	066415	
Connector 4 th Pole UVR	066418	



Socket-plug panel connector

Socket-Plug connector on rear of panel

Type	1SDA...R1	
Socket-plug panel connector with 3PINS	066409	
Socket-plug panel connector with 6PINS	066410	
Socket-plug panel connector with 9PINS	066411	
Socket-plug panel connector with 15PINS	066412	



Socket-plug connector of fixed part

Fixed part socket-plug connector

Type	1SDA...R1	
Socket-plug connector of Moving Part 12PINS	066413	
Socket-plug connector of Fixed Part 12PINS	066414	

Electrical signals

Auxiliary contacts -AUX-

Type	1SDA...R1		
	Fixed/Plug-in		Withdrawable
Uncabled Version			
AUX 24V DC	066423		
AUX-SA 24V DC	066425		
AUX 250V AC	066422		
AUX-SA 250V AC	066424		
Cabled Version			
AUX-C 1Q+1SY 24V DC	066446		066447
AUX-C 3Q+1SY 24V DC	066448		066449
AUX-SA-C 24V DC	067116		067117
AUX-C 1Q+1SY 250V AC	066431		066432
AUX-C 2Q+1SY 250V AC	066433		
AUX-C 2Q+2SY+1SA 250V AC	066438		066439
AUX-C 3Q 250V AC Left	066427		
AUX-C 3Q+1SY 250V AC	066434		066435
AUX-C 3Q+2SY 250V AC	066436		066437
AUX-SA-C 250V AC	066429		066430
AUX-C 1Q+1SY 400V AC	066444		066445
AUX-C 2Q 400V AC	066440		066443



AUX uncabled



AUX cabled



AUX for withdrawable

Ordering codes for XT4

Accessories



AUP - Auxiliary position contacts

Auxiliary position contacts -AUP-

Type	1SDA...R1	
Cabled Version		
AUP-I – Four Racked-in contacts 250V AC for plug-in/withdrawable circuit-breaker	066450	
AUP-I – Four Racked-in contacts 24V DC for plug-in/withdrawable circuit-breaker	066451	
AUP-R – Two Racked-out contacts 250V AC for withdrawable circuit-breaker	066452	
AUP-R – Two Racked-out contacts 24V DC for withdrawable circuit-breaker	066453	



AUE - Early auxiliary contacts

Early auxiliary contacts -AUE-

Type	1SDA...R1	
	Fixed/Plug-in	Withdrawable
AUE – Two contacts in the rotary handle RHx (open)	067118	067119
AUE – Two contacts in the rotary handle RHx (closed)	066454	066455

Motor Operators



MOE - Motor operator

Stored energy motor operator MOE

Type	1SDA...R1	
MOE 24V DC	066463	
MOE 48...60V DC	066464	
MOE 110...125V AC/DC	066465	
MOE 220...250V AC/DC	066466	
MOE 380...440V AC	066467	
MOE 480...525V AC	066468	

Electronic stored energy motor operator MOE-E

Type	1SDA...R1	
MOE-E 24V DC	066469	
MOE-E 48...60V DC	066470	
MOE-E 110...125V AC/DC	066471	
MOE-E 220...250V AC/DC	066472	
MOE-E 380...440V AC	066473	
MOE-E 480...525V AC	066474	



Direct handle



Transmitted handle



IP54



Fixed padlock

Rotary Handles

Rotary Handles

Type	1SDA...R1		
	Fixed/Plug-in		Withdrawable
RHD Normal Direct Handle	069053		066476
RHD Direct Emergency Handle	069054		066478
RHE Normal Transmitted Handle	069055		066480
RHE Emergency Transmitted Handle	069056		066482
RHS L Normal Left Lateral Handle	069058		
RHS L Emergency Left Lateral Handle	069059		
RHS R Normal Right Lateral Handle	069060		
RHS R Emergency Right Lateral Handle	069061		
Transmitted Handle Spare Parts			
RHE_B Base for Transmitted Handle	069057		066484
RHE_S Rod of 500mm	066576		
RHE_H Normal Transmitted Handle	066577		
RHE_H Emergency Transmitted Handle	066578		
LH Wide Normal Handle	066583		
LH Wide Emergency Handle	066585		

IP54 Protection for transmitted rotary handle

Type	1SDA...R1	
IP54 protection for transmitted handle -RHE-	066587	

Locks

Padlock on the circuit-breaker

Type	1SDA...R1	
PLL Fixed lock with padlocks in open position	066590	
PLL Fixed lock with padlocks in open/closed position	066592	

Ordering codes for XT4

Accessories



Key lock on the circuit-breaker

Key lock on the circuit-breaker

Type	1SDA...R1	
KLC Ronis key lock open, different keys, removable in open position	066599	
KLC Ronis key lock open, same Type A keys, removable in open position	066600	
KLC Ronis key lock open, same Type B keys, removable in open position	066601	
KLC Ronis key lock open, same Type C keys, removable in open position	066602	
KLC Ronis key lock open, same Type D keys, removable in open position	066603	
KLC Ronis key lock open, same keys, removable in both position	066604	



Key lock on the handle

Key lock on the handle / front for locks

Type	1SDA...R1	
RHL Ronis key lock open, different keys - RHx/FLD	066617	
RHL Ronis key lock open, same Type A keys - RHx/FLD	066618	
RHL Ronis key lock open, same Type B keys - RHx/FLD	066619	
RHL Ronis key lock open, same Type C keys - RHx/FLD	066620	
RHL Ronis key lock open, same Type D keys - RHx/FLD	066621	
RHL Ronis key lock open/closed, different keys - RHx	066622	
RHL Ronis key lock open/closed, different keys - FLD	069182	



Key lock on the motor

Key lock on the motor

Type	1SDA...R1	
MOL-D Ronis key lock open, different keys	066629	
MOL-S Ronis key lock open, same Type A keys	066630	
MOL-S Ronis key lock open, same Type B keys	066631	
MOL-S Ronis key lock open, same Type C keys	066632	
MOL-S Ronis key lock open, same Type D keys	066633	
MOL-M Key lock against manual operation	066634	



Front for locks

Front for FLD locks

Type	1SDA...R1	
	Fixed/Plug-in	Withdrawable
Front for FLD locks	066635	066636



Interlock

Mechanical interlock*

Type	1SDA...R1	
MIR-H	066637	
MIR-V	066638	
Plate XT2 F	066641	
Plate XT2 P/W	066642	
Plate XT4 F	066645	
Plate XT4 P/W	066646	

* If the CB interlocked has got a stored energy motor operator (MOE/MOE-E) a key lock between MOL-D and MOL-S is mandatory



RC Sel

Residual current devices

Residual current devices

Type	1SDA...R1	
	4 poles	
RC Sel	067131	

Panel type residual current relay

Type	1SDA...R1	
RCQ020/A 115-230V AC	065979	
RCQ020/A 415V AC	065980	
Toroid closed Ø 60mm	037394	
Toroid closed Ø 110mm	037395	
Toroid closed Ø 185mm	050543	



DIN Guide

Installation

Bracket for fixing onto DIN rail

Type	1SDA...R1		
	3 poles		4 poles
KIT DIN50022	066653		066653



Terminal cover

Terminals

Insulating Terminal Covers

Type	1SDA...R1		
	3 poles		4 poles
LTC Low terminal covers	066662		066663
HTC High terminal covers	066670		066671



Sealable screw

Sealable screws for Terminal Covers

Type	1SDA...R1	
	2 pcs	
Kit with two sealable screws	066672	



Phase separators

Phase Separators

Type	1SDA...R1		
	4 pcs		6 pcs
PB Height 25mm	069062		069063
PB Height 100mm	066675		066680
PB Height 200mm	066677		066682

Ordering codes for XT4

Accessories



EF Terminal



FCCuAl Terminal

Terminals

Type	1SDA...R1			
	3 pcs	4 pcs	6 pcs	8 pcs
F Front Terminals	066861	066862	066863	066864
EF Extended front terminals	066877	066878	066879	066880
ES Extended spread front terminals	066901	066902	066903	066904
FC CuAl Terminals for CuAl cables 1x1...150mm ²	067191	067192	067193	067194
FC CuAl Terminals for CuAl cables 1x120...240mm ² + ADP	067195	067196	067197	067198
FC CuAl Terminals for CuAl cables 2x35...150mm ²	067199	067200	067201	067202
FC Cu Terminals for Cu cables	066917	066918	066919	066920
MC Multi-cable Terminals 6x2.5...35mm ²	066933	066934	066935	066936
R Rear adjustable Terminals	066949	066950	066951	066952
FB Flexible busbar Terminals	066969	066970	066971	066972

Accessories for electronic trip units

Type	1SDA...R1	
	Fixed/Plug-in	Withdrawable
Ekip Display	068659	068659
Ekip LED Meter	068660	068660
Ekip Com	068661	068662
Ekip Multimeter Display on front of switchboard	074192	074192
PR212/CI Contactor control unit	050708	050708
HMI030 Interface on front of panel	063143	063143

CT External neutral

Type	1SDA...R1
CT External neutral 40A	066975
CT External neutral 63A	066976
CT External neutral 100A	066977
CT External neutral 160A	066978
CT External neutral 250A	066979

Kit of Electronic trip unit auxiliary Voltage

Type	1SDA...R1	
	Fixed/Plug-in	Withdrawable
KIT of 24V DC auxiliary voltage for electronic trip units	066980	066981
KIT for PTC Connection	066982	066983
KIT for Ext NE Connection	066984	066985
KIT for PR212/CI Connection	066986	066987
KIT for external neutral voltage connection	069651	069652

Test and Configuration Unit

Type	1SDA...R1
Ekip TT - Trip Test Unit	066988
Ekip T&P - Programming and test Unit	066989



Ekip T&P unit



ATS021

Automatic transfer devices

ATS021- ATS022 Automatic transfer devices

Type	1SDA...R1	
ATS021	065523	
ATS022	065524	

Spare parts

Type	1SDA...R1			
	Fixed/Plug-in		Withdrawable	
SA RC Sel - Opening solenoid of the residual current device	067209		067210	
AUX-C -Loose cabled Auxiliary Contact 250V AC ⁽¹⁾	066994		066995	
AUX-C -Loose cabled Auxiliary Contact 24V DC ⁽¹⁾	066996		066997	

⁽¹⁾ un-numbered cables



Fixed/Moving part connector
for withdrawable

Fixed Part Connector for Withdrawable

Type	1SDA...R1	
1 connector for fixed part/moving part of withdrawable with 2 PINS for SOR/UVR up to 400V	067213	
1 connector for fixed part/moving part of withdrawable with 3 PINS for AUX up to 400V	067214	



Flange

Flange for Compartment door

Type	1SDA...R1					
	3 poles		4 poles		3 poles	4 poles
	Fixed/ Plug-in		Fixed/ Plug-in		With- drawable	With- drawable
Small flange for circuit-breaker	068657		068657			
Large flange for circuit-breaker	068646		068647			
Flange for MOE/MOE-E/FLD	068649		068649		068650	068650
Flange for direct handle RHD	068651		068651		068652	068652
Flange for residual current RC Sel			066649			066650



Index

Circuit-breaker.....	8/2
Performance Parameters	8/4
Releases and Protections.....	8/6
Motor protection.....	8/9
Communication	8/10
Standards and Regulations	8/11
Symbols.....	8/12
ABB SACE documentation.....	8/13

Glossary

Circuit-breaker

G1.1 Circuit-breaker

Mechanical switching apparatus, able to close, carry and break currents in normal short-circuit condition and also close, carry for a specified time and break currents in specific abnormal circuit conditions such as that verified in case of short-circuit.

G1.2 Non-automatic circuit-breaker (switch-disconnector)

Mechanical switching device which, in the open position, complies with the specified requirements for the isolating function.

G1.3 Current-limiting circuit-breaker

Circuit-breaker with a break time short enough to prevent the short-circuit current from reaching the peak value it would otherwise reach.

G1.4 Rate of contact wear

Percentage of contact wear. Indicatively shows the state of electrical life of the circuit-breaker contacts.

G1.5 Double insulation

all the circuit-breakers in the SACE Tmax XT family have double insulation between the active power parts and the front parts of the apparatus where the operator works during normal plant service, so as to prevent the risk of contact with live parts. Each electrical accessory is completely segregated from the power circuit, and particularly the control assembly, which is completely isolated from the energised circuits. Moreover, the circuit-breaker has redundant insulation between both the internal live parts and the connection terminal area. The distances between connection terminals are greater than those required by the IEC Standards and conform to those established by the American regulations (UL 489 Standard).

G1.6 Positive operation

The operating lever always indicates the exact position of the circuit-breaker moving contacts:

- red line (I): Closed position;
- green line (O): Open position;
- yellow-green line: Trip position, open following tripping by the releases or test pushbutton.

The signals are precise and reliable, in compliance with the requirements established by the IEC 60073 and IEC 60417-2 Standards.

When the releases trip, the moving contacts automatically open and the lever moves to the Trip position; to reclose the circuit-breaker the latter must be reset by pushing the operating lever from the trip position to the Open position. From this position is possible re-closing the circuit-breaker.

The circuit-breaker operating mechanism is the free trip type and acts regardless of the pressure put on the lever or the speed of the operation.

G1.7 Isolation behaviour

Characteristic of a mechanical switching device which, in the open and trip position, carries out a disconnection function and provides a sufficient insulating distance (distance between contacts) to guarantee safety.

G1.8 Electromagnetic compatibility

In accordance with the IEC 60947-2 Standard (Annex B + Annex F, European Directive N° 89/336) concerning EMC electromagnetic compatibility, the Tmax family circuit-breakers used with electronic trip units and residual current releases are guaranteed for operation in the presence of interference caused by:

- electromagnetic equipment;
- atmospheric disturbance (static) flowing through the electrical networks;
- interference from radio waves;
- electrostatic discharges.

Moreover, the circuit-breakers do not generate disturbance to the other electronic devices situated in the vicinity of the installation site is generated.

G1.9 Tropicalization

All the Tmax XT series circuit-breakers can be used in the most critical environmental conditions defined by the following standards:

- IEC 60721-2-1 (climatogram 8);
- IEC 60068-2-30;
- IEC 60068-2-2;
- IEC 60068-2-52.

Tropicalization is guaranteed by:

- moulded-case made of synthetic resins reinforced with glass fiber;
- rust-preventive treatment on the main metal parts;
- Fe/Zn galvanisation (UNI ISO 2081), protected by a conversion layer free of hexavalent chrome (in compliance with ROHS) with the corrosion resistance guaranteed by ISO 4520 class 2c;
- application of anti-condensation protection for electronic trip units and relative accessories.

G1.10 Resistance to impact and vibrations

In compliance with IEC 60068-2-6 standards and with the regulations established by the most important classification bodies (RINA, Det Norske Veritas, Bureau Veritas, Lloyd's Register of Shipping, Germanischer Lloyd, ABS and the Russian Maritime Register of Shipping), all the Tmax circuit-breakers are unaffected by mechanically and electromagnetically generated vibrations.

G1.11 Degree of protection (IP)

The IP degree of protection indicates the level of protection of a device against contacts with live parts and penetration of foreign bodies of the liquid and solid type.

Glossary

Performance Parameters

G2.1 Size

Term that indicates a group of circuit-breakers with physical dimension common to a nominal current size (same poles number).

G2.2 Rated uninterrupted current (I_n)

The rated uninterrupted current for a circuit-breaker is the current value, that the circuit-breaker can carry during uninterrupted service.

G2.3 Rated service current (I_e)

Current value defined by the manufacturer, which takes into account the rated service voltage at the rated frequency, the rated service, the utilisation category and the type of protective casing, if any.

G2.4 Rated service voltage (U_e)

The rated service voltage of a device is the voltage value which, along with the rated current value, determines the use of the device itself and which the applicable tests and utilisation category refer to.

G2.5 Rated insulation voltage (U_i)

The rated insulation voltage of a device is the voltage value to which the dielectric tests and surface insulation distances refer. In no case may the rated service voltage value exceed the rated insulation voltage.

G2.6 Rated impulse withstand voltage (U_{imp})

Peak value of an impulse voltage of given shape and polarity that the device can withstand without faults under specified test conditions and to which the insulation clearances refer.

G2.7 Rated ultimate short-circuit breaking capacity (I_{cu})

The rated ultimate short-circuit breaking capacity of a circuit-breaker is the value of the short-circuit current the circuit-breaker is able to break twice (according to the O – t – CO cycle) at the corresponding rated operating voltage. The circuit-breaker is not required to carry its rated current after the opening and closing cycle.

G2.8 Rated service short-circuit breaking capacity (I_{cs})

The rated service short-circuit breaking capacity of a circuit-breaker is the current value the circuit-breaker is able to break three times according to a cycle of opening, pause and closing operations (O - t - CO - t - CO) at a given rated service voltage (U_e) and at a given power factor. After this cycle, the circuit-breaker must be able to carry its rated current.

G2.9 Rated short-time withstand current (I_{cw})

The rated short-time withstand current is the current value the circuit-breaker can carry in the closed position for a short time under specified conditions of service and behaviour. The circuit-breaker must be able to carry this current for as long as the established delay time lasts so as to guarantee selectivity among circuit-breakers installed in series.

G2.10 Rated short-circuit making capacity (I_{cm})

The rated short-circuit making capacity of a device is the value, declared by the manufacturer, that coincides with the rated service voltage, the rated frequency and with a specified alternating current power factor or direct current time constant. It is expressed as the maximum peak value of the prospective current under specified conditions.

G2.11 Utilisation category of circuit-breakers

The utilisation category of a circuit-breaker must be established according to whether it is specifically designed to achieve selectivity by means of an intentional delay or not, in relation to other devices installed in series on the load side, under short-circuit conditions.

It's possible to distinguish two user classes:

Class A - Circuit-breakers not specifically designed for selectivity under short-circuit conditions in relation to other protection devices installed in series on the load side, i.e. without intentional delay, applicable in short-circuit conditions and, therefore, without specification of the short-time withstand current.

Class B - Circuit-breakers specifically designed for selectivity under short-circuit conditions in relation to other protection devices installed in series on the load side, i.e. with an intentional delay (which can be adjusted), applicable under short-circuit conditions. The short-time withstand current is specified for these circuit-breakers (I_{cw}).

A circuit-breaker belongs to category B if its I_{cw} value exceeds:

- between $12I_n$ and 5kA, whichever is higher, for $I_n \leq 2500A$;
- 30kA for $I_n > 2500A$.

G2.12 Utilisation category of non-automatic circuit-breakers

The utilisation category of non-automatic circuit-breakers establishes the type of condition of use.

It is identified by two letters, which indicate the type of circuit in which the device may be installed (AC for alternating current and DC for direct current), a two-digit number for the type of load that can be controlled and an additional letter (A or B), which indicates the operating frequency.

With reference to the utilisation categories, the product Standard establishes the current values the switch-disconnector must be able to break and interrupt under abnormal conditions. The utilisation categories of non-automatic circuit-breakers are listed in the table below:

Nature of the current	Utilisation categories		
	Utilisation category		Typical applications
	Frequent operation	Infrequent operation	
Alternating current	AC-20A	AC-20B	Connection and disconnection under no-load conditions
	AC-21A	AC-21B	Connection and disconnection under no-load conditions
	AC-22A	AC-22B	Resistive load operation including moderate overloads
	AC-23A	AC-23B	Mixed resistive and inductive load operation including moderate overloads
Direct current	DC-20A	DC-20B	Operation of motors or other highly inductive loads
	DC-21A	DC-21B	Operation of resistive loads including moderate overloads
	DC-22A	DC-22B	Mixed resistive and inductive load operation including a moderate overload (e.g. motors with shunt)
	DC-23A	DC-23B	Operation of highly inductive loads

G2.13 Electrical life

The electrical life of a device indicates the number of on-load operating cycles and the resistance of the contacts to electrical wear under the conditions specified in the relative product Standard.

G2.14 Mechanical life

The mechanical life of a device indicates the number of no-load operating cycles (each operating cycle consists of a closing and opening operation) the device is able to carry out without overhauls or replacement of mechanical parts (routine maintenance is allowed).

G2.15 Dissipated power

This is the loss, caused by the joule effect, due to the electrical resistance of the circuit-breaker poles; the energy lost is dissipated in heat.

G2.16 Utilisation categories for operating parts

The utilisation categories given in the table are considered to be standard (CEI EN 60947-5-1).

Type of current	Class	Typical applications
AC	AC-12	Control of resistive loads and electronic loads with insulation obtained by use of optoinsulators
	AC-13	Control of electronic loads with insulation transformer
	AC-14	Control of small electromagnetic loads ($\leq 72VA$)
	AC-15	Control of electromagnetic loads ($> 72VA$)
DC	DC-12	Control of resistive loads and electronic loads with insulation obtained by use of optoinsulators
	DC-13	Control of electromagnets
	DC-14	Control of electromagnetic loads with economiser resistors in the circuit

Glossary

Releases and Protections

G3.1 Release

Device, mechanically connected to a mechanical operating device, which frees the latching components and allows the operating device to be opened or closed.

G3.2 Thermomagnetic trip unit

Thermomagnetic trip units use a bimetal and an electromagnet to detect respectively overloads and short-circuits. They are suitable for protecting both alternating and direct current networks.

G3.3 Magnetic only trip unit

Device for protection against short-circuits which provides a higher magnetic trip threshold than the one available with a thermomagnetic circuit-breaker. The magnetic only release is better able to deal with any problems concerning the particularly high current the motor absorbs during the first instants of its starting phase.

G3.4 Electronic trip unit

Releases connected to current transformers (three or four, depending on the number of conductors to be protected) which, installed inside the circuit-breaker, provide the double function of supplying the power able to operate the release correctly (self-supply) and detecting the value of the current that passes through the live conductors. They are therefore only compatible with alternating current networks.

The signal from the transformers is processed by the electronic part (microprocessor), which compares it with the threshold settings. When the signal exceeds the thresholds, circuit-breaker release is controlled by means of an opening solenoid, which acts directly on the circuit-breaker control unit.

If there is an auxiliary power supply in addition to self-supply, the voltage value must be 24V DC $\pm 20\%$.

G3.5 Residual current release

Device able to detect the earth fault current by means of a toroidal transformer which includes all the live conductors, as well as the neutral if distributed.

Residual current releases can be used in conjunction with the circuit-breaker to obtain two main functions in one single device:

- protection against overloads and short-circuits;
- protection against indirect contacts (voltage on conductive parts owing to loss of insulation).

G3.6 Magnetic protection

Protection against short-circuits with instantaneous trip.

G3.7 Thermal protection

Protection against overloads with inverse long-time delayed trip.

G3.8 Protection against Overloads (L)

Protection against overloads with long inverse time delay trip even with the trip curve established by the IEC 60255-3 Standard. Used in coordination with fuses and medium voltage protections.

G3.9 Protection against instantaneous short-circuit (I)

Provides instantaneous protection against short-circuits.

G3.10 Protection against delayed short-circuit (S)

Provides protection against short-circuit currents with delayed intervention at fixed time or inverse short time. Thanks to the delay setting, this device is particularly suitable when selective coordination must be achieved among the various different devices.

G3.11 Protection against earth faults (G)

Protection against earth faults with delayed fixed time of trip.

G3.12 Residual current protection (I Δ n)

This function is particularly suitable when residual current protection is required for protection against indirect contacts.

G3.13 Protection of the neutral

Detection of overcurrents in the neutral conductor so as to break the phase conductors (neutral protected but not isolated) or to break the neutral conductor itself (neutral protected and isolated).

G3.14 Distribution systems

The distribution system establishes the status of the neutral in the power supply system and the method for connecting the conductive part towards earth.

The Italian standard, CEI 64-8/3 (which is aligned with the IEC 60364-3 international Standard), classifies electrical systems with a combination of two letters. The first indicates the situation of the power supply system towards earth:

- T direct earth connection of an alternating current point, generally the neutral;
- I earth insulation, or earth connection of a point, generally the neutral, by means of an impedance.

The second letter gives the situation of the conductive parts of the electrical installation in relation to the earth:

- T conductive parts directly earthed;
- N conductive parts connected to the earthing point of the power supply system.


Other letters may follow which indicate the arrangement of the neutral and protection conductors:

- S neutral and protection functions carried out by separate conductors;
- C neutral and protection functions carried out by a single conductor (PEN conductor).

The main distribution systems used are illustrated below with reference to these definitions.

G3.15 TT system

In the TT system, the neutral and conductive parts are connected to two electrically independent earthing systems.




G3.16 TN system

In the TN system, the neutral is connected directly to the earth, while the conductive parts are connected to the same earthing system as the neutral.

The TN system is divided into three different types, depending on whether the neutral and protection conductors are separate or not:


1. TN-S: the neutral conductor N and the protection conductor PE are separate




Glossary

Releases and Protections

2. TN-C: the neutral and protection functions are combined in a single conductor called PEN




3. TN-C-S: the neutral and protection functions are partly combined in a single conductor called PEN and partly separate PE+N



Consult QT3: "Distribution systems and protection against indirect contacts and earth faults" for further details.

G3.17 IT system

IT system have no active parts directly earthed, but may have live parts connected to earth through high value impedance. All the exposed-conductive-parts, separately or in group, are connected to an independent earth electrode.



Glossary

Motor protection

G4.1 Protection against phase unbalance and phase loss (U)

Protection function which acts if unbalance between the current values of the individual phases protected by the circuit-breaker is detected (according to IEC 60947 annex T).

G4.2 Rotor lock protection (R)

The function protects motor from possible damages caused by rotor stopping during functioning.

G4.3 Starting current

Is the current value which, in accordance with the CEI EN 60947-4-1 Standard, is assigned a value of about $7.2I_{le}$. It represents the current required by the motor during the starting phase, and which persists throughout the starting time.

G4.4 Starting time

This is the time the motor takes to reach its rated running speed. The starting time depends on the characteristics of the load the motor must drive, and particularly on the type of motor.

G4.5 Operating class

The starting classes distinguish the thermal relays according to their trip curves. The following table (which refers to the most common applications) lists the classes defined in the IEC60947-4-1 Standard.

Operating class	Trip time T_i [s] for $7.2I_{lr}$	Trip time T_i [s] for $7.2I_{lr}$ (banda "E")
2	–	$T_i \leq 2$
3	–	$2 < T_i \leq 3$
5	$0,5 < T_i \leq 5$	$3 < T_i \leq 5$
10A	$2 < T_i \leq 10$	–
10	$4 < T_i \leq 10$	$5 < T_i \leq 10$
20	$6 < T_i \leq 20$	$10 < T_i \leq 20$
30	$9 < T_i \leq 30$	$20 < T_i \leq 30$
40	–	$30 < T_i \leq 40$

Time T_i is the cold trip time of the thermal relay at 7.2 times the set current value. It is common practice to associate class 10 with the normal starting type and class 30 with the heavy-duty starting type.

The other trip classes and trip time indicated under band "E", have recently been introduced in a variant to the CEI EN 60947-4-1 Standard, and are characterised by a more restricted trip range due to raising the minimum non-trip time.

¹⁾ The load characteristics which the motor must carry, the type of motor and the starting methods, are factors which affect the starting time and therefore selection of the thermal trip unit.

G4.6 Contactor

Mechanical operating device with a single stand-by position and non-manual operation able to make, carry and break currents under normal circuit conditions, including overload operating conditions.

G4.7 Utilisation category of the contactor

The Standard establishes different utilisation categories for the contactor. Each category defines precise minimum performance values (e.g. application range or rated breaking capacity) according to current, voltage, power factor or time constant values and test conditions specified in the Standard.

G4.8 PTC

Thermostatic probe able to measure the internal temperature of an electric motor.

Consult QT7: The asynchronous three-phase motor, general information and ABB offer for coordinating the protections" for further details.

Glossary

Communication

G5.1 Communication protocol

Specification of standardized dialogue among several digital devices which exchange data. It is an operating mode based on the structure or length of binary words that must be common to all the elements that exchange data. Communication without dialogue protocol is not possible.

G5.2 Modbus RS485

This is a basic communication protocol, one of the most widespread standards in industrial automation and power distribution spheres.


G5.3 Network

A network generically consists of nodes interconnected with communication lines:

- the node (an “intelligent” device able to dialogue with other devices) is the data transmission and/or reception point;
- the communication line is the element that connects two nodes and represents the direct path the information takes in order to be transferred between two nodes. In practice, it is the physical means (coaxial cable, twisted telephone cable, optic fibre, infrared rays) along which the information and data travel.

G5.4 Bus network

The bus network structure is based on a common transmitting means (usually a twisted cable or coaxial cable) for all the nodes connected, therefore in parallel.



Consult QT9: “Communication with ABB circuit-breakers via Bus” for further details.

Glossary

Standards and Regulations

G6.1 Standards

Technical specification approved by a recognised organisation with the task of defining the state-of-the-art characteristics (dimensional, environmental, safety, etc.) of a product or service.

G6.2 Directive

Ensemble of rules which define the essential requirements regarding safety which the products must comply with in order to guarantee user safety.

G6.3 Naval Register

A Body able to certify a product/service as conforming to the regulations/criteria fixed internationally by the International Maritime Organization. The certification issued confirms that a ship is authorised to carry out the activity it was designed for.

G6.4 RoHS Directive

European Directive 2002/95/EC of 27 January 2003 (Decree Law 25 N° 151 of July 2005) aimed at eliminating or reducing the use of dangerous substances in electrical and electronic equipment. It requires manufacturers and companies to adapt to the relative provisions and to compile a manufacturer's declaration, without certification by third parties.

G6.5 CE marking

This is a mark that must be affixed to certain types of product by the manufacturer in order to self-certify correspondence (or conformity) with the essential requirements for marketing and use of that product in the European Union. The law requires this mark to be affixed on the product so that it can be marketed in the European Economic Area (EEA) member states.

Symbols

SYMBOL	DESCRIPTION
CB	Circuit-breaker
PF	Fixed part
PM	Mobile part
F Version	Circuit-breaker in fixed version
P Version	Circuit-breaker in plug-in version
W Version	Circuit-breaker in withdrawable version
F	Front terminals
EF	Front extended terminals
ES	Front extended spread terminals
FCCuAl	Terminal for copper/aluminium cables
FCCu	Terminal for copper cables
R	Rear terminals
HR/VR	Rear flat vertical/horizontal terminals
FB	Terminals for flexible busbars
MC	Multi-cable terminal
HTC	High terminal covers
LTC	Low terminal covers
PS	Phase separators
RHD	Direct rotary handle
RHE	Transmitted rotary handle
RHE-LH	Transmitted rotary handle with wide handgrip
RHS	Lateral rotary handle
FLD	Front for locks
PLL	Padlock device
KLC	Key lock
SOR or YO	Shunt opening release
PS-SOR or YO	Permanent shunt opening release
UVR or YU	Undervoltage release
UVD	Time-delay device for undervoltage release
AUX Q	Auxiliary contact in open/closed position
AUX SY	Auxiliary contact tripped
AUX S51	Release tripped auxiliary contact
SA	Opening solenoid of residual current device
AUP-I	Plugged-in auxiliary position contacts
AUP-E	Withdrawn auxiliary position contacts
AUE	Early auxiliary contacts on the handle
MOD	Direct action motor operator
MOE	Stored energy motor operator
MOE-E	Electronic motor operator
CB	Circuit-breaker
NE	External neutral
RHx	All the handles (RHD, RHE, RHE-UI, RHS)
3Q	Left open/closed auxiliary contacts
24V	24V auxiliary voltage
AUE inside	Early auxiliary contacts inside the circuit-breaker

ABB SACE documentation

The technical documentation is available on-line on BOL web site <http://bol.it.abb.com> in "Work tools - Technical guides" section:

- Technical Application Paper, volume 1 "Low voltage selectivity with ABB circuit-breakers"
- Technical Application Paper, volume 2 "MV/LV transformer substations: theory and example of short-circuit calculation"
- Technical Application Paper, volume 3 "Distribution system and protection against indirect contact and earth fault"
- Technical Application Paper, volume 4 "ABB circuit-breakers inside LV switchboards"
- Technical Application Paper, volume 5 "ABB circuit-breakers for direct current applications"
- Technical Application Paper, volume 6 "Arc-proof low voltage switchgear and controlgear assemblies"
- Technical Application Paper, volume 7 "Three-phase asynchronous motors. Generalities and ABB proposals for the coordination of protective devices"
- Technical Application Paper, volume 8 "Power factor correction and harmonic filtering in electrical plants"
- Technical Application Paper, volume 9 "Bus communication with ABB circuit-breakers"

Contact us

ABB SACE

A division of ABB S.p.A.

L.V. Breakers

Via Pescaria, 5

24123 Bergamo – Italy

Phone: +39 035 395 111

Fax: +39 035 395 306-433

www.abb.com

The data and illustrations are not binding. We reserve the right to make changes in the course of technical development of the product.

© Copyright 2015 ABB.
All rights reserved.



Stay tuned. Discover more by visiting the webpages reserved to Tmax XT and be always up-to-date with the latest edition of the catalogue.