


Håndbetjente motorværn

Guide til valg af tilbehør til MS132, MS132T og MS165



Hjælpekontakter til MS132/MS132T/MS165

Monteringssted	Kontaktkonfiguration			Kontaktfunktioner			Varenumre	
	Front	Slutte (NO)	Bryde (NC)	Bryderposition	Overbelastning	Kortslutning	Type	EAN-nr.
✓		1	1		✓		HK1-11	4013614320361
✓		2	0		✓		HK1-20	4013614320378
✓		0	2		✓		HK1-02	4013614320385
	✓	1	1		✓		HKF1-11	4013614320354
	✓	2	0		✓		HKF1-20	4013614480614
	✓	1	0		✓		HKF1-10	4013614502620
	✓	0	1		✓		HKF1-01	4013614502644
✓		1	1			✓	SK1-11	4013614320392
✓		2	0			✓	SK1-20	4013614320408
✓		0	2			✓	SK1-02	4013614320415
✓		1	1			✓	CK1-11	4013614403927
✓		2	0			✓	CK1-20	4013614403934
✓		0	2			✓	CK1-02	4013614403941

ABB A/S
Meterbuen 33
2740 Skovlunde, Danmark
Tlf.: 4450 4450
contact.center@dk.abb.com

Vi forbeholder os retten til at ændre indholdet af dette dokument uden forudgående varsel.

Copyright© 2019 ABB
Alle rettigheder forbeholdes